Edition: April 21, 2006

Service Manual

Lexmark™ X642e, X644e, X646e MFP

7002-xxx

- Table of Contents
- Start Diagnostics
- Safety and Notices
- Trademarks
- Index

LEXMARK™

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

Edition: April 21, 2006

The following paragraph does not apply to any country where such provisions are inconsistent with local law: LEXMARK INTERNATIONAL, INC. PROVIDES THIS PUBLICATION “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

Comments may be addressed to Lexmark International, Inc., Department D22A/032-2, 740 West New Circle Road, Lexington, Kentucky 40550, U.S.A or e-mail at ServiceInfoAndTraining@Lexmark.com. Lexmark may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Lexmark, Lexmark with diamond design, MarkNet, and MarkVision are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

PrintCryption is a trademark of Lexmark International, Inc.

LEXFAX is a service mark of Lexmark International, Inc.

Other trademarks are the property of their respective owners.

© 2006 Lexmark International, Inc.
All rights reserved.

UNITED STATES GOVERNMENT RIGHTS
This software and any accompanying documentation provided under this agreement are commercial computer software and documentation developed exclusively at private expense.

P/N 12G9662

Table of contents

Laser notices xi

Preface xx

General information 1-1

Maintenance approach 1-1
Configured models 1-2
Options 1-3
Specifications 1-4
General 1-4
Resolution 1-4
Data streams 1-4
Memory configuration 1-5
Recommended operating clearances 1-5
Dimensions 1-6
Power requirements 1-7
Electrical specifications 1-7
Environment 1-8
Acoustics 1-8
Media specifications 1-9
Paper and specialty media guidelines 1-9
Supported print media 1-9
Print media sizes 1-9
Print media types 1-11
Print media weights 1-11
Selecting print media 1-13
Paper 1-13
Paper characteristics 1-13
Transparencies 1-14
Envelopes 1-14
Labels. 1-15
Card stock 1-16
Storing print media 1-16
Avoiding jams 1-16
Tools required 1-17
Acronyms 1-18

Diagnostic information 2-1

Start 2-1
Symptom tables 2-1
Service errors (8xx.xx and 9xx.xx's) 2-1
User status and attendance messages 2-1
Additional information. 2-1
Understanding the MFP operator panel 2-2
MFP operator panels 2-2
Home screen and Home screen buttons 2-4
Buttons and touchscreen icon buttons 2-4
Menus 2-9
Symptom tables 2-10
Printer symptoms 2-10
Scanner—ADF symptoms 2-11
Scanner—flatbed symptoms 2-11

Scanner—scan quality 2-11
High-capacity feeder (2000-sheet) symptoms 2-11
Paper tray symptoms 2-12
Duplex option symptoms 2-12
Envelope feeder symptoms 2-12
Messages and error codes 2-13
Service error codes 2-13
Sub error codes for 8*xx*, 9*xx*, and 2*xx* error codes 2-13
User status displays. 2-38
User attendance messages 2-42
User line 2 link messages 2-56
Check device connection messages 2-56
User attendance messages—paper jams and paper handling errors (2*xx.xx*) 2-57
Service checks 2-95
290.00 Error code service check 2-95
290.01 Error code service check 2-97
290.02 Error code service check 2-99
290.10 Error code service check 2-101
291.00 Error code service check 2-102
291.01 Error code service check 2-104
291.02 Error code service check 2-105
292.00 Error code service check 2-106
293 Error code service check 2-107
294.00 Error code service check 2-108
294.01 Error code service check 2-109
294.02 Error code service check 2-111
294.03 Error code service check 2-112
298.01 Error code service check—models X644e/X646e 2-114
298.02 Error code service check 2-114
842.xx Error code service check 2-114
843.00 Error code service check 2-115
845.00 Error code service check 2-115
848.00 Error code service check 2-116
848.01 Error code service check 2-116
900.xx Error code service check 2-116
900.90 Error code service check 2-116
927.xx Fan service check 2-117
Main fan service check 2-117
Cartridge fan service check. 2-117
950.00 through 950.29 EPROM mismatch failure 2-118
950.30 through 950.60 EPROM mismatch failure 2-119
ADF paper length sensor service check—models X644e/X646e 2-120
ADF paper width sensor service check—models X644e/X646e 2-121
Charge roll service check 2-121
Cover closed sensors service check—flatbed 2-122
Cover closed switch/cable service check—printer 2-123
Dead machine service check 2-123
Duplex option service check 2-125
Envelope feeder service check 2-127
Flatbed size sensor service check 2-129
Fuser service checks 2-130
920.xx—Cold fuser service check. 2-130
922.xx—Cold fuser check 2-132
923.xx—Hot fuser service check. 2-133
924.xx—Hot fuser service check. 2-134
925.xx—Hot fuser service check. 2-135
Fuser exit sensor service check 2-136
Fuser narrow media sensor service check 2-137

High-capacity feeder input tray service check 2-139
Input sensor service check 2-144
Input tray(s) service check 2-145
Interface card service check 2-146
LCD touchscreen contrast control service check—model X642e 2-147
LCD touchscreen display service check—models X644e/X646e 2-147
Main drive service check 2-151
Operator panel Help and Home buttons service check—model X642e 2-152
Operator panel Menu button service check—model X642e 2-152
Operator panel right cover assembly service check 2-153
Options service check 2-154
Flash memory option(s) 2-154
DRAM memory option(s) 2-154
Hard disk option 2-154
Output bin sensor standard tray service check 2-155
Paper feed service check—printer 2-155
Paper size sensing service check 2-157
Parallel port service check 2-158
Print quality service check 2-159
Scan quality service check 2-164
Signature button assembly service check 2-169
System board service check 2-169
Toner sensor service check 2-170
Transfer roll service check 2-171

Diagnostic aids 3-1

Accessing service menus 3-1
Diagnostics Menu 3-2
Entering Diagnostics Menu 3-2
Available tests 3-2
Registration (printer) 3-5
Quick Test 3-6
PRINT TESTS 3-7
Input source tests 3-7
Printing Quality Pages 3-7
HARDWARE TESTS 3-8
Panel Test 3-8
Button Test 3-8
DRAM Test 3-9
CACHE Test 3-9
Parallel Wrap test 3-10
Serial Wrap test 3-10
DUPLEX TESTS 3-11
Quick Test (duplex) 3-11
Top Margin (duplex) 3-11
Sensor Test (duplex) 3-12
Motor Test (duplex) 3-12
Duplex Feed 1 3-13
Duplex Feed 2 3-13
INPUT TRAY TESTS 3-13
Feed Tests (input tray) 3-13
Sensor Test (input tray) 3-14
OUTPUT BIN TESTS 3-14
Feed Tests (output bins) 3-14
Sensor Test (standard output bin) 3-15
BASE SENSOR TEST 3-15

DEVICE TESTS 3-16
Quick Disk Test 3-16
Disk Test/Clean 3-16
Flash Test 3-17
PRINTER SETUP 3-17
Defaults 3-17
Printed Page Count 3-18
Permanent Page Count 3-18
Serial Number 3-18
Envelope Enhance 3-18
Engine Setting 1 through 4 3-18
Model Name 3-18
Configuration ID 3-19
Edge to Edge 3-19
Parallel strobe adjustment (Par *x* Strobe Adj) 3-19
EP SETUP 3-20
EP Defaults 3-20
Fuser Temperature (Fuser Temp) 3-20
Fuser Page Count 3-20
Warm Up Time 3-20
Transfer 3-21
Print Contrast 3-21
Charge Roll 3-21
Gap Adjust 3-21
EVENT LOG 3-21
Display Log 3-21
Print Log 3-22
Clear Log 3-22
SCANNER TESTS 3-23
ASIC Test 3-23
Feed Test 3-23
Scanner Manual Registration 3-23
Sensor Tests 3-23
Configuration menu (CONFIG MENU) 3-24
Entering Configuration Menu 3-24
Available menus 3-24
Maintenance Page Count 3-25
Reset Maintenance Counter 3-25
Print Quality Pages 3-26
SIZE SENSING 3-26
Panel Menus 3-27
PPDS Emulation 3-27
Factory Defaults 3-28
Energy Conserve 3-28
Min Copy Memory 3-29
Format Fax Storage 3-29
ADF Edge Erase 3-29
FB Edge Erase 3-30
Automatic Scanner Registration 3-30
EVENT LOG 3-31
Paper Prompts 3-31
Envelope Prompts 3-32
Jobs On Disk 3-32
Disk Encryption 3-32
Wipe Disk 3-33
Font Sharpening 3-34
Require Standby 3-34
LES Applications 3-34

Key Repeat Initial Delay . . . 3-35
Key Repeat Rate . . . 3-35
Wiper Message . . . 3-35
Exit Configuration Menu . . . 3-35
Theory . . . 3-36
Autocompensator operation . . . 3-36
Autoconnect system, paper tray options, envelope feeder—electrical . . . 3-37
Autoconnect cabling and connectors . . . 3-37
Duplex Option . . . 3-37
Option microcode . . . 3-37
Paper feed jams . . . 3-38
Identifying jams . . . 3-38
Access doors and trays . . . 3-39
Understanding jam messages . . . 3-40
Clearing jams . . . 3-40
250 Paper Jam Check MP Feeder . . . 3-40
260 Paper Jam Check Env Feeder . . . 3-41
23x and 24x jams . . . 3-43
200 and 201 Paper Jam Remove Cartridge . . . 3-46
202 Paper Jam Open Rear Door . . . 3-47
23x Paper Jam Open Duplex Rear Door . . . 3-48
Clearing ADF jams . . . 3-49
290, 291, 292, and 294 Scanner Jams . . . 3-49

Repair information . . . 4-1
Handling ESD-sensitive parts . . . 4-1
Adjustment procedures . . . 4-2
Fuser solenoid adjustment . . . 4-2
Gap adjustment . . . 4-2
Printhead assembly adjustment—printer . . . 4-2
Paper alignment assembly adjustment . . . 4-3
Scanner registration . . . 4-4
Automatic Scanner Registration . . . 4-4
Manual registration . . . 4-5
Removal procedures . . . 4-6
Scanner ADF and flatbed removals . . . 4-6
ADF front cover removal . . . 4-6
ADF pick assembly removal . . . 4-7
ADF rear cover removal . . . 4-7
ADF top cover removal . . . 4-9
Scanner left side cover removal . . . 4-10
Front flatbed cover removal . . . 4-11
Scan cover (flatbed) removal . . . 4-11
Scanner right side cover removal . . . 4-12
ADF attach screws removal . . . 4-13
ADF CCD module assembly removal (models X644e/X646e) . . . 4-14
ADF complete assembly removal . . . 4-15
ADF upper entrance guide assembly removal . . . 4-16
CCD belt removal . . . 4-17
CCD belt tension spring removal . . . 4-19
Cover closing actuator removal . . . 4-21
Cover closed actuator removal . . . 4-22
Document tray assembly removal . . . 4-23
Flatbed CCD ribbon cable removal . . . 4-24
Flatbed CCD module assembly removal . . . 4-28
Flatbed contact glass removal . . . 4-31
Flatbed white cushion removal . . . 4-32

Flatbed interconnect card removal 4-33
Flatbed paper length sensor assembly removal 4-35
Flatbed scan assembly removal 4-38
Flatbed scan motor assembly removal 4-41
Hard disk removal 4-44
Home sensor removal 4-46
Lower exit guide assembly removal 4-47
Pickup solenoid assembly removal 4-48
Scanner control card removal 4-48
Scanner flatbed glass holder assembly removal 4-50
Separator assembly torque limiter removal 4-52
Upper glass holder removal 4-53
Printer removals 4-54
Fuser wiper cover assembly removal 4-54
Upper sub cover removal 4-55
Upper tray cover removal (paper support) 4-56
Printer left side cover removal 4-56
Redrive door 4-58
Printer right cover removal 4-58
Operator panel left cover assembly removal 4-61
Operator panel right cover assembly removal 4-64
Touchscreen bezel removal 4-66
LCD touchscreen removal—models X644e and X646e 4-67
LCD touchscreen removal—model X642e 4-69
Multipurpose feeder/lower front cover assembly removal 4-71
Left cover handle holder removal 4-72
Right cover handle holder removal 4-72
Left and right frame extensions 4-73
Pass thru plate 4-74
Bevel gear removal 4-75
Developer drive assembly removal 4-77
Developer drive coupler kit removal 4-78
ESD cover removal 4-78
Fuser assembly removal 4-79
Fuser exit sensor removal 4-82
Fuser exit sensor flag and spring removal 4-84
Fuser lamp removal 4-86
Fuser narrow media sensor removal 4-88
Fuser narrow media flag and spring removal 4-90
Fuser to LVPS AC cable removal 4-92
Fuser top cover removal 4-95
Fuser transfer plate removal 4-97
Gear release link removal 4-98
High voltage power supply removal 4-99
Inner paper deflector assembly removal 4-101
Input sensor removal 4-102
Integrated tray autocompensator assembly removal 4-103
Integrated tray autocompensator pick roll assembly removal 4-105
Interface card assembly removal 4-107
LCD inverter card assembly removal 4-108
Low voltage power supply removal 4-109
Main fan removal 4-111
Main drive assembly removal 4-113
Modem removal 4-115
MPF arm assembly removal 4-116
MPF lower paper deflector 4-117
MPF pick tire removal 4-118
MPF solenoid assembly removal 4-119

Paper alignment assembly removal 4-122
Paper bin full sensor flag removal 4-124
Paper size sensing board removal 4-125
Power takeoff shaft and spring removal 4-126
Printer outer shield removal 4-126
Printhead removal 4-127
Redrive assembly removal 4-128
Signature button contact assembly removal 4-129
System board and inner shield removal—model X642e 4-130
System board and inner shield removal —models X644e/X646e 4-131
Toner sensor removal 4-132
Transfer roll assembly removal 4-132
Upper cover removal (printer) 4-133
Upper front cover hinge assembly removal 4-136
Upper paper deflector assembly removal 4-138
USB card 4-139

Locations and connections 5-1

Locations 5-1
Sensors—flatbed 5-1
Sensors—ADF 5-2

Connections 5-3
System board 5-3
Autoconnect 5-8
Fuser board 5-9
High voltage power supply 5-9
Interface card 5-10
USB card 5-10
Low voltage power supply 5-11
Operator panel card (UICC #1)—model X642e 5-12
Operator panel card (UICC #1)—models X644e/X646e 5-14
LCD inverter board (IUCC #2) 5-16
Scanner control card 5-17
Motor driver board 5-23
Flatbed interconnect card 5-26
Modem card 5-31

Preventive maintenance 6-1

Safety inspection guide 6-1
Lubrication specifications 6-1
Scheduled maintenance 6-1
Maintenance kit 6-1
Cleaning the scanner glass, cushions, and strips 6-2

Parts catalog 7-1

How to use this parts catalog 7-1
Assembly 1: Covers—printer (model X642e) 7-2
Assembly 2: Cover—printer (models X644e and X646e) 7-6
Assembly 3: Covers—ADF scanner 7-8
Assembly 4: Frame 1 7-10
Assembly 5: Frame 2 7-12
Assembly 6: Frame 3 7-14
Assembly 7: Scanner automatic document feeder (ADF)—pickup 7-16
Assembly 8: Scanner ADF—paper feed 7-17

Assembly 9: Scanner ADF—lower exit guide assembly 7-18
Assembly 10: Scanner ADF—motors and belts 7-19
Assembly 11: Scanner ADF—sensors 7-20
Assembly 12: Scanner—flatbed 7-22
Assembly 13: Printhead 7-24
Assembly 14: Paper feed—autocompensator 7-25
Assembly 15: Paper feed—multipurpose feeder 7-26
Assembly 16: Paper feed—alignment 7-28
Assembly 17: Integrated 500-sheet paper tray 7-30
Assembly 18: Drives—Main drive and developer drive 7-32
Assembly 19: Hot roll fuser 7-34
Assembly 20: Transfer/charging 7-36
Assembly 21: Electronics—power supplies 7-38
Assembly 22: Electronics—card assemblies 7-40
Assembly 23: Electronics—shields 7-42
Assembly 24: Cabling diagram 1 7-43
Assembly 25: Cabling diagram 2 7-44
Assembly 26: Cabling diagram 3 7-45
Assembly 27: Cabling diagram 4—model X642e 7-46
Assembly 28: Cabling diagram 4—models X644e/X646e 7-48
Assembly 29: Cabling diagram 5 7-50
Assembly 30: Cabling diagram 6—model X642e 7-52
Assembly 31: Cabling diagram 6—models X644e/X646e 7-54
Assembly 32: Cabling diagram 7 7-56
Assembly 33: Cabling diagram 8—model X642e 7-57
Assembly 34: Cabling diagram 8—models X644e/X646e 7-58
Assembly 35: Optional 250-sheet paper drawer 7-59
Assembly 36: Optional 250-sheet paper tray 7-60
Assembly 37: Optional 500-sheet paper drawer 7-61
Assembly 38: Optional 500-sheet paper tray 7-62
Assembly 39: Duplex option 7-63
Assembly 40: Envelope feeder 7-64
Assembly 41: High-capacity feeder 1 7-66
Assembly 42: High-capacity feeder 2 7-68
Assembly 43: High-capacity feeder 3 7-69
Assembly 44: High-capacity feeder 4 7-70
Assembly 45: Options 7-71

Index I-1

Part number index I-9