



Maintenance Reset Instructions - HP CLJ Printers Transfer Kit and Fuser Kit

CLJ 4500

Service mode:

- Hold JOB CANCEL and SELECT buttons at power up until the three lights remain solid
- Release, then press MENU (right side) then SELECT
- Printer should display SERVICE MODE
- Scroll until printer reads "TRANSFER COUNT" or "FUSER COUNT"
- Set all digits to zero

CLJ 4550

- Scroll MENU button to resets menu then press SELECT button on either "RESET FUSER LIFE COUNT" or "RESET TRANSFER LIFE COUNT"

CLJ 8500 CLJ 8550

- Scroll MENU button to resets menu
- Press SELECT button on either "RESET FUSER LIFE COUNT" or "RESET TRANSFER LIFE COUNT"

CLJ 4600 / CLJ4650 – CLJ5500 / CLJ5550

- With printer at ready state, scroll until "CONFIGURE DEVICE" (✓)
- to "RESETS" (✓)
- to "RESET SUPPLIES" (✓)
- Highlight either "NEW FUSER KIT" or "NEW TRANSFER KIT"
- Press (✓) then to "YES" (✓)

CLJ 4700 / CLJ CP4005 / CLJ 4730 MFP / CLJ CM4730 MFP

This series has the fuser and transfer belt designed to automatically reset the consumable counters.

Please Note:

- Printers must be tuned off when changing either part
- There is now way to reset either fuser or transfer count other than replacing the component

CLJ 9500

With printer at ready state:

- Scroll to "CONFIGURE DEVICE" (✓)
- to "RESETS" (✓)
- to "RESET SUPPLIES" (✓)
- Highlight either "NEW FUSER KIT" or "NEW TRANSFER KIT"
- Press (✓) then to "YES" (✓)