



www.LaserPros.com

Item Number	Item Description
RM1-0013	HP 4200 Fusing Assembly
Q7848-61006	HP P3005 Duplex Formatter Board - Network
RM1-2763	HP CLJ 2700/3000/3600/3800/CP3505 Fusing Assembly
RM1-1535	HP 2410/2420/2430 Fusing Assembly
RG5-5750	HP 9000/9040/9050/M9040/M9050 Fusing Assembly
RG5-7060	HP 5100 Fusing Assembly
RM1-4559	HP P4014/4015/4515 500 Sheet Tray 2 Paper Cassette
RM1-1088	HP 4200/4250/4300/4350 500 Sheet Paper Tray
RM1-0715	HP 1300/1150 Fusing Assembly
RG5-0876	HP 4+/5 Drive Train Gear Assembly
RG5-1852	HP 5Si/8000 Paper Input Unit
RM1-2522	HP 5200 Fusing Assembly
RG5-6467	HP CLJ 4600/4650 MP Tray 1 Assembly
RG5-6208	HP 9000/9040/9050/9500 2000 Sheet Feeder PPU Assembly
CC519-67919	HP CM3530MFP/CP3525 Fusing Assembly
RM1-6274	HP P3015 Fusing Assembly
CC519-67904	HP CM3530MFP 80GB Hard Drive
RG5-5643	HP 9000/9050 Face Down Delivery Assembly
RG5-5663	HP 9000/9040/9050 Registration Assembly
Q2440A	HP 4200/4300 Optional 500 Sheet Assembly
RM1-2705	HP CLJ 3000/3600/3800/CP3505 250 Sheet Cassette
Q3722-69002	HP 9050 Formatter Board - Network
RM1-3007	HP M5025/5035MFP Fusing Assembly
C3765B	HP 5Si/8000/8100/8150 Envelope Feeder
Q3942-69011	HP 4345MFP Formatter Board - Network
RG5-4132	HP 2100 Fusing Assembly
40X4194	Lexmark 4505 X20X/34X/E238/33X/34X Fuser Assembly
RG5-6391	HP CLJ 4600 DC Controller
RG5-6647	HP CLJ 5500/5550 Tray 2 500 Sheet Paper Cassette
J6054-69051	HP EIO 40GB Disk
Q3713-69002	HP CLJ 5550 Formatter Board - Non Network
Q7819-61009	HP M3027/3035MFP Formatter Board
CB356-67901	HP 1320 Formatter Board - Network
Q3948-60191	HP CLJ 2820/2840 Flatbed Scanner Assembly
RM1-1080	HP 4250/4350 Cartridge Access Door Cover Assembly
CB480-69002	HP CLJ 4730/CM4730MFP Formatter Board - Network
RM1-4228	HP P1505 Fusing Assembly (RM1-4208)



www.LaserPros.com

RM1-1354	HP 4345/M4345MFP DC Controller Assembly
CB518-67901	HP P4014/4015/4515 Optional 500 Sheet Feeder
CB425-67911	HP M4345MFP Formatter Board
RG5-7709	HP CLJ 5500/5550 Tray 2 Paper Pickup Assembly
RH3-2258	HP CLJ 9500MFP Power Supply Assembly
99A2444	Lexmark 4069 T620/622 500 Sheet Pickup Assembly
C8053B	HP 4000/4050/4100 Envelope Feeder
RG5-6090	HP CLJ 9500 Manual Tray 1 Feed Assembly
RG5-7079	HP 5100 Main Drive Gear Assembly
RG9-1486	HP 1005/1200/3300/3330 Laser Scanner Assembly
RM1-0463	HP CLJ 3500/3550/3700 Front Cover Assembly
CC399-67901	HP CM2320MFP Simplex Formatter Board - Network
RG5-0085	HP III Si DC Power Supply
RG5-6670	HP CLJ 5500/5550 Tray 2 Pickup Assembly
RM1-2715	HP CLJ 3000/3600/3800 Front Cover Assembly - Duplex
C4122A	HP 4000/4050 Envelope Feeder
C4125A	HP 4000/4050 500 Sheet Tray (C4125-67901)
CB409-60001	HP 1020 Formatter Board
CC476-67912	HP M3027/3035MFP Legal ADF Assembly
PF2282-SVPCR	HP M4345MFP Auto Document Feeder Assembly
Q7492-69003	HP CLJ 4700 Formatter Board - Network
RG5-6225	HP 9000/9040/9050/CLJ 9500 Vertical Transfer Unit Assembly
RH7-1522	HP CLJ 9500/9500MFP Cooling Fan
RH7-1658	HP 9000/9040/9050/9500MFP Fan
56P2502	Lexmark 5060 C752 System Board - Non Network
CC476-67911	HP M3035MFP Legal Size Scanner Assembly without ADF
Q6445-60001	HP 3390/3392AIO Duplex Formatter Board - Network
RG5-4410	HP 8000/8100/8150 Tray 4/5 Pickup Assembly
RG5-7572	HP CLJ 2550 Fusing Assembly
RM1-3258	HP CM6030MFP/CP6015 Color Plane Registration Sensor Assembly
RM1-5550	HP CP4025/4525 Fusing Assembly
RM1-5779	HP CP4025/4525 HVPS Lower
RM1-5781	HP CP4025/4525 HVPS Upper
RM1-6300	HP P3015 HVPS Assembly - Simplex
40X1304	Lexmark 4511 E340/342 Laser/Mirror Printhead Assembly
40X1307	Lexmark 4511 E340 Controller Card
40X1309	Lexmark 4511 E340/342 Front Access Cover Assembly
40X1315	Lexmark 4511 E340/342 LCD Operator Control Panel



www.LaserPros.com

40X1317	Lexmark 4511 E238/240/340/342 LVPS/HVPS Card Assembly
40X1335	Lexmark 4511 E238/240/340/342 Top Cover Assembly
40X1339	Lexmark 4511 E238/240 Rear Cover Assembly
C9674-67901	HP CLJ 9500 Duplexer Assembly
Q3726-69007	HP 9040/9050MFP Formatter Board
Q3948-67903	HP CLJ 2820/2840AIO ADF Paper Pickup Assembly
Q5982-69001	HP CLJ 3000/3800 Simplex Formatter Board - Network
Q6500-67903	HP 3390/3392MFP Automatic Document Feeder
RC1-0287	HP 4200/4300 Left Cover
RC2-7670	HP P3015 Right Cover Assembly
RC2-7672	HP 3015 Right Front Cover Assembly
RC2-7673	HP P3015 Right Rear Cover Assembly
RC2-7674	HP P3015 DIMM Cover Assembly
RC2-7676	HP P3015 Upper Right Cover Assembly - Duplex
RC2-7688	HP P3015 Formatter Cover Assembly
RC2-7707	HP P3015 Upper Right Cover Assembly - Simplex
RG0-1015	HP 1200 Toner Access Door
RG1-4140	HP CLJ 4600/4650 500 Sheet Tray
RG5-6563	HP 4100/4101MFP ADF Control Panel
RG5-6770	HP CLJ 5500/5550 Tray 3 500 Sheet Paper Cassette
RG5-7057	HP 5100 DC Controller
RH7-1144	HP 4/4M Upper Right Rear Fan
RM1-1041	HP 4345/M4345MFP Engine Power Supply
RM1-1108	HP 4250/4350 DC Controller
RM1-3538	HP CM6030/6040MFP/CP6015 1 x 500 Sheet Paper Tray Right Door Assy
RM1-5001	HP CM3530MFP/CP3525 Fusing Drive Assembly - Simplex
RM1-6264	HP P3015 Cartridge Door Assembly
RM1-6265	HP P3015 Multipurpose Cover Assembly
RM1-6266	HP P3015 Multipurpose Tray 1 Lifting Plate Assembly
RM1-6280	HP P3015 HVPS PCB Assembly - Duplex
RM1-6289	HP P3015 Top Cover Assembly
RM1-6291	HP P3015 Left Cover Assembly
RM1-6292	HP P3015 Rear Cover
RM1-6518	HP P3015 Control Panel Assembly - Duplex
RM1-6519	HP P3015 Control Panel Assembly - Simplex
12G0253	Lexmark 4045 M410/412 Top Cover
12G4184	Lexmark 4025 W820 Fuser Assembly
40X4576	Lexmark 4062 T65X/X651/652/654/656 550 Sheet Feeder



www.LaserPros.com

CC493-69001	HP CP4025/4525 Formatter PC Board
CC516-69002	HP CM6040MFP Intermediate Paper Transport Unit
CC519-67903	HP CM3530MFP Formatter Board
CE475-69001	HP P3015 Formatter Board - Network
CE860-67901	HP CP5525 Tray 3 500 Sheet Feeder
FG3-2887	HP CP6015/CM6030/6040MFP Tray PCA Board
Q3938-67905	HP CM6030/6040/6049MFP Inverter Assembly
Q3938-67908	HP CM6030/6040/6049MFP Scanner Motor
Q3938-67920	HP CM6030/6040/6049MFP Upper Left Cover
Q3938-67921	HP CM6030/6040/6049MFP ADF Lower Left Cover
Q3938-67922	HP CM6030/6040/6049MFP Upper Right Cover
Q3938-67923	HP CM6030/6040/6049MFP ADF Lower Right Cover
Q3938-67924	HP CM6030/6040/6049MFP ADF Top Cover
Q3938-67925	HP CM6030/6040/6049MFP ADF Rear Cover
Q3938-67926	HP CM6030/6040/6049MFP Front Cover
Q3938-67972	HP CM6030/6040/6049MFP Carriage Assembly
Q5982-69002	HP CLJ 3000/3800 Duplex Formatter Board - Network
Q6497-69005	HP 5200 Formatter Board - Non Network
Q6507-61006	HP 2410/2420/2430 Formatter Board - Network
Q7829-60183	HP M5025/5035MFP Scanner Control Board
Q7829-60185	HP M5025/5035MFP Scanner
RC1-9871	HP CM6030/6040MFP/CP6015 1 x 500 Sheet Paper Tray Rear Cover
RC1-9872	HP CM6030/6040MFP/CP6015 1 x 500 Sheet Paper Tray Left Cover
RG5-6150	HP CLJ 9500 Delivery Feed Assembly
RG5-6390	HP CLJ 4600 Laser Scanner Assembly
RM1-1784	HP CLJ 4700/CP4005 Duplexer Assembly
RM1-2112	HP CLJ 4730 Duplexer Assembly
RM1-3531	HP CM6040MFP Auto Close Assembly
RM1-3537	HP CM6030/6040MFP/CP6015 3 x 500 Sheet Paper Tray Right Door Assy
RM1-3569	HP CM6030/6040MFP/CP6015 Input Tray Paper Feed PCA Assy
RM1-3686	HP CM6030/6040/6049MFP/CP6015 Intermediate Lower Feed Guide Assy
RM1-4563	HP P4014/4015/4515 MP Tray/Tray 1 Pickup Assembly
RM1-5494	HP CP4025/4525 Face Down Delivery Tray
RM1-5509	HP CP4025/4525/CM4540MFP Right Door Assembly
RM1-5522	HP CP4025/4525 Delivery Assembly Duplex
RM1-5546	HP CP4025/4525 Duplexing Drive Assembly
RM1-5549	HP CP4025/4525 Tray 1 Paper Pickup Drive Assembly
RM1-5605	HP CP4025/4525 Waste Toner Motor Assembly



www.LaserPros.com

RM1-5636	HP CP4025/4525 Interconnecting PCA Assembly
RM1-5914	HP CP4025/4525 Lifter Assembly
RM1-6322	HP P3015 Laser Scanner Assembly
40X0001	Lexmark 4061 T64X Fuser Wiper Cover Assembly
40X0647	Lexmark 4024 W840/850 Fuser Assembly
56P1066	Lexmark 4500 E321/323 Optional Feeder - White
56P9531	Lexmark 5055 C910/912 Exit Tray Assembly
56P9983	Lexmark 5055 C910 RIP Board - Non Network
63H2324	IBM 4317 Fuser Assembly
CB414-67926	HP M3027/3035MFP ADF Assembly - Letter Size
CC395-60102	HP M9040/9050MFP Control Panel Assembly
CE522-67901	HP CM3530MFP/CP3525 500 Sheet Feeder Assembly
CE664-69004	HP CM6030/6040MFP Scanner Assy without Power Supply, Boards, and Cables
CE725-67901	HP CP5525 Tray 4/5/6 3 x 500 Sheet Feeder with Stand
IR4041K512NR	HP 4730/4345/M4345MFP Scanner Control Board
IR4041-SVPCR	HP 4345/M4345MFP Scanner Assembly
Q2486A	HP CLJ 3500/3700 500 Sheet Feeder Assembly
Q3673-69001	HP CLJ 4600/4650 Optional 500 Sheet Feeder
Q3931-67929	HP CP6015 Hard Drive
Q3938-67950	HP CM6030/6040/6049MFP ADF Paper Input Tray Assembly
Q3942-60140	HP LJ 4345MFP Control Panel Assembly
RG5-0381	HP IIIiSi/4Si Job Offset Assembly
RG5-0511	HP 4/4M DC Controller
RH5-3079	HP 9000/9040/9050MFP Sensor PC Board
RM1-0470	HP CLJ 3500/3550/3700 250 Sheet Tray
RM1-1013	HP 4345/M4345MFP Power Supply
RM1-1043	HP 4345/M4345MFP Fusing Assembly
RM1-1862	HP CLJ 2605 Top Cover Assembly - Simplex
RM1-2109	HP CM4730MFP Multipurpose Paper Input Tray Assembly
RM1-2600	HP CLJ 3000 DC Controller Board
RM1-3333	HP CM6040MFP/CP6015 Right Door Assembly
RM1-3559	HP CM6030/6040MFP/CP6015 Intermediate Paper Transfer Unit Driver
RM1-3774	HP M3027/3035MFP Engine Control Board
RM1-4140	HP CM6030/6040MFP/CP6015 Saddle Controller PCA
RM1-4395	HP CM6030/6040/6049MFP Intermediate Upper Feed Guide Assy
RM1-4957	HP CM3530MFP/CP3525 Duplex Right Door Assembly
RM1-5185	HP CLJ 2605 Laser Scanner Assembly
RM1-5250	HP P4014 Top Cover Assembly



www.LaserPros.com

RM1-5449	HP P4014/4015/4515 Right Cover Assembly
RM1-5763	HP CP4025/4525 Low Voltage Power Supply
RM1-6281	HP P3015 Engine Controller PCA
40X0066	Lexmark 4061 T642/644 Pickup Arm Assembly
40X1134	Lexmark 5056 C912/920 Printhead
40X4304	Lexmark 4062 T650 250 Sheet Pick Arm Assembly
40X4375	Lexmark 4062 T650 System Card Assembly
56P3089	Lexmark 4505 E234/332 Controller Card - Network
99A2447	Lexmark 4069 T622 Main Drive Assembly
C8085-60540	HP 9040/9050/9500MFP Latching Mechanism
CC395-67903	HP M9040/9050MFP Formatter Board - Network
CC493-67917	HP CP4025/4525 Registration Assembly Duplex
CC493-69001	HP CP4025/4525 Formatter PC Board
CE710-69001	HP CP5225 Fusing Assembly
CE710-69003	HP CP5225 Intermediate Transfer Belt Assembly
P4015-FDA	HP P4014/4015/4515 Fuser Drive Assembly
Q1314-69003	HP 4100/4101/9000MFP Fax Module
Q3703-69001	HP CLJ 2550LN/2550N Simplex Formatter Board - Network
Q3938-67943	HP CM6030/6040MFP ADF Assembly
Q3938-67982	HP CM6030/6040MFP Formatter Board
RG5-1391	HP 4V Pickup Roller Assembly
RG5-2248	HP 4V Paper Guide Plate Assembly
RG5-4360	HP 8100/8150 Top Cover Assembly
RG5-4811	HP 5000 Laser Scanner Assembly
RG5-5562	HP 2200 Drive Assembly
RG5-6227	HP 9000/9040/9050 Paper Path Connection Assembly
RG5-6228	HP 9000/9040/9050 2000 Sheet Feed Drive Assembly
RG5-6778	HP CLJ 5500/5550 Front Top Cover Assembly
RG5-7882	HP CLJ 9500/9500MFP Print Cartridge Drive Board
RH7-1152	HP 4/4M Main Motor
RM1-0865	HP 3015/3020/3030 Fusing Assembly
RM1-1019	HP 4345/M4345MFP Reversing Separation Guide Assembly
RM1-1047	HP 4345/M4345MFP Delivery Tray Assembly
RM1-1307	HP 1320 Front Cover Assembly
RM1-1740	HP CLJ 4700/CP4005 Tray 1 Assembly
RM1-2492	HP 5200 Face Up Delivery Assembly
RM1-2713	HP CLJ 3000D/3600D/3800D Top Cover Assembly - Duplex
RM1-2962	HP M5025/5035MFP Delivery Drive Assembly



www.LaserPros.com

RM1-2994	HP M5025/5035MFP Low Voltage Power Supply
RM1-3066	HP 3050/3055AIO/M1319 Scanner Guide Assembly
RM1-4191	HP P1505 Paper Pickup Tray Assembly
RM1-4270	HP P2015/M2727NFMFP Rear Cover Assembly - Duplex
RM1-4289	HP P2014 Top Cover Assembly
RM1-5003	HP CP3525 Delivery Assembly - Simplex
RM1-5506	HP CP4025/4525/CM4540MFP Front Door Assembly
RM1-5919	HP CP4025/4525 Paper Pickup Assembly
12G4513	Lexmark 4500 E321/322/323 Tray 2 - White
56P0588	Lexmark 4069 T616 Engine Board
56P0619	Lexmark 4048 T420 RIP Card Assembly - Network
56P0884	Lexmark 4022 W812 Fuser Maintenance Kit
56P1514	Lexmark 5060 C752/760/762 LVPS with Cabling
56P2302	Lexmark 4048 T430 Rear Cover Assembly
56P9974	Lexmark 5055 C912 RIP Board - Network
99A1055	Lexmark 4059 2000 Sheet Arm Assembly
99A1138	Lexmark 4059 1855 Printhead
99A2029	Lexmark 4520 T522 500 Sheet Redrive Assembly
C7130-67902	HP CLJ 5550 500 Sheet Paper Feeder Assembly
C9124-60103	HP 3300/3310/3320/3330MFP Flatbed Scanner Assembly
CB414-67921	HP M3035/3027MFP Flatbed Scanner Assembly - Letter Size
CB437-69001	HP P4014/4515 Formatter Board
CB480-67911	HP CLJ 4730/CM4730MFP Hard Drive
CB534-60112	HP M1522NMFP ADF Input Tray Assembly
CC375-60001	HP P2014 Formatter Board
CC434-60101	HP CM2320MFP Base Model Control Panel
CE664-69005	HP CM6030/6040MFP Scanner Controller Board
Q3931-67909	HP CM6040MFP/CP6015 Registration Assembly
Q5969-67901	HP 4345/M4345MFP Duplexer Assembly
Q7529-60002	HP 3055AIO Simplex Formatter Board - Network
Q7829-67939	HP M5025/5035MFP Automatic Document Feeder
RC1-9344	HP CM6040MFP/CP6015 Left Rear Cover
RG1-4175	HP 4100/4101MFP Power Supply with Veristor Cover
RG5-1396	HP 4V Gear Mounting Assembly
RG5-1870	HP 5Si Top Cover Assembly
RG5-3111	HP CLJ 8500/8550 Transfer Drum Cleaner Holder
RG5-3300	HP CLJ 4500 Top Cover Assembly
RG5-5150	HP CLJ 4500/4550 Top Cover Assembly



www.LaserPros.com

RG5-5646	HP 9000/9040/9050 Left Door Assembly
RH7-1317	HP 4V Fan Above I/O
RH7-1632	HP CLJ 9500 Cooling Fan FM2
RH7-1657	HP 9000/9040/9050 Fan 1
RK2-0472	HP 4345/M4345MFP DC Controller Fan
RL1-1284	HP CM6040MFP/CP6015 Top Cover Assembly
RL1-1335	HP CM6040MFP/CP6015 Upper Duplexer Feed Guide
RM1-0858	HP 3015/3020/3030AIO Paper Pickup Tray Assembly
RM1-0940	HP 4345/M4345MFP Paper Output Tray
RM1-1015	HP 4345MFP Front Cover Assembly
RM1-1022	HP 4345/M4345MFP Reversing Assembly
RM1-1572	HP 4345/M4345MFP Multipurpose Tray Assembly
RM1-2458	HP 5200 Toner Cartridge Door
RM1-2465	HP 5200 MP Tray Assembly
RM1-2490	HP 5200 Face Down Top Output Assembly
RM1-2673	HP CLJ 3000/3600/3800 Front Cover Assembly - Simplex
RM1-2714	HP CLJ 3000D/3600D/3800D Fuser Access Door - Duplex
RM1-2900	HP 5200 Tray 3 500 Sheet Cassette
RM1-2976	HP M5025/5035MFP Upper Cassette Pickup Assembly
RM1-2995	HP M5025/5035MFP Connecting PCA Assembly
RM1-3059	HP M1319/3050/3052/3055 Delivery Tray Assembly
RM1-3419	HP 3050 Scanner Paper Input Tray Assembly
RM1-3459	HP M5025/5035MFP DC Controller Board
RM1-3812	HP CLJ 5550 DC Controller
RM1-4098	HP 5200 DC Controller
RM1-4224	HP P1505 Paper Pickup Assembly
RM1-4977	HP CM3530MFP/CP3525 Waste Toner Duct Assembly
RM1-4986	HP CP3525 Front Door Assembly
RM1-5005	HP CM3530MFP/CP3525 Right Door Assembly - Simplex
RM1-5009	HP CP3525 Registration - Simplex
RM1-5521	HP CP4025/4525/CM4540MFP Main Drive Motor Assembly
RM1-5928	HP CP4025/4525 500 Sheet Paper Input Tray Cassette
RM1-6272	HP P3015 Registration Roller Assembly
RM1-6339	HP CLJ 3000 Laser Scanner Assembly
RM1-6434	HP P2035 Cartridge Access Door
RM1-6642	HP CM6030/6040/6049MFP Controller PC Board Assembly
12G0255	Lexmark 4045 M410/412 Left Cover
12G0256	Lexmark 4045 M410/412 Right Cover



www.LaserPros.com

12G0266	Lexmark 4045 M410/412 Multipurpose Feeder Input Tray
12G2221	Lexmark 4023 W810 Fuser Assembly
40X0030	Lexmark 4061 T642/644 500 Sheet Redrive Assembly
40X4569	Lexmark 4062 T65X/X65X Optional 250 Sheet Tray
56P1053	Lexmark 4500 E220/321/323 Fuser Assembly
56P1191	Lexmark 4520 T520 System Board - Network
56P9700	Lexmark 5055 C910/912/920 Paper Feed Solenoid
56P9973	Lexmark 5055 C912 RIP Board - Non Network
99A0001	Lexmark 4059 1250/16XX/1855/2450 Operator Panel Assembly
C4116A	HP 5000 250 Sheet Universal Tray
CB418-60001	HP P1505N Formatter Board
CC483-67905	HP CM3530MFP ADF Assembly
CC493-67914	HP CP4025/4525/CM4540MFP Laser Scanner Assembly
Q2657-60001	HP 3380AIO Scanner Control Board
Q2658-67901	HP 3380AIO Simplex Formatter Board - Non Network
Q2660-60143	HP 3380AIO Flatbed Scanner Assembly
Q2666-60101	HP 3030AIO Control Panel Assembly
Q6502-60117	HP 3052/3055AIO Scanner Lid with ADF
Q6503-60101	HP 3055AIO Control Panel Assembly
Q7528-60001	HP 3052AIO Simplex Formatter Board - Network
Q7539-69003	HP CP6015N Formatter Board - Network
RB2-5690	HP 9000/9040/9050 Face up Tray
RC1-3035	HP 4345/M4345MFP Formatter Cover
RC1-8223	HP M5025/5035MFP Formatter Board Cover
RC1-8227	HP M5025/5035MFP Upper Left Cover
RC2-5054	HP CP3525 Upper Cover
RG5-5502	HP CLJ 4500/4550 Carousel Drive Assembly
RG5-7639	HP CLJ 2820/2840 250 Sheet Tray
RH7-1623	HP 9040/9050 Controller Board Fan 2
RK2-1097	HP 5200 Control Panel Assembly
RM1-0004	HP 4200/4300 Tray 1 Paper Input Assembly
RM1-0864	HP 3015/3020/3030AIO Paper Pickup Assembly
RM1-0903	HP 3015/3020/3030AIO Power Supply Assembly
RM1-1018	HP 4345/M4345MFP Duplexer Cover
RM1-1687	HP CLJ 4700/CP4005 Tray1/Tray 2 Pickup Drive Assembly
RM1-1760	HP CLJ 4700/CP4005 500 Sheet Feeder Pickup Drive Assembly
RM1-1925	HP CLJ 2600/2605/CM1015MFP 250 Sheet Tray
RM1-2463	HP 5200 Multipurpose Cover Assembly



www.LaserPros.com

RM1-2530	HP 5200 Tray 2 Paper Pickup Assembly
RM1-2538	HP 5200 Fuser Drive Motor Assembly
RM1-2969	HP M5025/5035MFP Lifter Drive Assembly
RM1-2977	HP M5025/5035MFP Lower Cassette Pickup Assembly
RM1-2984	HP M5025/5035MFP Cartridge Door Assembly
RM1-2990	HP M5025/5035MFP Left Door Cartridge Assembly
RM1-2991	HP M5025/M5035MFP Right Door Assembly
RM1-3222	HP CP6015/CM6040MFP Lifter Drive Assembly
RM1-3594	HP CM6040MFP/CP6015 Low Voltage Power Supply
RM1-4404	HP CM6030/6040MFP Internal Front Door Cover Assembly
RM1-4516	HP CP6015 Control Panel
RM1-4975	HP CM3530MFP/CP3525 Paper Pickup Drive Assembly
RM1-5656	HP CP4025/4525 Fuser Drive Assembly
RM1-5758	HP CP4025/4525 DC Controller PCA Assembly
RM1-5786	HP CP4025/4525 Control Panel Assembly
RM1-6279	HP P3015 Tray 2 500 Sheet Paper Tray
RM1-6425	HP P2055 Cartridge Access Door
RM1-6444	HP P2055 Rear Cover Assembly
12G1695	Lexmark 10/100 Base Ethernet Card
12G3552	Lexmark 4045 M412 Main Drive Assembly
40X0017	Lexmark 4061 T640/642/644 Lower Front Cover
40X5928	Lexmark 4061 T644 System Board - Network
56P1089	Lexmark 4500 E321/323 Option Feeder - Black
56P1090	Lexmark 4500 E220/321/323 Tray 2 - Black
56P1328	Lexmark 4060 T632/634 Redrive Assembly
56P4398	Lexmark 4048 T430 Controller Card Assembly
56P9751	Lexmark 5055 C910/912 Fuser Assembly
99A1530	Lexmark 4069 T614 500 Sheet Pickup Assembly
99A2151	Lexmark 4060 T630 250 Sheet Redrive Assembly
C2083D	HP 4/4+ 500 Sheet Lower Cassette
C7868-60001	HP 9000MFP Copy Connect Board
CB358-67901	HP 1160 Simplex Formatter Board - Non Network
CC367-60001	HP CM1312NF/2320NFMFP DAA Fax Card
Q2665-60117	HP 3020 ADF and Flatbed Scanner Lid
Q2668-60001	HP 3015AIO Formatter Board
Q3931-67907	HP CM6040MFP/CP6015 Laser Scanner
Q6502-60116	HP 3052/3055AIO Flatbed Scanner Assembly
Q7509-69001	HP CLJ 9500MFP Formatter Board



www.LaserPros.com

Q7725-67998	HP CLJ 9500MFP 32MB Flash Firmware
RC1-1574	HP CLJ 3500/3550/3700 Tray 1 Cover
RC1-8220	HP M5025/5035MFP Top Cover
RC1-8221	HP M5025/5035MFP Front Cover
RC1-8228	HP M5025/5035MFP Lower Left Cover
RC1-8233	HP M5025/5035MFP Top Cover
RC1-8236	HP M5025/5035MFP Right Grip Cover
RC1-8373	HP 3050/3052/3055AIO/M1319 Left Cover
RC1-9350	HP CP6015/CM6040MFP Front Upper Cover
RC2-5800	HP M1319 Right Cover
RG5-1545	HP 4V Delivery Guide Assembly
RG5-1562	HP 4V Multipurpose Input Tray
RG5-6235	HP 9000/9040/9050 2000 Sheet Feeder Paper Control Board
RG5-6780	HP CLJ 5500/5550 Multipurpose Tray Assembly
RG5-7164	HP 5100 Optional 500 Sheet Tray
RG5-7879	HP CLJ 9500/9500MFP Process Cartridge PC Board
RH5-3078	HP 9000/9040MFP ADF Intermediate Board
RK2-0996	HP CLJ 3000 Control Panel
RK2-1284	HP M5025/5035MFP Rear Fan
RK2-1285	HP M5025/5035MFP Front Fan
RL1-1161	HP 3050/3052/3055AIO/M1319 Scanner Support Frame
RM1-0027	HP 4200/4240/4250/4300/4350 Rear Door Assembly
RM1-0554	HP 1150/1300 Tray Cover
RM1-1100	HP M4345MFP Front Cover Assembly
RM1-1322	HP 1160 250 Sheet Tray 2 Paper Cassette
RM1-2555	HP 5200/M5025/5035MFP Laser Scanner Assembly
RM1-3001	HP 5200/M5025/5035MFP Registration Assembly
RM1-3060	HP 3050/3052/3055 Paper Input Tray
RM1-3293	HP CM6040MFP/CP6015 Face Down Delivery Assembly
RM1-4195	HP P1505 Control Panel
RM1-4415	HP CM6040MFP/CP6015 Right Rear Cover Assembly
RM1-5689	HP CM3530MFP Low Voltage Power Supply PCA
RM1-5695	HP CP3525 Interconnecting PCA
RM1-6446	HP P2035 250 Sheet Paper Tray
12G1846	Lexmark 4044 E310 Front Cover Assembly
12G4034	Lexmark 4025 W820 Exit Assembly High Paper Retard
12G6357	Lexmark 5060 C750 Front Access Door Assembly
56P0601	Lexmark 4048 T420 Front Cover Display



www.LaserPros.com

56P0683	Lexmark 4500 E321/323 Control Panel - White
56P1065	Lexmark 4500 E323 Front Cover Assembly
56P1074	Lexmark 4500 E323 Controller Card - Network
56P2303	Lexmark 4048 T430 MPF Front Door Assembly
56P4100	Lexmark 4061 T640 250 Sheet Duplex Assembly
56P9566	Lexmark 5055 C910/912 Face Down Guide Assembly
5851-2462	HP 9040/9050/9500MFP Control Panel Assembly
99A1586	Lexmark 4069 T610 Inner Redrive Assembly
C8541-69001	HP 4100/4101 Copy Processor Board
CC436-67901	HP CM2320NFMFP Auto Document Feeder Assembly - Duplex
CC454-60003	HP CM3530MFP Scanner Controller Board
J4106A	HP Jet Direct Card - 400N 10 Base T
Q1891-67901	HP CLJ 9500MFP 2000 Sheet High Capacity Input Tray
Q3701-60020	HP 4345/M4345/4730/9500MFP Modem PCA (Q3701-60010)
Q3938-67963	HP CM6030/6040/6049MFP Control Panel Assembly
R96-5062	HP CLJ 4730MFP 2x500 Sheet Optional Feeder Assembly
RC1-9351	HP CM6040MFP Paper Delivery Cover
RC2-8280	HP P2035 Right Cover
RG5-5135	HP CLJ 4500/4550 Face Down Delivery Assembly
RG5-6207	HP 9000/9040/9050/9500 Paper Size Sensing Board
RG5-6229	HP 9000/9040/9050/9500 Tray 4 Paper Volume Sensing Assembly
RG5-7700	HP CLJ 5550 Drive Assembly
RG5-7732	HP CLJ 5550 Rear Top Cover Assembly
RH5-3122	HP CLJ 9500MFP Scanner Control Board
RM1-0464	HP CLJ 3500/3550/3700 Multipurpose Tray Assembly
RM1-2219	HP CLJ 4730 500 Sheet Paper Tray
RM1-2750	HP CLJ 3000/3600/3800 Paper Output Tray
RM1-2978	HP M5025/5035MFP 250 Sheet Tray 2 Assembly
RM1-3218	HP CM6040MFP/CP6015 Fuser Power Supply Assembly
RM1-3286	HP CP6015 Drum Motor
RM1-3345	HP CM6040MFP/CP6015 Tray 1 Paper Pickup Assembly
RM1-3356	HP CP6015 Front Door Assembly
RM1-5448	HP P4014 Face Up Output Tray Assembly
RM1-5928	HP CP4025/4525 500 Sheet Paper Input Tray Cassette
RM1-6394	HP P2055 250 Sheet Tray