

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).

service



i n v e n t

A large, white HP LaserJet printer with a scanner/ADF (Automatic Document Feeder) on top. The scanner lid is open, and the printer is positioned in an office setting with windows in the background.

Scanner/ADF for the  
**hp** LaserJet  
9000mfp/9000Lmfp/9040mfp/9050mfp  
and  
**hp** color LaserJet 9500mfp



# Scanner/ADF service manual for the HP LaserJet 9000mfp/9000Lmfp/9040mfp/ 9050mfp/9500mfp

## **service** ---

This manual is used in conjunction with the  
*HP LaserJet 9000 and 9050 Printer Service Manual*, and the  
*HP Color LaserJet 9500/9500mfp Print Engine Service Manual*.

© 2004 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

Part number: C8549-90955

Edition 1, 9/2004

The information contained in this document is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

## Trademark Credits

Adobe® and PostScript® are trademarks of Adobe Systems Incorporated.

Microsoft®, MS-DOS®, and Windows® are U.S. registered trademarks of Microsoft Corporation.

TrueType™ is a U.S. trademark of Apple Computer, Inc.

UNIX® is a registered trademark of The Open Group.

Energy Star® is a U.S. registered service mark of the United States Environmental Protection Agency.



# Table of contents

## List of tables

## List of figures

### 1

#### MFP requirements

Space requirements HP LJ 9000mfp/9000Lmfp/9040mfp/9050mfp	18
Space requirements HP LJ 9500mfp	20

### 2

#### MFP information

MFP specifications	22
MFP features	22
Identification	22
Specifications	23
Interface connections	26
Regulatory information	28
Service approach	28
Parts and supplies	28
Warranty	28
Limited warranty for the print cartridge	28
Service and support	29

### 3

#### MFP configuration

Control panel	32
Control panel layout HP LJ 9000mfp/9000Lmfp	32
Touch-screen graphical display layout HP LJ 9000mfp/9000Lmfp	33
Control panel layout HP LJ 9040mfp/9050mfp/9500mfp	34
Touch-screen display layout HP LJ 9040mfp/9050mfp/9500mfp	35
Settings and defaults	36
Setting the display language	36
Setting tray registration	36
E-mail settings	38
FAX settings (HP LaserJet 9040mfp/9050mfp/9500mfp)	39
Color copy settings (HP LaserJet 9500mfp)	40
Control panel menus (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp)	41
Menu map (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp)	41
Using a menu map (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp)	41
Retrieve job menu (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp)	42
If you select PRINT, the printer prompts you to specify the number of copies to print (1 to 32,000)	42
Information menu (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp)	42
Paper handling menu (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp)	43
Configure device menu (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp)	45
Printing submenu (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp)	45
PCL submenu	47

Print-quality submenu (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp) . . . . .	48
System setup submenu (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp) . . . . .	50
I/O submenu (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp) . . . . .	52
EIO X Jetdirect submenu (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp) . . . . .	53
Resets submenu (LJ 9000mfp/9000Lmfp/9040mfp/9050mfp) . . . . .	57
Diagnostics menu (HP LJ 9000mfp/9000Lmfp/9040mfp/9050mfp) . . . . .	58
Service menu (HP LJ 9000mfp/9000Lmfp/9040mfp/9050mfp) . . . . .	58
Control panel menus (HP CLJ 9500mfp) . . . . .	59
Menu map (CLJ 9500mfp) . . . . .	59
Using a menu map (CLJ 9500mfp) . . . . .	59
Retrieve job menu (CLJ 9500mfp) . . . . .	60
Information menu (CLJ 9500mfp) . . . . .	61
Paper handling menu (CLJ 9500mfp) . . . . .	62
Configure device menu (CLJ 9500mfp) . . . . .	64
Printing submenu (CLJ 9500mfp) . . . . .	68
PCL submenu (CLJ 9500mfp) . . . . .	70
Print quality submenu (CLJ 9500mfp) . . . . .	72
System setup submenu (CLJ 9500mfp) . . . . .	74
I/O submenu (CLJ 9500mfp) . . . . .	77
Resets submenu (CLJ 9500mfp) . . . . .	81
Diagnostics menu (CLJ 9500mfp) . . . . .	82
Service menu (CLJ 9500mfp) . . . . .	85
Installing firmware updates . . . . .	87
Downloading the new firmware to the MFP . . . . .	87
Remote firmware update through a local Windows port . . . . .	88
Remote firmware update through a Windows network . . . . .	89
Remote firmware update for UNIX systems . . . . .	89
Remote firmware update by using FTP on a direct network connection . . . . .	90
Remote firmware update by using FTP through a browser . . . . .	91
Remote firmware update using the HP LaserJet utility (Mac OS 8.6 and 9.x only) . . . . .	92
Remote firmware update using the LPR command . . . . .	93
Using HP Web Jetadmin to download the firmware to the MFP . . . . .	93
MFP messages during firmware update . . . . .	94
Troubleshooting a firmware update . . . . .	95

## 4 MFP maintenance

Cleaning the MFP and accessories . . . . .	98
General cleaning . . . . .	98
ADF cleaning . . . . .	99
Glass cleaning . . . . .	105

## 5 Theory of operation

Differences in MFPs . . . . .	108
Mechanical structure . . . . .	110
Motors and fans . . . . .	112
Basic block diagram . . . . .	114
Basic system configuration . . . . .	115
Scanner unit systems . . . . .	115
Scan mode . . . . .	116
Power supply assembly . . . . .	117
PowerSave (sleep) mode (HP LJ 9000mfp/9000Lmfp) . . . . .	119
Sleep mode (HP LJ 9040mfp/9050mfp/9500mfp) . . . . .	120
Low-voltage power supply circuit . . . . .	122
Scanner controller circuit . . . . .	124

Flatbed operation . . . . .	125
Flatbed document exposure control . . . . .	125
Flatbed optical drive control . . . . .	126
Flatbed optical unit operation . . . . .	127
Flatbed document size detection . . . . .	128
ADF operation . . . . .	131
ADF document exposure control . . . . .	131
ADF document feed control . . . . .	132
ADF document size detection . . . . .	134
ADF feeder sensors . . . . .	135
ADF document skew detection . . . . .	136
Scanned data flow . . . . .	137
Copy processor . . . . .	138
Scanning process control signals . . . . .	139
Typical scanning process flow . . . . .	139
Copy processor LEDs (HP LJ 9000mfp/9000Lmfp) . . . . .	140
Copy processor LEDs (HP LJ 9040mfp/9050mfp/9500mfp) . . . . .	142

## 6 Removal and replacement

Introduction . . . . .	147
Removal and replacement strategy . . . . .	147
Electrostatic discharge . . . . .	147
Required tools . . . . .	147
External covers . . . . .	148
Control panel (HP LJ 9000mfp/9000Lmfp) . . . . .	148
Control panel (HP LJ 9040mfp/9050mfp/9500mfp) . . . . .	150
ADF feeder cover . . . . .	151
ADF feeder cover handle . . . . .	153
ADF back cover . . . . .	154
ADF front cover . . . . .	155
Lower delivery roller cover . . . . .	156
White board cover . . . . .	157
Copy processor/connect board . . . . .	158
Flatbed rail cover . . . . .	159
Flatbed back cover . . . . .	160
Flatbed right cover . . . . .	161
Flatbed left cover . . . . .	162
Flatbed upper front cover . . . . .	163
Flatbed lower front cover . . . . .	164
ADF base cover assembly . . . . .	165
Glass . . . . .	170
Internal . . . . .	172
ADF main assembly . . . . .	172
ADF optical assembly . . . . .	177
ADF scanning lamp (HP LJ 9000mfp/9000Lmfp) . . . . .	184
ADF shading filter . . . . .	187
Flatbed optical unit . . . . .	188
Flatbed scanning lamp (HP LJ 9000mfp/9000Lmfp) . . . . .	191
Switch and solenoids . . . . .	193
ADF feeder cover detection switch . . . . .	193
Weight solenoid . . . . .	194
Shutter solenoid . . . . .	195

Motors and fans . . . . .	196
Pickup motor . . . . .	196
Delivery motor . . . . .	198
Flatbed motor . . . . .	200
Power supply assembly . . . . .	202
ADF fan assembly . . . . .	205
Flatbed fan assembly . . . . .	206
PCB assemblies . . . . .	207
ADF analog processor PCB (HP LJ 9000mfp/9000Lmfp only) . . . . .	207
ADF inverter PCB (HP LJ 9000mfp/9000Lmfp only) . . . . .	208
ADF intermediate PCB . . . . .	209
ADF width detection sensor assembly . . . . .	210
Flatbed inverter PCB (HP LJ 9000mfp/9000Lmfp only) . . . . .	211
Flatbed intermediate PCB) . . . . .	212
Scanner controller board . . . . .	214
Intermediate PCB assembly . . . . .	217
Power supply assembly . . . . .	219
Rollers and belts . . . . .	222
Pickup roller (D-roller) . . . . .	222
Pickup roller assembly . . . . .	223
Feed roller assembly . . . . .	224
Lower registration roller assembly . . . . .	225
Lower delivery roller . . . . .	231
Upper delivery roller assembly . . . . .	232
Separation belt assembly . . . . .	233
Separation belts . . . . .	236
Scan engine . . . . .	238

## 7 Troubleshooting

Troubleshooting process . . . . .	245
Preliminary operating checks . . . . .	246
Power on . . . . .	247
Power-on defects . . . . .	247
Malfunction troubleshooting . . . . .	248
Troubleshooting with control panel messages . . . . .	249
Control panel display . . . . .	249
Event log page . . . . .	249
Control panel messages . . . . .	252
MFP message tables . . . . .	253
Alphabetic error messages . . . . .	253
Numeric error messages . . . . .	255
Troubleshooting with the copy processor . . . . .	260
HP LJ 9000mfp/9000Lmfp . . . . .	260
HP LJ 9040mfp/9050mfp/9500mfp . . . . .	262
User- and service-level diagnostics . . . . .	264
Diagnostics . . . . .	264
Service test (HP LJ 9000mfp/9000Lmfp/9040mfp/9050mfp) . . . . .	265
Service-level diagnostics . . . . .	266
Service menu . . . . .	266
Calibrations . . . . .	268
Control-panel touch screen calibration (HP LJ 9000mfp/9000Lmfp) . . . . .	268
Control-panel touch screen calibration (HP LJ 9040mfp/9050mfp/9500mfp) . . . . .	270
Scanner/ADF calibration simplified . . . . .	271
ADF calibrations . . . . .	274
Glass calibrations . . . . .	282

Measurement and adjustment . . . . .	287
ADF unit height adjustment . . . . .	287
ADF skew adjustment . . . . .	289
ADF width sensor adjustment . . . . .	291
Weight solenoid stroke adjustment . . . . .	292
Jam troubleshooting . . . . .	293
Jams . . . . .	293
Evaluating the information pages . . . . .	295
Configuration page . . . . .	295
Jetdirect page . . . . .	297
Supplies status page . . . . .	298
Usage page . . . . .	299
File directory page . . . . .	300
Image-formation troubleshooting . . . . .	301
Copy-image defects . . . . .	302
Scanner controller PCB . . . . .	309
Connector locations . . . . .	310
Electrical structure . . . . .	311
Wiring diagrams . . . . .	312

## 8 Parts and diagrams

Introduction . . . . .	316
Ordering parts . . . . .	316
Consumables (HP LJ 9000mfp/9000Lmfp9040mfp/9050mfp) . . . . .	317
Consumables (HP CLJ 9500mfp) . . . . .	322
Common hardware . . . . .	326
Illustrations and parts lists . . . . .	327
MFP system assembly . . . . .	328
External panels and covers . . . . .	329
Flatbed scanner assembly . . . . .	332
Flatbed optical assembly . . . . .	337
ADF scanner assembly . . . . .	339
Paper pickup assembly . . . . .	342
ADF main assembly . . . . .	347
ADF optical assembly . . . . .	350
PCB assemblies . . . . .	352
Alphabetical parts list . . . . .	353
Numerical parts list . . . . .	358

## Index

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).

