


For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).



**hp** color LaserJet  
2550 printer

**service**



hp color LaserJet 2550 series printer

**Service Manual** \_\_\_\_\_

## Copyright information

© 2004 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number Q3702-90923

Edition 1, 5/2004

## Safety information

### WARNING!

#### Potential Shock Hazard

Always follow basic safety precautions when using this product to reduce risk of injury from fire or electric shock.

Read and understand all instructions in the user guide.

Observe all warnings and instructions marked on the product.

Use only a grounded electrical outlet when connecting the printer to a power source. If you do not know whether the outlet is grounded, check with a qualified electrician.

Do not touch the contacts on the end of any of the sockets on the printer. Replace damaged cords immediately.

Unplug this product from wall outlets before cleaning.

Do not install or use this product near water or when you are wet.

Install the product securely on a stable surface.

Install the product in a protected location where no one can step on or trip over the power cord and where the power cord will not be damaged.

If the product does not operate normally, see the online user guide.

Refer all servicing questions to qualified personnel.

Information regarding FCC Class B, Parts 15 and 68 requirements can be found in the user guide.

## Trademark credits

Adobe®, Acrobat®, Adobe® PostScript® 3™, and the Acrobat Logo® are trademarks of Adobe Systems Incorporated.

Microsoft®, Windows®, and Windows NT® are U.S. registered trademarks of Microsoft Corporation.

UNIX® is a registered trademark of The Open Group.

Energy Star® and the Energy Star logo® are U.S. registered marks of the United States Environmental Protection Agency.



# Table of contents

## 1 Product information

Chapter contents .....	1
Printer configurations .....	2
HP color LaserJet 2550L .....	2
HP color LaserJet 2550Ln .....	2
HP color LaserJet 2550n .....	3
Printer features .....	4
Printer overview.....	7
Hardware components.....	7
Model and serial numbers .....	7
Software components .....	9
Software and supported operating systems .....	9
Software tips .....	10
Software for Windows .....	11
Software for Macintosh .....	12
Uninstalling the printing software .....	13
Specifications .....	15
Media specifications .....	17
Supported media weights and sizes .....	17
General guidelines .....	18
Paper and print media .....	19
Printing and storage environment .....	19
Envelopes .....	20
Labels .....	21
Transparencies .....	22
Hewlett-Packard limited warranty statement .....	23
Limited warranty for the print cartridges and imaging drum .....	24
Print cartridge information .....	25
Refilled print cartridges .....	25
HP LaserJet printing supplies .....	25
HP Printing Supplies Returns and Recycling Program information.....	25
Regulatory statements .....	27
Safety statements .....	28
Laser safety statement .....	28
Canadian DOC statement .....	28
Korean EMI statement .....	28
Finnish laser statement .....	29

## 2 Installation and operation

Chapter contents .....	31
Operating environment .....	32
Interface ports .....	33
Control panel features .....	34
Understanding Supplies Status .....	34
Understanding Printer Status .....	35

Input trays .....	37
Printer output paths .....	38
Top output bin .....	38
Rear output door .....	38
Loading media .....	39
Loading tray 1 .....	39
Loading optional tray 2 .....	40
Loading optional tray 3 .....	42
HP LaserJet Toolbox .....	44
Supported operating systems .....	44
Supported browsers .....	44
Viewing the HP LaserJet Toolbox .....	45
Status tab .....	45
Troubleshooting tab .....	45
Alerts tab .....	46
Documentation tab .....	46
Device Settings window .....	47
Other links .....	48

### 3 Maintenance

Chapter contents .....	49
Life expectancies of supplies .....	50
User-replaceable parts .....	52
Replacing the tray 1 pickup roller and separation pad .....	52
Replacing the separation pad in optional tray 2 or in optional tray 3 .....	57
Cleaning the printer .....	61
Cleaning the printer .....	61
Calibrating the printer .....	63
To calibrate the printer at the printer .....	63
To calibrate the printer from the HP LaserJet Toolbox .....	63
Managing supplies .....	64
Supplies life .....	64
Checking and ordering supplies .....	64
Storing supplies .....	65
Replacing and recycling supplies .....	65
HP policy for non-HP supplies .....	66
HP fraud hotline .....	66

### 4 Theory of operation

Chapter contents .....	67
Introduction .....	68
Engine control system .....	70
Basic sequence of operation .....	70
Power-on sequence .....	72
Motors and fans .....	73
Laser/scanner system .....	74
Pickup and feed system .....	75
Paper trays .....	76
Jam detection .....	77
Photosensors and switches .....	78
Solenoid and clutches .....	80
Printed circuit assemblies .....	82
Image-formation system .....	84
Image-formation process .....	85
Latent-image-formation stage .....	85

Developing stage .....	86
Transfer stage .....	87
Fusing stage .....	89
Print cartridge .....	93
Imaging-drum E-label .....	94

## 5 Removal and replacement

Chapter contents .....	97
Introduction .....	99
Removal and replacement strategy .....	99
Electrostatic discharge .....	99
User-replaceable parts .....	99
Required tools .....	99
Before performing service .....	101
Pre-service procedures .....	101
Parts removal order .....	102
Removal and replacement .....	103
Imaging drum .....	103
Print cartridges .....	103
Fuser cover (and fuser) .....	104
Right- and left-side covers .....	106
Control panel .....	107
On-off switch .....	109
Interface cover .....	110
Formatter assemblies .....	111
Fuser motor .....	116
Dc controller .....	117
Optional tray 2 (250-sheet tray) .....	118
Carousel-engagement motor .....	120
Front lower cover .....	121
Back cover .....	122
Top cover .....	123
Top door .....	125
Air duct and fan .....	127
Laser/scanner assembly .....	128
Front cover .....	130
Density sensor and top-of-page sensor .....	130
E-label reader (for imaging-drum E-labels) .....	132
Tray 1 (multipurpose tray) .....	133
Tray 1 separation pad assembly .....	135
Gear assembly .....	136
Waste-toner sensor .....	138
Rotary-drive assembly .....	139
Top plate .....	142
Print-cartridge carousel .....	145
Aligning the carousel gears .....	149
Registration-roller assembly .....	150
Toner-catch tray .....	151
Transfer-roller plate .....	152
Transfer roller .....	152
Feed-drive shaft .....	153
ECU pan .....	154
Sub-high-voltage transformer PCA .....	157
High-voltage transformer PCA .....	158
Low-voltage PCA .....	159

Paper-top sensor .....	160
Fuser-wrap sensor .....	161
250-sheet feeder pickup roller .....	162
500-sheet feeder pickup roller .....	163

## 6 Troubleshooting

Chapter contents.....	167
Basic troubleshooting .....	169
Clearing jams .....	171
Where to look for jams .....	171
To clear jams from inside the printer .....	171
To clear jams from input areas .....	172
To clear jams from output areas .....	174
Control panel light messages .....	176
Supplies Status lights .....	177
Printer Status lights .....	182
Solving image-quality problems .....	190
Print-quality checklist .....	190
Solving image-quality problems (all print jobs) .....	190
Solving image-quality problems (color print jobs) .....	200
Resolving problems that generated messages .....	204
Messages for both Windows and Macintosh .....	204
Messages for Windows only .....	204
Resolving problems that did not generate messages .....	206
Troubleshooting checklist .....	206
Checking the network .....	207
Solving general printing problems .....	207
Solving PostScript (PS) errors .....	212
Solving common Macintosh problems .....	213
Manually rotating the print-cartridge carousel .....	216
Functional checks .....	218
Engine test .....	218
High-voltage power-supply check .....	219
Paper-path check .....	219
Service mode functions .....	221
Cold reset .....	221
NVRAM initializer .....	221
Error report.....	222
Super NVRAM initialization.....	222
Network card cold reset.....	222
Using PJI commands .....	223
Troubleshooting tools .....	225
Demo page .....	225
Configuration page .....	225
Supplies Status page .....	226
Repetitive image defects .....	227
General timing charts .....	228
Locations of connectors .....	230
Dc controller connections .....	233
Main wiring diagram .....	234
HP LaserJet Toolbox .....	236
To view the HP LaserJet Toolbox .....	236

## 7 Parts and diagrams

Chapter contents .....	237
------------------------	-----

Ordering parts and supplies .....	238
Parts .....	238
Related documentation and software .....	238
Supplies .....	238
Accessories .....	239
Assembly locations (1 of 2).....	241
Assembly locations (2 of 2).....	242
Covers.....	244
Internal assemblies.....	246
PCA assemblies.....	268
Alphabetical parts list.....	270
Numerical parts list.....	278

## Index

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).