

HP Color LaserJet 4700/CP4005 Series Service Manual

For the complete PDF manual
please visit www.LaserPros.com.



HP Color LaserJet 4700/CP4005 Series printers

Service Manual



Copyright

© 2006 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

CB503-90929

Edition 1, 10/2006

FCC Class A Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense. The end user of this product should be aware that any changes or modifications made to this equipment without the approval of Hewlett-Packard could result in the product not meeting the Class A limits, in which case the FCC could void the user's authority to operate the equipment.

Trademark Credits

Adobe®, Adobe Photoshop® and PostScript® are trademarks of Adobe Systems Incorporated.

Bluetooth is a trademark owned by its proprietor and used by Hewlett-Packard Company under license.

CorelDRAW™ is a trademark or registered trademark of Corel Corporation or Corel Corporation Limited.

Linux is a U.S. registered trademark of Linus Trovalds.

Microsoft®, Windows®, and Windows XP® are U.S. registered trademarks of Microsoft Corporation.

PANTONE®* *Pantone, Inc's check-standard trademark for color.

UNIX® is a registered trademark of the Open Group.

ENERGY STAR® and the ENERGY STAR logo® are U.S. registered marks of the United States Environmental Protection Agency.

Safety Information

WARNING!

Potential Shock Hazard

Always follow basic safety precautions when using this product to reduce the risk of injury from fire or electric shock.

Table of contents

1 Product information

Printer configurations	2
HP Color LaserJet 4700 (Q7491A)	2
HP Color LaserJet 4700n (Q7492A)	3
HP Color LaserJet 4700dn (Q7493A)	3
HP Color LaserJet 4700dtn (Q7494A)	3
HP Color LaserJet 4700ph+ (Q7495A)	4
HP Color LaserJet CP4005n (CB503A)	4
HP Color LaserJet CP4005dn (CB504A)	5
Printer features	6
Printer walkaround	11
HP Color LaserJet 4700 models	11
HP Color LaserJet CP4005 models	12
Identification, site requirements, and specifications	15
Model and serial numbers	15
Power and regulatory label	15
Site requirements	16
Space requirements	17
Physical specifications	18
Electrical specifications	18
Environmental specifications	19
Acoustic emissions	19
Supply storage requirements	20
Skew specifications	20
Media specifications	21
Printing and paper storage environment	21
Envelopes	22
Envelopes that have double side seams	23
Envelopes that have adhesive strips or flaps	23
Envelope margins	23
Envelope storage	23
Labels	24
Label construction	24
Transparencies	24
Supported types and sizes of print media	25
Media to avoid	29
Media that can damage the printer	29
Printing on special media	31
Transparencies	31
Glossy paper	31

Colored paper	32
Envelopes	32
Labels	32
Heavy paper	33
HP LaserJet Tough paper	33
Preprinted forms and letterhead	33
Recycled paper	34
Weight equivalence table	34
Environmental product stewardship program	36
Protecting the environment	36
Ozone production	36
Power consumption	36
Toner consumption	36
Paper use	36
Plastics	36
HP LaserJet print supplies	36
Return and recycling instructions	37
United States and Puerto Rico	37
Multiple returns (two to eight cartridges)	37
Single returns	37
Shipping	37
Non-US returns	37
Paper	37
Material restrictions	38
Disposal of waste equipment by users in private households in the European Union	38
Material Safety Data Sheet (MSDS)	39
For more information	39
Hewlett-Packard Limited Warranty Statement	40
Limited warranty for print cartridges and image drums	42
Color LaserJet Image Fuser Kit and Image Transfer Kit Limited Warranty Statement	43
Country/region-specific safety statements	44
Laser safety	44
Canadian DOC regulations	44
VCCI statement (Japan)	44
Power cord statement (Japan)	44
EMI statement (Korea)	44
EMI statement (Taiwan)	45
Finnish laser statement	46
Australia	46

2 Service approach

Service approach	50
Parts and supplies	51
Ordering parts, supplies, and accessories over the Internet	51
Ordering directly through the embedded Web server (for printers with network connections)	51
Exchange program	51
Supplies	51
World Wide Web	51
HP Service Parts Information	52

HP available services	53
Ordering related documentation and software	55

3 Installation and configuration

What ships in the box	58
Unpacking the printer	59
Loading detectable standard-sized media into Tray 2 and optional trays	64
Connecting power	66
Installing a new control panel label	67
Testing the printer operation	68
Sleep delay	69
Setting sleep delay	69
Disabling/enabling sleep mode	69
Connecting to a computer	70
Parallel configuration	70
USB configuration	70
Auxiliary connection configuration	71
HP Jetdirect print servers	72
Available software solutions	73
Wireless printing	73
IEEE 802.11 standard	73
Bluetooth	73
Printer software	74
Software	74
Software features	74
Driver Autoconfiguration	74
Update Now	74
HP Driver Preconfiguration	75
Installing the printing system software	75
Installing Windows printing system software for direct connections	75
Installing Windows printing system software for networks	76
Setting up a Windows computer to use the network printer with Windows-sharing	77
Installing the software after the parallel or USB cable has been connected	77
Uninstalling the software	78
Removing software from Windows operating systems	78
Software for networks	78
HP Web Jetadmin	78
UNIX	79
Utilities	79
Embedded Web server	79
Features	79
Other components and utilities	80
Printer drivers	81
Supported printer drivers	81
Additional drivers	81
Select the correct printer driver	82
Printer-driver Help (Windows)	82
Gaining access to the printer drivers	82
Printer drivers for Macintosh computers	84

Supported printer drivers	84
Gaining access to the printer drivers	84
Software for Macintosh computers	86
Installing Macintosh printing system software for networks	86
Installing Macintosh printing system software for direct connections (USB)	87
To remove software from Macintosh operating systems	88
Network configuration	89
Configuring TCP/IP parameters	89
Manually configuring TCP/IP parameters from the printer control panel	89
Setting an IP address	89
Setting the subnet mask	90
Setting the default gateway	91
Disabling network protocols (optional) (HP Color LaserJet 4700 Series only)	91
Disabling IPX/SPX	92
Disabling DLC/LLC	92
Disabling AppleTalk	93
Setting network security on the printer	94
Locking the control panel	94
Levels of security	94
Using an ASCII PJI escape sequence to set network security	94

4 Maintenance

Cleaning the printer and accessories	98
Cleaning spilled toner	98
Vacuum specifications	98
Performing preventive maintenance	99
Managing the print cartridge	100
HP print cartridges	100
Non-HP print cartridges	100
Print cartridge authentication	100
Print cartridge storage	100
Print cartridge life expectancy	100
Checking the supply level	101
Using the control panel	101
Using the embedded Web server	101
Using HP Web Jetadmin	101
Approximate replacement intervals for supplies	102
ETB life	103
Changing print cartridges	104
Replacing a print cartridge	104
To replace the print cartridge	104
Replacing supplies	107
Locating supplies	107
Supply replacement guidelines	107
Making room around the printer for replacing supplies	108
Replacing the stapler cartridge (HP Color LaserJet 4700 Series)	108
Replacing the ETB	111
Replacing the fuser	111
Printer memory and fonts	113

Installing a hard drive, memory, and fonts	114
Installing a hard drive (HP Color LaserJet 4700 Series)	114
Installing DDR memory DIMMs	117
Installing a flash memory card (HP Color LaserJet 4700 Series only)	121
Enabling memory	125
To enable memory for Windows 98 and Me	125
To enable memory for Windows 2000 and XP	125
Installing an HP Jetdirect print server card (HP Color LaserJet 4700 Series only)	126
To install an HP Jetdirect print server card	126
Setting the real-time clock	130
Setting the date and time	130
To set the date format	130
To set the date	130
To set the time format	131
To set the time	131
Setting the wake time	132
To set the wake time	132
Setting the sleep delay	133
To set the sleep delay	133

5 Theory of operation

Basic operation	136
Operation sequence	136
Power on sequence	137
Internal components	139
Formatter system	141
Sleep mode	141
Image Resolution Enhancement technology (REt)	142
Input/Output	142
Parallel interface (HP Color LaserJet 4700 Series only)	142
USB 2.0 connector	142
ACC accessory port (HP Color LaserJet 4700 Series only)	142
Flash (HP Color LaserJet 4700 Series only)	143
Hard drive accessory (HP Color LaserJet 4700 Series only)	143
CPU	143
Printer memory	143
Read-only memory	143
Random-access memory	143
DIMM slots	143
Flash memory	143
Nonvolatile memory	143
PJL overview	144
PML	144
Control panel	144
Engine control system	145
DC controller PCB	145
Block operation	147
Motors, fans, and environment sensor	147
Failure detection	149
Drum motor failure detection	149

Fuser motor failure detection	150
ETB motor failure detection	150
Upper exhaust fan failure detection	150
Cartridge fan failure detection	150
Delivery fan failure detection	150
Power supply fan failure detection	150
Duplexer fan failure detection	151
Low-voltage power supply	151
Fuser control circuit	151
Low-voltage power supply circuit	153
Protective functions	154
Safety	155
Sleep mode	155
Power supply recognition	155
Heater temperature control	155
Initial rotation temperature control	156
Start-up temperature control	156
Print temperature control	157
Between-sheets temperature control	157
Temperature protective function	157
Protective function by the CPU	157
Protective function by the fuser heater safety circuit	157
Protective function by the thermoswitch	158
Temperature failure detection	158
Start-up failure (warmup failure)	158
Abnormal low temperature of main thermistor (no conduction)	158
Abnormal high temperature of main thermistor	158
Abnormal low temperature of sub thermistor (no conduction)	159
Abnormal high temperature of sub thermistor	159
Drive circuit abnormality	159
High-voltage power supply	159
Generation of biases	160
Video interface control	162
Laser/scanner system	163
Laser control	164
Scanner control	165
Image formation system	167
Image formation process	169
Electrostatic latent image formation block	171
Step 1: Pre-exposure	171
Step 2: Primary charging	172
Step 3: Laser beam exposure	172
Development block	172
Step 4: Development	172
Transfer block	173
Step 5: Attraction	173
Step 6: Transfer	173
Step 7: Separation	174
Fusing block	174
Step 8: Fusing	174

Cleaning block	175
Step 9: Drum cleaning	175
Print cartridges	175
Memory tag	177
Cartridge presence detection	177
Memory tag detection	177
Photosensitive drum detection	177
Developing cylinder disengaging control	178
ETB (electrostatic transfer/transport belt)	178
Transfer roller (Y, C, M) engagement/disengagement detection	180
Transfer roller engagement/disengagement control	180
Calibration and cleaning	181
ETB cleaning	182
Color misregistration corrective control	183
Color misregistration detection	184
Image stabilization control	185
Environmental change control	186
Conditions leading up to DHALF	187
Image halftone calibration control (DHALF)	187
Image density detection	187
Pickup/feed system	189
Pickup/feed unit	194
Paper tray detection and paper tray media size detection	194
Paper tray pickup operation	195
Media lift-up operation	196
Initial lift-up	196
Lift-up during printing	196
Multiple-feed prevention	197
Skew correction	199
Media detection	200
Feed speed control	201
Fusing and delivery block	202
Loop control	202
Fusing pressure release mechanism	203
Jam detection	204
Pickup delay jam	205
Pickup stationary jam	205
Delivery delay jam	205
Door open jam	205
Residual paper jam	205
Reversing unit jam 1	205
Reversing unit jam 2	206
Duplexing pickup unit jam 1	206
Automatic delivery function	206
Duplex feed unit	206
Reversing/duplexing feed operation	207
Jam detection	209
Reversing unit jam 1	210
Reversing unit jam 2	210
Duplexing pickup unit jam 1 (Duplexing unit stationary jam)	210

500-sheet paper feeder	211
Pickup and feed operations	212
Stapler/stacker (HP Color LaserJet 4700 Series only)	214
Staple mode	214
Stacker mode	214
Offset mode	214
Messages	215

6 Removal and replacement

Removal and replacement strategy	218
Repair notices	218
Caution regarding electrostatic discharge (ESD)	218
Required tools	218
Types of screws	219
Parts-removal tree	220
User-replaceable parts	221
Print cartridges and ETB	222
Fuser	222
Tray 1 pickup roller and separation pad	222
Tray 2-x separation roller	225
Tray 2-x feed and pickup rollers	226
Formatter	227
Compact flash	228
HP Jetdirect print server card (4700 models)	228
DDR memory DIMMs	228
Hard drive (4700 models)	228
Installing a new control panel label	228
Covers and external components	230
Paper tray (Tray 2)	231
Multipurpose tray (Tray 1)	231
Front cover	235
Duplex cover	239
Face down tray assembly	239
Top cover	240
Right cover	245
Left cover	247
Rear cover	249
Control panel	250
Main assemblies	253
Disengaging drive assembly	254
Remove main drive assembly	256
Reinstall main drive assembly	263
Pickup motor assembly	273
Lifter drive assembly	275
Delivery assembly	278
Paper feed assembly	283
Fuser drive assembly	286
Laser/scanner assembly	287
Motors and fans	297
Disengaging drive motor	298

Drum drive motors (Y/C/M/K)	298
Power supply fan/shroud (Fan 4)	299
Delivery fan/shroud (Fan 3)	300
Cartridge fan/shroud (Fan 2)	302
Upper exhaust fan (Fan 1)	305
Sensors and switches	308
Environment sensor	308
Power switch assembly	309
PCBs	312
DC controller PCB	312
Low-voltage power supply PCB	319
Memory controller PCB	321
E label memory contacts and cable	322
High-voltage power supply PCB	324
Toner level detection PCB	326
High-voltage contacts	326
500-sheet paper feeder	328
500-sheet paper feeder right cover	329
500-sheet paper feeder rear cover	329
500-sheet paper feeder left cover	330
500-sheet paper feeder front cover	331
500-sheet paper pickup drive assembly	333
500-sheet paper feeder lifter drive assembly	337
500-sheet paper feeder pickup rollers	339
Stapler/stacker (4700 models)	340
Remove the stapler/stacker from the printer	340
Staple cartridge left cover	341
Output tray	341
Left cover	342
Top cover	342
Right cover	344
Staple cartridge	346
Stapler/stacker PCB	347
Stapler/stacker unit assembly 24v 2.5 amp	348
Duplexer	349
Top duplexing assembly	349
Duplex tray	349

7 Troubleshooting

Introduction	352
Troubleshooting process	354
Pre-troubleshooting checklist	354
Troubleshooting checklist	355
Troubleshooting flowchart	356
Power-on checks	357
Power-on troubleshooting overview	357
Control panel messages	359
Warning messages	359
Error messages	359
Critical error messages	359

Message listing	359
Formatter lights	395
Embedded HP Jetdirect LEDs	395
Heartbeat LED	396
Accessory lights (4700 models)	397
Interpreting stapler/stacker indicator light codes	397
Replacement parts configuration	400
Formatter and DC controller	400
Formatter (new or previously installed in another printer)	400
DC controller (new or previously installed in another printer)	401
Formatter and firmware compact flash	401
Paper path troubleshooting	402
Jams	402
Jam locations	402
Jam locations by error message	405
Jam recovery	406
To disable paper jam recovery	407
Avoiding jams	407
Solving repeated jams	408
Persistent jams	408
Basic troubleshooting for jams	408
Data collection	409
General paper path troubleshooting	409
Paper path checklist	410
Jams in Tray 1	410
Jams in Tray 2	411
Jams in the paper path	412
Jams in the top cover	412
Jams in the duplex path	413
Common causes of paper jams	414
Paper jams	414
Clearing jams	415
Jam in Tray 1	415
Jam in Tray 2 or optional trays	416
Jams in top cover area	417
Clearing a jam in the top cover area	418
Clearing other jams	420
Jams in the stapler/stacker (4700 models)	423
Staple jams	429
Paper transport troubleshooting	432
Multiple pages are fed	432
Media is wrinkled or folded	432
Paper is skewed	433
Image formation troubleshooting	434
Print quality troubleshooting tools	434
Print quality problems associated with media	434
Overhead transparency defects	435
Print quality problems that are associated with the environment	436
Print quality problems that are associated with jams	436
Print quality troubleshooting pages	436

Understanding color variations	436
Common causes of color variation	437
Color selection process	437
Matching colors	437
PANTONE* color matching	437
Swatch book color matching	437
Using color	438
HP ImageREt 3600	438
Paper selection	438
sRGB	438
Adobe® RGB	439
CMYK+	439
Color options	439
Print in grayscale	439
Automatic or manual color adjustment	440
Manual color options	440
Halftone options	440
Neutral Grays	440
Edge Control	440
RGB Color	441
Adjusting color balance	441
To adjust color density	441
Web-downloadable color tables	442
Image defects	443
Light image	444
Light color	445
Dark image	445
Dark color	446
Completely blank image	446
All black or solid color	447
Dots in vertical lines	447
Dirt on the front or back of the paper	448
Vertical lines	448
White vertical lines	449
Horizontal lines	449
White horizontal lines	450
Missing color	450
Blank spots	451
Poor fusing	451
Distortion or blurring	452
Smearing	453
Misplaced image	454
Repetitive defects troubleshooting	454
Repetitive defect ruler	455
Interface troubleshooting	457
Communications checks	457
AUTOEXEC.BAT standard configurations	457
Parallel MS-DOS commands	457
Printer Job Language (PJM) commands	457
@PJM [Enter]	457

UEL	458
@PJL COMMENT	458
@PJL INFO CONFIG	458
@PJL INFO ID	458
@PJL INFO USTATUS	458
@PJL INFO PAGECOUNT	458
@PJL JOB	458
@PJL EOJ	459
@PJL ECHO	459
@PJL USTATUS JOB=ON/OFF	459
@PJL USTATUSOFF	459
Changing printer control panel configuration settings	460
Job storage limit (4700 models)	460
Setting the job storage limit	460
Job held timeout (4700 models)	460
Setting the job held timeout	460
Show IP address	461
Showing the IP address	461
Color/black mix	461
Setting the color/black mix	461
Tray behavior options	462
Setting the printer to use the requested tray	462
Setting manually feed prompt	463
Setting the printer default for PS defer media	463
Setting the printer to use size/type prompt	464
Setting the printer to use another tray	464
Setting the printer to duplex blank pages	465
Setting the printer to rotate images	465
Sleep delay	465
Setting sleep delay	466
Disabling/enabling sleep mode	466
Wake time	466
Setting the wake time	467
Display brightness	467
Setting the display brightness	467
Personality	468
Setting the personality	468
Clearable warnings	468
Setting the clearable warnings	469
Auto continue	469
Setting auto continue	469
Replace supplies	470
Setting replace supplies response	470
Order at	470
Setting order at response	470
Color supply out	471
Setting color supply out response	471
Jam recovery	471
Setting jam recovery response	472
RAM disk	472

Changing RAM disk behavior	472
Language	472
Selecting the language	473
Selecting the language if the display is in a language you do not understand	473
Using the printer control panel in shared environments	473
Control panel troubleshooting	474
Printing a menu map	474
Information menu	474
Paper handling menu	476
Configure device menu	478
Printing submenu	478
PCL submenu	482
Print quality submenu	483
System setup submenu	488
Stapler/stacker submenu (4700 models)	493
I/O submenu	494
Embedded Jetdirect submenu	495
Resets submenu	499
Diagnostics menu	500
Service menu	503
Tools for troubleshooting	505
Using the embedded Web server	505
Accessing the embedded Web server	505
Information tab	506
Settings tab	506
Setting the real-time clock	507
Networking tab	507
Other links	507
Configuration pages	507
Configuration page	507
HP embedded Jetdirect page	509
Paper handling configuration page (4700 models)	510
Finding important information on the configuration pages	511
Print the supplies status page	512
Print the usage page	513
Print the demo page	514
Print the file directory page	515
Print the PCL font list page	515
Print the PS font list page	516
Print the RGB samples page	517
Print the CMYK samples page	518
Diagnostics	520
LED diagnostics	520
Engine diagnostics	521
Diagnostics mode	521
Diagnostics that put the engine into the special diagnostics mode	521
Diagnostic tests	521
Individual diagnostic tests	522
Print the event log page	522

View the event log on the control panel display	523
Print the PQ troubleshooting pages	524
Diagnostics page	525
Disable cartridge check (special mode test)	526
Paper path sensors (special mode test)	527
Paper path test	527
Finishing paper path test	528
Manual sensor test (special mode test)	528
Manual sensor test 2 (special mode test)	531
Component test (special mode test)	532
Print/Stop test	535
Colorband test	535
Information menu	535
Configure device menu/printing menu	536
Configure device menu/print quality menu	536
Configure device menu/resets menu	536
Test pages	537
Engine test page	537
Formatter test page	537
Engine resets	538
Cold reset	538
To perform a cold reset	538
NVRAM initialization	538
To initialize NVRAM	538
Hard disk initialization (4700 models)	539
To initialize the hard disk	539
Calibration bypass	539
To bypass calibration	539
Quick Calibrate Now	539
Full Calibrate Now	539
Service menu	541
Using the Service menu	541
Clear event log	541
Mono cycle count/Color cycle count	541
Serial number	541
Service ID	541
Restoring the Service ID	541
Converting the Service ID to an actual date	542
Cold reset paper	542
Diagrams	543
Main parts	543
Switches	545
Sensors	546
Solenoids	547
Motors and fans	548
PCBs	549
DC controller PCB	550
Connectors	551
General timing chart	557
General circuit diagrams	558

8 Parts and diagrams

Introduction	562
Ordering parts and supplies	563
Parts that wear	563
Parts	563
Customer support	563
Supplies and accessories	563
Common fasteners	566
User-replaceable parts	567
Assembly locations	570
Major components	570
External covers and panels	572
Internal components	576
Accessories	610
Alphabetical parts list	628
Numerical parts list	634
Index	641

For the complete PDF manual
please visit www.LaserPros.com.