


HP Color LaserJet CP1210 and CP1510 Series Printers Service Manual



For the complete PDF manual
please visit www.LaserPros.com.



HP Color LaserJet CP1210 and HP Color
Laserjet CP1510 Series MFP Series Printers
Service Manual



Copyright information

© 2008 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number CC378-90983

Edition 1, 01/2008

Safety information

WARNING!

Potential Shock Hazard

Always follow basic safety precautions when using the product to reduce risk of injury from fire or electric shock.

Read and understand all instructions in the user guide.

Observe all warnings and instructions marked on the product.

Use only a grounded electrical outlet when connecting the product to a power source. If you do not know whether the outlet is grounded, check with a qualified electrician.

Do not touch the contacts on the end of any of the sockets on the product. Replace damaged cords immediately.

Unplug the product from wall outlets before cleaning.

Do not install or use the product near water or when you are wet.

Install the product securely on a stable surface.

Install the product in a protected location where no one can step on or trip over the power cord and where the power cord will not be damaged.

If the product does not operate normally, see the online user guide.

Refer all servicing questions to qualified personnel.

Information regarding FCC Class B, Parts 15 and 68 requirements can be found in the user guide.

Trademark credits

Microsoft® and Windows® are U.S. registered trademarks of Microsoft Corporation.

Windows Vista® is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.

Linux is a U.S. registered trademark of Linus Torvalds.

UNIX® is a registered trademark of The Open Group.

PostScript® is a trademark of Adobe Systems Incorporated.

ENERGY STAR and the ENERGY STAR mark are registered U.S. marks.

Table of contents

1 Product basics

Quick access to product information	2
Product comparison	3
Product features	3
Walkaround (HP Color LaserJet CP1210 Series Printer)	5
Front view	5
Back and side view	5
USB connection	6
Model and serial numbers	6
Walkaround (HP Color LaserJet CP1510 Series Printer)	7
Front view	7
Back and side view	8
Model and serial numbers	8
Supported operating systems	9
Supported product software	10
Software included with the product	10
Recommended installation for Windows	10
Express installation	10
Macintosh software (HP Color LaserJet CP1510 only)	10
Printer driver (HP Color LaserJet CP1210 Series Printer)	10
Supported printer drivers (HP Color LaserJet CP1510 Series Printer)	11
Other software provided	11
Software for Windows	11
HP Color LaserJet CP1210 Series Toolbox	11
HP ToolboxFX (HP Color LaserJet CP1510 Series Printer)	11
Software for Macintosh (HP Color LaserJet CP1510 Series Printer only)	12
PostScript Printer Description (PPD) files	12
Configuring the product using a Macintosh	12
Status Alerts software	12
Software for networks (HP Color LaserJet CP1510 Series Printer only)	12
HP Web Jetadmin	12
Embedded Web server (HP Color LaserJet CP1510 Series Printer)	12
Linux	13

System requirements	14
Windows requirements	14
Macintosh requirements (HP Color LaserJet CP1510 Series Printer only)	14
Connectivity (HP Color LaserJet CP1510 Series Printer only)	15
Supported networks	15

2 Control panel

Control-panel walkaround (HP Color LaserJet CP1210 Series Printer)	18
Control-panel walkaround (HP Color LaserJet CP1510 Series Printer)	19
Use the control-panel menus (HP Color LaserJet CP1510 Series Printer only)	21
Use the menus	21
Reports menu	22
System setup menu	23
Network config. menu	25
Service menu	26

3 Paper and print

Supported paper and print media	28
Paper for the HP Color LaserJet CP1210 Series Printer	28
Supported paper and print media sizes	28
Supported paper types and tray capacity	29
Paper for the HP Color LaserJet CP1510 Series Printer	30
Supported paper and print media sizes	30
Supported paper types and tray capacity	31
Load paper and print media	33

4 Manage and maintain

Print information pages	36
HP Color LaserJet CP1210 Series Toolbox	37
Supported browsers	37
View the HP Color LaserJet CP1210 Series Toolbox	38
Status	39
Event log	39
Alerts	40
Set up Status Alerts	40
Set up E-mail Alerts	40
Product information	40
Help	40
Device Settings	42
Device Information	42
Paper Handling	43
Printing	43
PostScript	43

Photo	43
Print Quality	44
Print Density	44
Paper Types	44
Extended Print Modes	45
System Setup	46
Service	46
Network Settings	47
Shop for Supplies	47
Other Links	47
HP ToolboxFX (HP Color LaserJet CP1510 Series Printer only)	48
View HP ToolboxFX	48
Status	49
Event log	49
Alerts	50
Set up Status Alerts	50
Set up E-mail Alerts	50
Product information	50
Help	50
Device Settings	52
Device Information	52
Paper Handling	53
Printing	53
PostScript	53
Photo	53
Print Quality	54
Print Density	54
Paper Types	54
Extended Print Modes	55
System Setup	56
Service	56
Network Settings	57
Shop for Supplies	57
Other Links	57
HP Embedded Web Server (HP Color LaserJet CP1510 Series Printer only)	58
Access the Embedded Web Server by using a network connection	58
Embedded Web server sections	59
HP Web Jetadmin	61
Manage supplies	62
Parts life expectancy	62
Check and order supplies	62
Print-cartridge storage	62
HP policy on non-HP print cartridges	62
HP fraud hotline and Web site	62

Recycle supplies	63
Replace supplies	63
Replace print cartridges	63
Work with memory	66
Product memory (HP Color LaserJet CP1510 Series Printer only)	66
Install memory DIMMs	66
Clean the product	69
Clean the separation and pickup rollers	69
Clean the paper path	69
Upgrade firmware	70

5 Theory of operation

Basic operation	72
Major product systems	72
Product components	73
Sequence of operation	74
Engine control system	75
DC controller	76
Low-voltage power supply	76
High-voltage power supply	77
Laser/scanner system	79
Laser failure detection	79
Image-formation system	80
Image-formation process	80
Latent-image formation stage	81
Step 1: primary charging	81
Step 2: laser-beam exposure	82
Developing stage	82
Step 3: development	82
Transfer stage	83
Step 4: primary transfer	83
Step 5: secondary transfer	83
Step 6: separation from the drum	84
Fusing stage	84
Step 7: fusing	84
ITB cleaning stage	85
Step 8: ITB cleaning	85
Drum cleaning stage	86
Step 9: drum cleaning	86
Pickup-and-feed system	87
Jam detection	88

6 Removal and replacement

Introduction	90
Removal and replacement strategy	90
Electrostatic discharge	90
Required tools	90
Before performing service	92
After performing service	92
Post-service test	93
Print-quality test	93
Parts removal order	94
Remove the print cartridges	95
Rollers	96
Pickup roller	96
Separation roller	98
Transfer roller	100
Feed assembly	102
External panels, covers, and doors	103
Right cover	103
Left cover	105
Front door and Tray 1 or jam-access door	107
Control-panel module and photo-card reader PCA	111
Rear-side cover	115
Rear-upper cover	116
Rear door and rear-lower cover	117
Top cover	119
Internal assemblies	122
Main motor	122
Fuser motor	123
Intermediate transfer belt (ITB)	124
Reinstall the ITB	129
DC controller PCA	131
Special consideration	131
Remove the DC controller PCA	131
Formatter PCA	134
Special consideration	134
Remove the formatter PCA	134
Power supply (high-voltage)	136
Power supply (low-voltage)	140
Power supply (fuser)	146
Fuser	149

7 Problem solve

Solve problems checklist	154
--------------------------------	-----

Menu map (HP Color LaserJet CP1510 Series Printer only)	155
Troubleshooting process	156
Pre-troubleshooting checklist	156
Power-on checks	158
Tools for troubleshooting	159
Print-quality troubleshooting tools	159
Calibrate the product	159
Problem-solve diagrams	160
Repetitive image defects	160
Interface ports	161
DC controller PCA	162
Major components	164
Solenoid, sensors, and motors	166
Rollers	167
PCAs	168
Timing diagram	170
Circuit diagram	171
Status-light patterns (HP Color LaserJet CP1210 Series Printer only)	172
Status-alert messages (HP Color LaserJet CP1210 Series Printer only)	176
Control-panel messages (HP Color LaserJet CP1510 Series Printer only)	179
Pages and reports	183
Demo page	183
Configuration page	183
Supplies status page	183
Event log	184
Paper-handling problems	186
Jams	186
Recover jams	186
Common causes of jams	187
Clear jams	188
Jam in Tray 1	188
Jam in Tray 2	189
Jam in fuser area	190
Jam in output bin	192
Image defects	193
General print quality issues	193
Solve issues with color documents	196
Performance problems	199
Solve connectivity problems	200
Solve direct-connection problems	200
Solve network problems (HP Color LaserJet CP1510 Series Printer only)	200
Service mode functions	202
Service menu	202
Service menu settings (HP Color LaserJet CP1510 Series Printer only)	202

Restore the factory-set defaults on the HP Color LaserJet CP1210 Series Printer	202
Restore the factory-set defaults on the (HP Color LaserJet CP1510 Series Printer)	202
Secondary service menu (HP Color LaserJet CP1510 Series Printer only)	202
Open the secondary service menu	202
Secondary service menu structure	203
Engine resets	203
Engine test page	203
Cold reset	203
NVRAM initialization	204
Solve memory card and PictBridge port (HP Color LaserJet CP1510ni only) problems	205

8 Parts and diagrams

Order parts, accessories, and supplies	208
Order directly from HP	208
Order through service or support providers	208
Order directly through the software	208
Supplies part numbers	209
Screws	211
How to use the parts lists and diagrams	211
Covers, panels, and doors	212
Internal assemblies	216
Alphabetical parts list	230
Numerical parts list	234

Appendix A Service and support

Hewlett-Packard limited warranty statement	240
Customer self repair warranty service	241
Print cartridge limited warranty statement	242
Customer support	243
Repack the product	244
Service information form	245

Appendix B Specifications

Physical specifications	248
Electrical specifications	248
Power consumption and acoustic emissions	248
Operating-environment specifications	248
Skew specifications	248

Appendix C Regulatory information

FCC regulations	250
-----------------------	-----

Environmental product stewardship program	251
Protecting the environment	251
Ozone production	251
Power consumption	251
Paper use	251
Plastics	251
HP LaserJet print supplies	251
Return and recycling instructions	252
United States and Puerto Rico	252
Multiple returns (two to eight cartridges)	252
Single returns	252
Shipping	252
Non-US returns	252
Paper	252
Material restrictions	252
Disposal of waste equipment by users in private households in the European Union ...	253
Material Safety Data Sheet (MSDS)	253
For more information	253
Declaration of conformity	254
Safety statements	255
Laser safety	255
Canadian DOC regulations	255
VCCI statement (Japan)	255
Power cord statement (Japan)	255
EMI statement (Korea)	255
Laser statement for Finland	256
Substances Table (China)	256
Certificate of Volatility	258
Index	259

For the complete PDF manual
please visit www.LaserPros.com.