


For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).



**service**

**hp** LaserJet 1160 printer

**hp** LaserJet 1320 series printer



HP LaserJet 1160 printer and HP LaserJet  
1320 Series printer

**Service Manual** \_\_\_\_\_

## Copyright information

© 2004 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number Q5927-90965

Edition 1, 11/2004

## Safety information

### WARNING!

#### Potential Shock Hazard

Always follow basic safety precautions when using this product to reduce risk of injury from fire or electric shock.

Read and understand all instructions in the user guide.

Observe all warnings and instructions marked on the product.

Use only a grounded electrical outlet when connecting the printer to a power source. If you do not know whether the outlet is grounded, check with a qualified electrician.

Do not touch the contacts on the end of any of the sockets on the printer. Replace damaged cords immediately.

Unplug this product from wall outlets before cleaning.

Do not install or use this product near water or when you are wet.

Install the product securely on a stable surface.

Install the product in a protected location where no one can step on or trip over the power cord and where the power cord will not be damaged.

If the product does not operate normally, see the online user guide.

Refer all servicing questions to qualified personnel.

Information regarding FCC Class B, Parts 15 and 68 requirements can be found in the user guide.

## Trademark credits

Adobe®, Acrobat®, Adobe® PostScript® 3™, and the Acrobat Logo® are trademarks of Adobe Systems Incorporated.

Microsoft®, Windows®, and Windows NT® are U.S. registered trademarks of Microsoft Corporation.

UNIX® is a registered trademark of The Open Group.

Energy Star® and the Energy Star logo® are U.S. registered marks of the United States Environmental Protection Agency.



# Table of contents

## 1 Product Information

Chapter contents.....	1
Printer configurations.....	2
HP LaserJet 1160 and HP LaserJet 1320 Series printers base models.....	3
Features.....	4
HP LaserJet 1160 printer.....	4
HP LaserJet 1320 Series printer.....	4
HP LaserJet 1320n printer.....	5
HP LaserJet 1320tn printer.....	5
HP LaserJet 1320nw printer.....	5
Specifications.....	6
Physical specifications .....	6
Printer capacities and ratings .....	6
Memory specifications .....	7
Port availability .....	7
Electrical specifications .....	8
Acoustic emissions .....	10
Environmental specifications .....	10
Print media specifications .....	11
Supported media sizes .....	11
Hewlett-Packard limited warranty statement .....	12
Hewlett-Packard software license agreement .....	13
Print cartridge limited warranty .....	14
HP LaserJet printing supplies .....	15
Declaration of Conformity statements .....	16
Country/region-specific safety statements .....	18
Laser safety statement .....	18
Canadian DOC regulations .....	18
Korean EMI statement .....	18
Laser statement for Finland .....	19

## 2 Installation

Chapter contents.....	21
Operating environment .....	22
Printer connections .....	22
Software.....	24
Supported operating systems .....	24
Software for Windows .....	25
Software for Macintosh computers .....	27

## 3 Operation

Chapter contents.....	29
Printer control panel .....	30
Status-light patterns .....	31

Printer information pages .....	37
Demo page .....	37
Configuration page .....	37
Supplies Status page .....	37
Network Configuration page .....	37
Using the HP Toolbox .....	38
Supported operating systems .....	38
Supported browsers .....	38
To view the HP Toolbox on Windows systems .....	39
To view the HP Toolbox on Macintosh systems .....	39
HP Toolbox sections .....	39
Other links .....	39
Status tab .....	39
Troubleshooting tab .....	40
Alerts tab .....	40
Documentation tab .....	40
Advanced Printer Settings window .....	41
Network window .....	41
Using the embedded Web server .....	42
To open the embedded Web server .....	42
Information tab .....	43
Settings tab .....	43
Networking tab .....	43
Other links .....	44
Wireless printing .....	45
IEEE 802.11b/g standard .....	45
Bluetooth .....	45

## 4 Maintenance

Chapter contents.....	47
Replacing the print cartridge.....	48
To replace the print cartridge.....	48
Cleaning the printer .....	49
Cleaning the print-cartridge area .....	49
Cleaning the printer media path .....	51
Changing the pickup roller .....	52
Cleaning the pickup roller .....	58
Changing the printer separation pad .....	59
Cleaning the printer separation pad.....	63

## 5 Theory of operation

Chapter contents.....	65
Introduction.....	66
Internal components.....	67
Timing.....	68
Engine control system.....	70
Laser/scanner system.....	72
Pickup/feed/delivery system.....	73
Image-formation system.....	75

## 6 Removal and replacement

Chapter contents.....	79
Introduction .....	80
Removal and replacement strategy .....	80

Electrostatic discharge .....	80
User-replaceable parts .....	80
Required tools .....	80
Before performing service .....	81
Pre-service procedures .....	81
Parts removal order .....	81
Covers.....	82
Left-side cover.....	82
Right-side cover.....	84
Back cover.....	86
Duplexer tray.....	89
Top cover.....	90
Control panel.....	93
Formatter.....	95
Laser/scanner.....	96
Memory-tag-reader assembly.....	97
Duplex-drive PCA.....	99
Fuser.....	101
Fan.....	101
Duplex-drive gears/face-down gears.....	103
Duplex solenoid (SL3) (HP LaserJet 1320 Series printers only).....	106
Fuser.....	107
Interlock assembly.....	117
ECU.....	119
Main motor.....	127
Pickup and feed assemblies.....	129
Transfer roller.....	129
Registration assembly.....	130
Main gear assembly/tray 2 pickup solenoid.....	131
Print-cartridge door.....	135
Wireless communications card.....	137

## 7 Troubleshooting

Chapter contents.....	139
Basic troubleshooting.....	141
Paper-handling problems .....	144
Paper jam .....	144
Print is skewed (crooked) .....	144
More than one sheet of media feeds through the printer at one time .....	144
Printer does not pull media from the media input tray .....	145
Printer curled the media .....	145
Printed media does not exit to the correct path .....	145
Print job is extremely slow .....	145
Paper-path troubleshooting.....	146
Solving print paper-feed problems.....	146
Printed page is different than what appeared on screen .....	148
Garbled, incorrect, or incomplete text .....	148
Missing graphics or text, or blank pages .....	148
Page format is different than on another printer .....	149
Graphics quality .....	149
Status light patterns .....	150
Fatal error secondary messages.....	156
Accessory error secondary messages.....	159
Troubleshooting postscript (PS) errors .....	160
Image troubleshooting.....	161

Print cartridge problems.....	161
Solving image-quality problems .....	162
Clearing jams .....	170
Print-cartridge area .....	170
Input trays .....	172
Output bin .....	176
Straight-through output path .....	176
Automatic two-sided printing (duplexing) path .....	178
Functional checks.....	182
Engine test.....	182
Printing an engine test.....	182
Half self-test functional check.....	183
To perform a half self-test check.....	183
To perform other checks .....	183
Drum rotation functional check .....	184
Heating element check.....	185
High-voltage contacts check.....	186
To check the print cartridge contacts .....	186
To check the high-voltage connector assembly .....	186
Wired network setup problemsolving .....	187
NVRAM initialization.....	188
Cold reset.....	189
Troubleshooting tools and reference diagrams.....	190
Repetitive image defects.....	190
General timing chart.....	191
Circuit diagram.....	192
Solenoids.....	194
Switches and sensors.....	195
Rollers and pads.....	196

## 8 Parts and diagrams

Chapter contents.....	197
Ordering parts and supplies .....	198
Parts .....	198
Related documentation and software .....	198
Supplies .....	198
Consumables and accessories.....	199
Assembly locations.....	202
Covers.....	206
Internal assemblies.....	208
Alphabetical parts list.....	226
Numerical parts list.....	230

## Index

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).