


For the complete PDF manual
please visit www.LaserPros.com.



hp LaserJet 1200 series



i n v e n t

service



HP LaserJet 1200 Series

Service

Copyright Information

© 2001 Hewlett-Packard Company

All Rights Reserved.
Reproduction, adaptations, or translation without prior written permission is prohibited except as allowed under copyright laws.

Part number C7044-90906
First edition, April 2001
Printed in USA

Warranty

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with respect to this information. HEWLETT-PACKARD SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Hewlett-Packard shall not be liable for any direct, indirect, incidental, consequential, or other damage alleged in connection with the furnishing or use of this information.

NOTICE TO U.S. GOVERNMENT USERS: RESTRICTED RIGHTS COMMERCIAL COMPUTER SOFTWARE: "Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) (1)(ii) of the Rights in Technical Data Clause at DFARS 52.227-7013."

Hewlett-Packard Company
11311 Chinden Boulevard
Boise, Idaho 83714 U.S.A.

Trademark Credits

Microsoft, Windows, and MS-DOS are U.S. registered trademarks of Microsoft Corporation.

TrueType is a U.S. trademark of Apple Computer, Inc.

All other products mentioned herein may be trademarks of their respective companies.



Safety Information

WARNING!

Potential Shock Hazard

Always follow basic safety precautions when using this product to reduce risk of injury from fire or electric shock.

- 1 Read and understand all instructions in the user guide.
- 2 Observe all warnings and instructions marked on the product.
- 3 Use only a grounded electrical outlet when connecting the HP LaserJet 1200 printer to a power source. If you don't know whether the outlet is grounded, check with a qualified electrician.
- 4 Do not touch the contacts on the end of any of the sockets on the HP LaserJet 1200 printer. Replace damaged cords immediately.

- 5 Unplug this product from wall outlets before cleaning.
- 6 Do not install or use this product near water or when you are wet.
- 7 Install the product securely on a stable surface.
- 8 Install the product in a protected location where no one can step on or trip over the power cord and the power cord will not be damaged.
- 9 If the product does not operate normally, see the online user guide.
- 10 Refer all servicing questions to qualified personnel.

Information regarding FCC Class B, Parts 15 and 68 requirements can be found in the user guide.

Contents

1 Product information

Chapter contents	13
Introduction	14
Hardware description	14
Firmware description	15
Product specifications	16
Model and serial numbers	19
Overview of printer	20
Front and side view	20
Back and side view	21
Overview of optional copier/scanner	22
Top view	22
Warranty statement	23
Extended warranty	24
Toner cartridge information	25
Refilled toner cartridges	25
Recycling toner cartridges	25

2 Installation and operation

Chapter contents	27
Operating environment	28
Identifying printer components	29
Printer control panel	29
Control panel light patterns	30
Copier/scanner control panel	32
Selecting media	33
Selecting media to print	33
Selecting media to copy or scan	34
Loading media	35
Loading media to print	35
Loading media to copy or scan	36
Printer output paths	37

3 Maintenance

Chapter contents	39
Life expectancies of consumables	40
User-replaceable parts	40
Replacing the printer pickup roller	41
Replacing the printer separation pad	43
Replacing the copier/scanner separation pad	45
Cleaning the equipment	46
Cleaning the print path	47
Cleaning the toner cartridge area	48
Cleaning the printer pickup roller	49
Cleaning the printer separation pad	50
Cleaning and recalibrating the copier/scanner	51
Cleaning the scanner path	51

4 Operational overview

Chapter contents	53
Basic functions	54
Formatter system	55
Control panel	56
Draft mode	56
MEt	56
Enhanced I/O	56
PJL overview	57
Printer functions	58
Engine control unit/power system	59
Image formation system	64
Printer paper-feed system	67
Jam detection	69
Optional copier/scanner	71
Optical system	71
Document pickup and feed systems	71
Basic sequence of operation (formatter-to-printer)	73

5 Removal and replacement

Chapter contents	75
Removal and replacement strategy	77
Required tools	77
Before performing service	78
Toner cartridge	78
Parts removal order	79

Covers	80
Left side cover	80
Optional copier/scanner	81
Back cover	82
Right side cover	84
Top cover	87
Control panel assembly	88
Front cover assembly	89
Internal assemblies	96
Transfer roller	96
Formatter	97
Laser/scanner assembly	99
Fuser assembly	101
Output rollers	105
Motor	107
Solenoid	108
Fan assembly	110
Right plate assembly	112
Pickup assembly	114
Pickup roller shaft	117
Paper lift plate assembly	118
Left plate assembly	119
Bottom assemblies	120
ECU pan	120
Paper-feed assembly	124

6 Troubleshooting

Chapter contents	129
Basic troubleshooting	130
Errors	132
Control panel light messages	132
Fatal error secondary messages	135
Checking the toner cartridge	137
Solving image-quality problems	138
Solving paper-feed problems	146
Solving print paper-feed problems	146
Solving copying and scanning paper-feed problems	148
Functional checks	149
Engine test	149
Half self-test functional check	150
Drum rotation functional check	151
Heating element check	152
High-voltage power supply check	153
Paper path check	155

Service mode functions	156
NVRAM initialization/cold reset	156
PJL software commands	156
Troubleshooting tools	159
Internal reports	159
Repetitive image defect ruler	161
Main wiring	162
Locations of connectors	164
Locations of LEDs, jumpers, and switches	165

7 Parts and diagrams

Chapter contents	167
Ordering parts and supplies	168
Parts	168
Related documentation and software	168
Consumables	168
Accessories	169
How to use the parts lists and diagrams	171
Common hardware	171
Assembly locations	172
Printer trays & optional copier/scanner	172
Covers	174
Internal assemblies	176
Internal components (1 of 2)	176
Internal components (2 of 2)	178
Electrical components	180
Paper pickup assembly (1 of 2)	182
Paper pickup assembly (2 of 2)	184
Fuser assembly	186
Alphabetical parts list	188
Numerical parts list	191

For the complete PDF manual
please visit www.LaserPros.com.