
Service Supplement

For the complete PDF manual
please visit www.LaserPros.com.

**HP LaserJet 5P / 5MP /
6P / 6MP Printer
(C3150A/ C3155A/
C3980A/ C3982A)**

Service Supplement

**HP LaserJet 5P / 5MP
Printer
(C3150A / C3155A)**

© Copyright Hewlett-Packard Company 1995

All Rights Reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

Publication number
C3150-90002

First edition, May 1995

Printed in USA

Warranty

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties or merchantability and fitness for a particular purpose.

Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damage in connection with the furnishing, performance, or use of this material.

WARNING

Electrical Shock Hazard

To avoid electrical shock, use only supplied power cords and connect only to properly grounded (3-hole) wall outlets.

Conventions

This manual uses the following conventions:

Color is used to emphasize items which are important to the material under discussion.

The names of major printer parts and assemblies are Capitalized.

Bold is used for emphasis, particularly in situations where *italic* type would be confusing.

Italic type is used to indicate related documents or emphasis.

COMPUTER type indicates text as seen on a computer monitor.

Note

Notes contain important information set off from the text.

CAUTION

Caution messages alert you to the possibility of damage to equipment or loss of data.

WARNING!

Warning messages alert you to the possibility of personal injury.

Contents

Overview	2
Product Information	3
Key Printer Locations and Parts.	4
Model and Serial Numbers	5
Product Specifications	6
Documentation and Software	8
Documentation	8
Software	9
New Product Features	10
The HP LaserJet 5P/5MP Status Panel	10
The GO and RESET Buttons	10
The Status Lights	11
Common LED patterns	12
Paper Movement Overview	16
Infrared Communication	18
To Print Using the Infrared Port	20
Troubleshooting IR Printing Problems	22
Interface Connections	25
The Parallel Printer Interfaces	26
Resource Saving	27
I/O Buffering	28
Service Mode, PJI Defaults	30
Test Pages and Resets	32
Printing a Self-Test Page	33
Life Expectancy of Consumables	36
Removal and Replacement	37
Overview	37
Required Tools	38
Removing the Power Door	39
Removing the I/O Cover	39
Removing the Left Side Cover	40
Removing the Top Cover	41
Removing the Tray 1 Pickup Assembly	44
Removing the Formatter Board and Shield	47
Removing the Fusing Assembly	50
Removing the DC Controller Assemblies	51
Troubleshooting	55
Continuable Data Error Light Patterns	56
Error 53 -- Memory/SIMM Errors	58
Fatal/Service Errors	60
Infrared Port Not Responding	65
Using the Infrared Test Tool	66
Parts and Diagrams	68
Ordering Parts	68
Ordering Consumables	69

Accessories	86
Index	87

For the complete PDF manual
please visit www.LaserPros.com.