



LASERJET PRO M1530

MFP SERIES

## Service Manual







# HP LaserJet Pro M1530 MFP Series

Service Manual

**Copyright and License**

© 2010 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number: CE538-90986

Edition 1, 9/2010


**Trademark Credits**

Microsoft®, Windows®, Windows® XP, and Windows Vista® are U.S. registered trademarks of Microsoft Corporation.


ENERGY STAR and the ENERGY STAR mark are registered U.S. marks.


## Conventions used in this guide

---

 **TIP:** Tips provide helpful hints or shortcuts.

 **NOTE:** Notes provide important information to explain a concept or to complete a task.

 **CAUTION:** Cautions indicate procedures that you should follow to avoid losing data or damaging the product.

 **WARNING!** Warnings alert you to specific procedures that you should follow to avoid personal injury, catastrophic loss of data, or extensive damage to the product.

---



---

# Table of contents

<b>1 Removal and replacement .....</b>	<b>1</b>
Introduction .....	2
Removal and replacement strategy .....	2
Electrostatic discharge .....	3
Required tools .....	3
Service approach .....	3
Before performing service .....	3
After performing service .....	4
Post-service test .....	4
Print-quality test .....	4
Parts removal order .....	4
Removal and replacement procedures .....	7
Print cartridge .....	7
Pickup roller .....	8
Separation pad .....	9
Transfer roller .....	10
Covers .....	10
Main tray .....	10
Output bin extension .....	11
Left cover .....	12
Remove the left cover .....	12
Scanner assembly .....	15
Remove the scanner assembly .....	15
Scanner hinges .....	17
Right cover .....	19
Remove the right cover .....	19
Duplex door .....	22
Duplex frame .....	23
Remove the duplex frame .....	23
Cartridge door .....	24
Remove the cartridge door .....	24
Front cover .....	27
Remove the front cover .....	27
Upper cover .....	28

Remove the upper cover .....	28
Main assemblies .....	29
Formatter PCA .....	29
Remove the formatter PCA .....	29
Fax PCA .....	31
Remove the fax PCA .....	31
Laser scanner assembly .....	32
Remove the laser scanner assembly .....	32
Reinstall the laser scanner assembly .....	35
Pickup assembly .....	36
Remove the pickup assembly .....	36
Reinstall the pickup assembly .....	41
Fuser .....	43
Remove the fuser .....	43
Reinstall the fuser .....	48
Main motor .....	49
Remove the main motor .....	49
Reinstall the main motor drive belt .....	54
Pickup solenoid .....	55
Remove the pickup solenoid .....	55
Engine controller PCA .....	59
Remove the engine controller PCA .....	59
Reinstall the engine controller PCA .....	64
Duplex reverse solenoid .....	67
Remove the duplex reverse solenoid .....	67
Main fan .....	70
Remove the main fan .....	70
Reinstall the main fan .....	73
Duplex connector PCA .....	74
Remove the duplex connector PCA .....	74
Scanner components .....	77
Document feeder input tray .....	77
Document feeder cover .....	78
Document feeder pick arm assembly .....	80
Remove the document feeder pick arm assembly .....	80
Document feeder core assembly .....	82
Remove the document feeder core assembly .....	82
Post scan pinch rollers .....	84
Remove the post scan pinch rollers .....	84
Document feeder base assembly .....	85
Remove the document feeder base assembly .....	85
Document feeder floating hinges .....	87
Remove the document feeder floating hinges .....	87
Control panel .....	88

<b>2 Solve problems .....</b>	<b>89</b>
Problem-solving checklist .....	90
Step 1: Check that the product power is on .....	90
Step 2: Check the control panel for error messages .....	90
Step 3: Test print functionality .....	90
Step 4: Test copy functionality .....	91
Step 5: Test the fax sending functionality .....	91
Step 6: Test the fax receiving functionality .....	91
Step 7: Try sending a print job from a computer .....	91
Menu map .....	92
Troubleshooting process .....	93
Determine the problem source .....	93
Power subsystem .....	94
Power-on checks .....	94
Tools for troubleshooting .....	95
Individual component diagnostics .....	95
Engine diagnostics .....	95
Engine test button .....	95
Components tests .....	96
Drum rotation functional check .....	96
Half self-test functional check .....	96
Diagrams .....	97
Plug/jack locations .....	97
Location of connectors .....	98
Locations of major components .....	100
General timing charts .....	104
General circuit diagram .....	105
HP ToolboxFX .....	106
View HP ToolboxFX .....	106
Status .....	106
Event log .....	106
Fax .....	107
Fax tasks .....	107
Fax phone book .....	107
Fax send log .....	109
Fax receive log .....	109
Block Faxes .....	109
Help .....	109
System Settings .....	110
Device information .....	110
Paper handling .....	111
Print quality .....	111
Paper types .....	111
System setup .....	112

Service .....	112
Device polling .....	112
Print Settings .....	112
Printing .....	112
PCL 5e .....	113
PostScript .....	113
Network Settings .....	113
Internal print quality test pages .....	114
Print a cleaning page .....	114
Configuration page .....	114
Print quality troubleshooting tools .....	115
Repetitive defect ruler .....	115
Control panel menus .....	115
Setup menu .....	115
Quick Forms menu .....	116
Reports menu .....	116
Fax Setup .....	117
System Setup menu .....	119
Service menu .....	121
Network Setup menu .....	122
Function-specific menus .....	122
Copy .....	123
Fax .....	124
Interpret control panel messages .....	126
Control panel message types .....	126
Control panel messages .....	126
Paper feeds incorrectly or becomes jammed .....	143
The product does not pick up paper .....	143
The product picks up multiple sheets of paper .....	143
Prevent paper jams .....	143
Clear jams .....	144
Jam locations .....	144
Clear jams from the document feeder .....	145
Clear jams from the input trays .....	146
Clear jams from inside the product .....	148
Clear jams from the output areas .....	150
Clear jams from the duplexer .....	151
Improve print quality .....	154
Select a paper type .....	154
Use paper that meets HP specifications .....	154
Print a cleaning page .....	155
Check the print cartridge .....	155
Print the Supplies Status page .....	156
Inspect the print cartridge for damage .....	157

Repeating defects .....	157
Use the printer driver that best meets your printing needs .....	158
Improve print quality for copies .....	158
Clean the product .....	160
Clean the pickup roller .....	160
Clean the document feeder pickup rollers and separation pad .....	161
Clean the paper path .....	162
Clean the paper path from HP ToolboxFX .....	162
Clean the paper path from the control panel .....	162
Clean the scanner glass strip and platen .....	162
The product does not print or it prints slowly .....	164
The product does not print .....	164
The product prints slowly .....	164
Solve connectivity problems .....	166
Solve direct-connect problems .....	166
Solve network problems .....	166
Poor physical connection .....	166
The computer is using the incorrect IP address for the product .....	166
The computer is unable to communicate with the product .....	167
The product is using incorrect link and duplex settings for the network .....	167
New software programs might be causing compatibility problems .....	167
The computer or workstation might be set up incorrectly .....	167
The product is disabled, or other network settings are incorrect .....	167
Service mode functions .....	168
Secondary service menu .....	168
Open the secondary service menu .....	168
Secondary service menu structure .....	168
Product resets .....	169
Solve fax problems .....	169
Fax troubleshooting checklist .....	169
Troubleshoot fax codes and trace reports .....	171
View and interpret fax error codes .....	171
View the fax trace report .....	172
Fax logs and reports .....	173
Print all fax reports .....	173
Print individual fax reports .....	173
Set the fax activity log to print automatically .....	174
Set the fax error report .....	174
Set the fax confirmation report .....	175
Include the first page of each fax on the fax confirmation, fax error, and last call reports .....	176
Change error correction and fax speed .....	176
Set the fax-error-correction mode .....	176
Change the fax speed .....	176

Solve problems sending faxes .....	177
An error message displays on the control panel .....	177
The Comm. Error message appears .....	177
No dial tone .....	178
The Fax is busy message appears .....	178
The No fax answer message appears .....	179
Document feeder paper jam .....	179
The Fax memory full message appears .....	179
Scanner error .....	180
The control panel displays a Ready message with no attempt to send the fax	180
The control panel displays the message "Storing page 1" and does not progress beyond that message .....	180
Faxes can be received, but not sent .....	180
Unable to use fax functions from the control panel .....	181
Unable to use speed dials .....	181
Unable to use group dials .....	181
Receive a recorded error message from the phone company when trying to send a fax .....	182
Unable to send a fax when a phone is connected to the product .....	182
Solve problems receiving faxes .....	183
The fax does not respond .....	183
The fax has a dedicated phone line .....	183
An answering machine is connected to the product .....	183
A telephone handset is connected to the product .....	184
The Answer Mode setting is set to the Manual setting .....	184
Voice mail is available on the fax line .....	184
The product is connected to a DSL phone service .....	185
The product uses a fax over IP or VoIP phone service .....	185
An error message displays on the control panel .....	185
The No fax detected message appears .....	185
The Comm. Error message appears .....	186
The Fax memory full message appears .....	186
The Fax is busy message appears .....	187
A fax is received but does not print .....	187
The Private Receive feature is on .....	187
The Receive to PC feature is enabled .....	187
Sender receives a busy signal .....	188
A handset is connected to the product .....	188
A phone line splitter is being used .....	188
No dial tone .....	188
Cannot send or receive a fax on a PBX line .....	188
Solve general fax problems .....	189
Faxes are sending slowly .....	189
Fax quality is poor .....	190

Fax cuts off or prints on two pages .....	190
Product updates .....	191
<b>3 Parts and diagrams .....</b>	<b>193</b>
Order parts by authorized service providers .....	194
Order replacement parts .....	194
Related documentation and software .....	194
Supplies part numbers .....	194
Whole unit replacement part numbers .....	194
Customer self repair parts .....	195
Service parts .....	195
How to use the parts lists and diagrams .....	195
Assembly locations .....	196
Locations of major components .....	196
Covers .....	200
Internal assemblies .....	202
Internal assemblies (1 of 4) .....	202
Internal assemblies (2 of 4) .....	204
Internal assemblies (3 of 4) .....	206
Internal assemblies (4 of 4) .....	208
Scanner and document feeder (ADF) main assemblies .....	210
Document feeder internal components .....	212
Alphabetical parts list .....	214
Numerical parts list .....	217
<b>Appendix A Service and support .....</b>	<b>221</b>
Hewlett-Packard limited warranty statement .....	222
HP's Premium Protection Warranty: LaserJet print cartridge limited warranty statement .....	223
Data stored on the print cartridge .....	224
End User License Agreement .....	225
Customer support .....	227
Repack the product .....	228
<b>Appendix B Product specifications .....</b>	<b>229</b>
Physical specifications .....	230
Power consumption .....	230
Acoustic specifications .....	230
Environmental specifications .....	230
<b>Appendix C Regulatory information .....</b>	<b>231</b>
FCC regulations .....	232
Environmental product stewardship program .....	233
Protecting the environment .....	233

Ozone production .....	233
Power consumption .....	233
Toner consumption .....	233
Paper use .....	233
Plastics .....	233
HP LaserJet print supplies .....	233
Return and recycling instructions .....	234
United States and Puerto Rico .....	234
Multiple returns (more than one cartridge) .....	234
Single returns .....	234
Shipping .....	234
Non-U.S. returns .....	235
Paper .....	235
Material restrictions .....	235
Disposal of waste equipment by users in private households in the European Union ....	235
Chemical substances .....	236
Material Safety Data Sheet (MSDS) .....	236
For more information .....	236
Declaration of conformity .....	237
Certificate of Volatility .....	239
Safety statements .....	240
Laser safety .....	240
Canadian DOC regulations .....	240
VCCI statement (Japan) .....	240
Power cord instructions .....	240
Power cord statement (Japan) .....	240
EMC statement (Korea) .....	240
Laser statement for Finland .....	241
GS statement (Germany) .....	241
Substances Table (China) .....	242
Restriction on Hazardous Substances statement (Turkey) .....	242
Additional statements for telecom (fax) products .....	243
EU Statement for Telecom Operation .....	243
New Zealand Telecom Statements .....	243
Additional FCC statement for telecom products (US) .....	243
Telephone Consumer Protection Act (US) .....	244
Industry Canada CS-03 requirements .....	244
<b>Index .....</b>	<b>247</b>