



Service Manual

**Lexmark™ C540n, C543dn, C544n,
C544dn, C544dtn, and C544dw**

5025-2xx, 4xx

- ***Table of contents***
- ***Start diagnostics***
- ***Safety and notices***
- ***Trademarks***
- ***Index***

LEXMARK™

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

Edition: October 14, 2008

The following paragraph does not apply to any country where such provisions are inconsistent with local law:

LEXMARK INTERNATIONAL, INC. PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

Comments may be addressed to Lexmark International, Inc., Department D22A/032-2, 740 West New Circle Road, Lexington, Kentucky 40550, U.S.A or e-mail at ServiceInfoAndTraining@Lexmark.com. Lexmark may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user's responsibility.

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

PCL® is a registered trademark of the Hewlett-Packard Company. PCL is Hewlett-Packard Company's designation of a set of printer commands (language) and functions included in its printer products. This printer is intended to be compatible with the PCL language. This means the printer recognizes PCL commands used in various application programs, and that the printer emulates the functions corresponding to the commands.

All other trademarks are the property of their respective owners.

© 2008 Lexmark International, Inc.

All rights reserved.

UNITED STATES GOVERNMENT RIGHTS

This software and any accompanying documentation provided under this agreement are commercial computer software and documentation developed exclusively at private expense.

Table of contents

Table of contents	iii
Notices and safety information	ix
Laser notice	ix
Safety information	xv
Preface	xviii
Conventions	xviii
General information	1-1
Models	1-1
Options and features	1-1
Printer specifications	1-2
Memory	1-2
Print quality	1-2
Connectivity (network support)	1-3
Operating modes	1-3
Data streams	1-4
Dimensions	1-4
Clearances	1-5
Power and electrical specifications	1-6
Acoustics	1-7
Environment specifications	1-7
Media handling	1-8
Input and output sources	1-8
Duplex capability	1-8
Media input size specifications	1-9
Media input type specifications	1-10
Media output size and type	1-11
Media guidelines	1-12
Paper characteristics	1-12
Unacceptable paper	1-12
Selecting paper	1-13
Selecting preprinted forms and letterhead	1-13
Storing paper	1-13
Using recycled paper and other office papers	1-13
Tools required for service	1-14
Acronyms	1-15
Diagnostic information	2-1
Start	2-1
POR (Power-On Reset) sequence	2-2
Symptom tables	2-3
Printer symptom table	2-3
Print quality symptom table	2-4
Error codes and messages	2-5
User status and customer attendance messages	2-5
Paper Jam messages	2-11
Service error messages	2-12
Service checks	2-24
122.xx—Fuser temperature incorrect	2-24
90x.xx error	2-24
925.01—Fan error service check	2-25
930.xx–935.xx—Printhead errors service check	2-25

936.xx, 937.xx—Transport motor service check	2-26
950.xx NVRAM Failure service check	2-26
Autocompensator mechanism service check	2-27
Bin full sensor service check	2-27
Dead printer service check	2-28
Duplex/manual feed sensor (S1) service check	2-29
Front door sensor or switches service check	2-30
Fuser exit sensor service check	2-31
Fuser service check	2-32
Input sensor (S2) service check	2-34
Main drive gear assembly (EP drive) service check	2-35
Operator panel service check	2-36
One or more operator panel buttons fail	2-36
Operator panel display blank, five <i>beeps</i>	2-37
Operator panel display blank, printer <i>beeps</i> five times and pauses	2-38
Operator panel displays all diamonds, no <i>beeps</i>	2-39
Operator panel displays all diamonds, five <i>beeps</i>	2-40
Operator panel display is dim and unchanging	2-41
Print quality service check	2-42
Print quality—background	2-43
Print quality—blank page	2-44
Print quality—blurred or fuzzy print	2-45
Print quality—half-color page	2-45
Print quality—horizontal banding	2-46
Print quality—horizontal line	2-46
Print quality—insufficient fusing	2-47
Print quality—missing image at edge	2-47
Print quality—mottle (2–5mm speckles)	2-47
Print quality—narrow vertical line	2-48
Print quality—random marks	2-48
Print quality—residual image	2-49
Print quality—solid color page	2-50
Print quality—vertical banding	2-50
Printhead service check	2-51
Toner meter cycle (TMC) card	2-52
Toner meter sensors (Y, C, M, K) on TMC card	2-52
Transfer roll service check	2-53
Tray 1 sensor service check	2-53
User operator panel and Administration menus	2-55
Printer operator panel	2-55
Operator panel buttons	2-55
Menu map	2-56

Diagnostic aids **3-1**

Accessing service menus	3-1
Diagnostics Menu (Diag Menu)	3-2
Diagnostics Menu structure	3-2
Available tests	3-2
Registration	3-4
Skew	3-5
Quick Test	3-5
Alignment	3-7
Print Tests	3-10
Input source tests	3-10
Print quality test pages (Prt Quality Pgs)	3-11
Hardware Tests	3-11
Panel Test	3-11
Button Test	3-12
DRAM Test	3-12

Duplex Tests	3-13
Quick Test (duplex)	3-13
Top Margin (duplex)	3-14
Left Margin (duplex)	3-14
Input Tray Tests	3-15
Feed Tests	3-15
Sensor Test	3-15
Base Sensor Test	3-16
Miscellaneous tests	3-16
Motor Detect	3-16
Device Tests	3-17
Flash Test	3-17
Printer Setup	3-17
Defaults	3-17
Page counts	3-17
Serial Number	3-18
Engine Setting 1 through 4	3-18
Model Name	3-18
Configuration ID	3-18
ITU Barcode	3-19
Reset Fuser Cnt	3-19
EP Setup	3-19
EP Defaults	3-19
Fuser Temperature	3-19
DC Charge Adjust, Dev Bias Adj, Transfer Adjust	3-20
TPS Setup	3-20
Right or Left TPS	3-20
Cal Ref Adj	3-20
Reset Color Cal	3-21
Reports	3-21
Menu Settings Page	3-21
Event Log	3-21
Display Log	3-21
Print Log	3-22
Clear Log	3-22
EXIT Diags	3-23
Configuration menu (Config Menu)	3-24
Available tests	3-24
Prt Quality Pgs	3-24
Color Trapping	3-24
Reports	3-25
Menu Settings Page	3-25
Event Log	3-25
Panel Menus	3-25
PPDS Emulation	3-25
Demo Mode	3-25
Factory Defaults	3-26
Energy Conserve	3-26
Auto Color Adj	3-27
Font Sharpening	3-27
Exit Config	3-27
Paper jams	3-28
Avoiding jams	3-28
Understanding jam numbers and locations	3-29
200 paper jams	3-30
201 paper jam	3-30
202 paper jam	3-31
230 paper jam	3-32
235 paper jam	3-32

24x paper jam	3-32
250 paper jam	3-32
Theory of operation	3-33
Print engine theory	3-33
Electrophotographic process (EP process)	3-33
Electrophotographic process basics	3-33
Step 1: Charge	3-34
Step 2: Expose	3-35
Step 3: Develop	3-36
Step 4a: First transfer	3-37
Step 4b: Second transfer	3-38
Step 5: Fuse	3-39
Step 6: Clean/erase	3-40
Paper path, transport components	3-42
Paper path Information	3-42
Transport components	3-43
Duplex process	3-44
Color theory	3-45
What is RGB color?	3-45
What is CMYK color?	3-45
How is color specified in a document to be printed?	3-45
How does the printer know what color to print?	3-45
Should I use PostScript or PCL emulation printer software? What settings should I use for the best color?	3-45
Why doesn't the printed color match the color I see on the computer screen?	3-45
The printed page appears tinted. Can I adjust the color?	3-45
My color transparencies seem dark when they are projected. Is there anything I can do to improve the color?	3-46
What is manual color correction?	3-46
How can I match a particular color (such as a corporate logo)?	3-47
What are detailed Color Samples, and how do I access them?	3-47
Repair information	4-1
Handling ESD-sensitive parts	4-1
Removal procedures	4-2
Front cover assembly removal	4-2
Left cover assembly removal	4-6
Operator panel bezel and name plate removal	4-8
Operator panel removal	4-9
Right cover assembly removal	4-10
Rear shield removal	4-11
Top cover assembly removal	4-12
Autocompensator mechanism (ACM) removal—standard tray	4-15
Bin full sensor removal	4-18
Bin full sensor flag and exit deflector removal	4-18
Controller board removal	4-19
Developer unit removal	4-21
Duplex sensor removal	4-21
Exit deflector and bin full sensor flag removal	4-24
Fuser assembly removal	4-26
Fuser drive motor assembly removal	4-29
Fuser exit sensor removal	4-30
High-voltage power supply (HVPS) assembly removal	4-31
Image transfer unit (ITU) removal	4-33
Imaging unit (IU) removal	4-35
Low-voltage power supply (LVPS) assembly removal	4-37
Lower frame removal, right and left	4-39
Left lower frame	4-39
Right lower frame	4-41

Main drive gear assembly removal	4-45
Pick tires removal—standard media tray	4-48
Printhead removal	4-49
Toner cartridge contacts	4-50
Toner density sensor (TDS) removal—left or right sensor	4-53
Toner meter cycle (TMC) card removal	4-55
Tray present sensor removal	4-57
USB port connector removal	4-59
Waste toner bottle removal	4-60
Wireless network antenna removal	4-61
Wireless network card	4-63
Connector locations	5-1
Locations	5-1
Connectors	5-2
Controller board diagram	5-2
High-voltage power supply (HVPS) diagram	5-10
Low-voltage power supply (LVPS) diagram	5-12
Toner meter cycle (TMC) card	5-13
Wireless network card	5-14
Preventive maintenance	6-1
Safety inspection guide	6-1
Parts catalog	7-1
How to use this parts catalog	7-1
Assembly 1: Covers	7-2
Assembly 2: Frames	7-4
Assembly 3: Electronics	7-6
Assembly 4: Cables	7-8
Assembly 5: Options and miscellaneous	7-9
Index	I-1
Part number index	I-7