



## *Service Manual*

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).

**Lexmark™ W820 Options**

**4025-XXX**

- ***Table of Contents***
- ***Start Diagnostics***
- ***Safety and Notices***
- ***Trademarks***
- ***Index***
- ***Manuals Menu***

# LEXMARK™

Lexmark and Lexmark with diamond design are  
trademarks of Lexmark International, Inc., registered  
in the United States and/or other countries.

**Edition: May 2001**

**The following paragraph does not apply to any country where such provisions are inconsistent with local law:**  
LEXMARK INTERNATIONAL, INC. PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

Comments may be addressed to Lexmark International, Inc., Department D22A/032-2, 740 West New Circle Road, Lexington, Kentucky 40550, U.S.A or e-mail at [ServiceInfoAndTraining@Lexmark.com](mailto:ServiceInfoAndTraining@Lexmark.com). Lexmark may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you. You can purchase additional copies of publications related to this product by calling 1-800-553-9727. In other countries, contact your point of purchase.

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

PostScript is a registered trademark of Adobe Systems Incorporated.

Other trademarks are the property of their respective owners.

**© Copyright Lexmark International, Inc. 2001.  
All rights reserved.**

**UNITED STATES GOVERNMENT RESTRICTED RIGHTS**

This software and documentation are provided with RESTRICTED RIGHTS. Use, duplication or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 and in applicable FAR provisions: Lexmark International, Inc., Lexington, KY U.S.A. P/N 12G3782

# Contents

<b>Preface</b> .....	ix
<b>Safety Information</b> .....	x
<b>General Information</b> .....	1-1
<b>Maintenance Approach</b> .....	1-1
<b>Tools Required For Service</b> .....	1-1
<b>Symbols Used in this Manual</b> .....	1-1
<b>Safety Details</b> .....	1-1
Printer Power Supply and Electrical Components .....	1-2
Mechanical Components .....	1-2
Printer Laser Components .....	1-2
Printer Fuser Components .....	1-3
Safety Components .....	1-3
Caution Labels .....	1-3
<b>Envelope Feeder</b> .....	1-4
Envelope Feeder Overview .....	1-4
Schematic Diagram of the Envelope Feeder Operation .....	1-5
Envelope Feeder Power and Control .....	1-6
Envelope Feeder Drive Generation and Distribution .....	1-6
Envelope Feeder Power .....	1-6
Envelope Feeder Control .....	1-7
Envelope Feeder Control Components .....	1-8
Mechanical Drive .....	1-8
Envelope Feeder Paper Path .....	1-10
Envelope Feeder Paper Path Components .....	1-10
Envelope Feeder General Specifications .....	1-11
<b>Duplex</b> .....	1-12
Duplex Overview .....	1-12
Schematic Diagram of the Duplex Operation .....	1-13
Duplex Power and Control .....	1-13
Duplex Drive Generation and Distribution .....	1-13
Duplex Power .....	1-14
Duplex Control .....	1-14
Duplex Control Components .....	1-15
Mechanical Drive .....	1-15
Duplex Drive Components .....	1-16
Duplex Paper Path .....	1-17
Duplex Paper Path Components .....	1-20

## 4025 Options

Duplex General Specifications .....	1-21
<b>Mailbox .....</b>	<b>1-22</b>
Mailbox Overview .....	1-22
Schematic Diagram of the Mailbox Operation .....	1-23
Mailbox Power and Control .....	1-24
Mailbox Drive Generation and Distribution .....	1-24
Mailbox Power .....	1-24
Mailbox Control .....	1-24
Mailbox Control Components .....	1-26
Mechanical Drive .....	1-27
Drive for the Mailbox .....	1-28
Mailbox Mechanical Drive Components .....	1-29
Mailbox Paper Path .....	1-30
Paper Path 1: Bypass the Mailbox and Feed Paper to the Output Tray .....	1-30
Paper Path 1 Components .....	1-31
Paper Path 2: Feed Paper to Bin 10 .....	1-32
Paper Path 2 Components .....	1-33
Paper Path 3: Feed Paper to Bins 2 through 10 .....	1-35
Paper Path 3 Components .....	1-36
Mailbox Modes .....	1-37
Paper Size Recommendations .....	1-38
Print Speeds While Using the Mailbox .....	1-38
Mailbox General Specifications .....	1-39
<b>High Capacity Feeder .....</b>	<b>1-40</b>
High Capacity Feeder Overview .....	1-40
Schematic Diagram of the High Capacity Feeder Operation .....	1-41
High Capacity Feeder Power and Control .....	1-42
High Capacity Feeder Drive Generation and Distribution .....	1-42
High Capacity Feeder Power .....	1-42
High Capacity Feeder Control .....	1-43
High Capacity Feeder Control Components .....	1-44
Mechanical Drive .....	1-45
Drive for High Capacity Feeder .....	1-45
Drive for Tray 3 .....	1-46
Mechanical Drive Tray 3 Components .....	1-47
Drive for Tray 4 .....	1-49
Lift Motor Operation for Tray 4 .....	1-50
Mechanical Drive Tray 4 Components .....	1-50
Drive for Tray 5 .....	1-52
Lift Motor Operation for Tray 5 .....	1-53
Mechanical Drive Tray 5 Components .....	1-54
High Capacity Feeder Paper Path .....	1-55

## 4025 Options

Feed from Tray 3 .....	1-56
Tray 3 Paper Path Components .....	1-57
Feed from Tray 4 .....	1-57
Tray 4 Paper Path Components .....	1-59
Feed from Tray 5 .....	1-61
Tray 5 Paper Path Components .....	1-62
High Capacity Feeder General Specifications .....	1-64
<b>Glossary of Terms, Acronyms, and Abbreviations .....</b>	<b>1-65</b>
<b>Diagnostic Information .....</b>	<b>2-1</b>
<b>Start .....</b>	<b>2-1</b>
<b>Envelope Feeder .....</b>	<b>2-2</b>
Envelope Feeder Error Code Table .....	2-2
Envelope Feeder Symptom Table .....	2-2
Envelope Feeder Error Code Service Checks .....	2-3
Envelope Feeder Symptom Service Checks .....	2-7
<b>Duplex .....</b>	<b>2-8</b>
Duplex Error Code Table .....	2-8
Duplex Symptom Table .....	2-9
Duplex Error Code Service Checks .....	2-9
Error Code 997 .....	2-17
Duplex Symptom Service Checks .....	2-18
<b>Mailbox .....</b>	<b>2-19</b>
Mailbox Error Code Table .....	2-19
Mailbox Symptom Table .....	2-20
Mailbox Error Code Service Checks .....	2-20
Error Code 996 .....	2-29
Mailbox Symptom Service Checks .....	2-30
<b>High Capacity Feeder .....</b>	<b>2-32</b>
High Capacity Feeder Error Code Table .....	2-32
High Capacity Feeder Symptom Table .....	2-33
High Capacity Feeder Error Code Service Checks .....	2-33
Error Code 993 and 994 .....	2-51
High Capacity Feeder Symptom Service Checks .....	2-52
<b>Diagnostic Aids .....</b>	<b>3-1</b>
<b>Envelope Feeder Tests .....</b>	<b>3-1</b>
Feed Test .....	3-1
Sensor Test .....	3-1
<b>Duplex Tests .....</b>	<b>3-2</b>
Feed Test .....	3-2

## 4025 Options

Sensor Test .....	3-2
<b>Mailbox Tests .....</b>	<b>3-3</b>
Feed Test .....	3-3
Feed All Bins Test .....	3-3
Sensor Test .....	3-4
<b>High Capacity Feeder Tests .....</b>	<b>3-5</b>
Feed Test .....	3-5
Sensor Test .....	3-6
<b>Repair Information .....</b>	<b>4-1</b>
Preparation .....	4-1
Work Notes .....	4-1
<b>Removal and Replacement Procedures .....</b>	<b>4-2</b>
<b>Envelope Feeder .....</b>	<b>4-2</b>
<b>Duplex Unit Assembly .....</b>	<b>4-3</b>
Duplex Cover .....	4-4
Duplex Rear Cover .....	4-5
Duplex Front Cover .....	4-6
Duplex PWB and Bracket .....	4-7
Duplex Wait Clutch .....	4-8
Duplex Drive Assembly .....	4-9
Duplex Exit Sensor .....	4-10
Duplex Exit Gate Solenoid .....	4-11
Exit Roll .....	4-12
Duplex Wait Sensor .....	4-14
Duplex Interlock Switch .....	4-15
Exit Roll Belt .....	4-16
Duplex Pinch Roll .....	4-17
Inner Chute Assembly .....	4-18
<b>Mailbox .....</b>	<b>4-19</b>
Mailbox Left Cover Assembly .....	4-21
Mailbox Front Cover .....	4-22
Mailbox Rear Cover .....	4-24
Mailbox Top Cover .....	4-25
Actuator Cover Assembly .....	4-27
Bin 10 Jam Sensor .....	4-29
BIN 10 Tray Assembly .....	4-30
Mailbox Drive Belt .....	4-32
BIN Trays 1 - 9 Assemblies .....	4-34
Gate Solenoids 1 - 9 .....	4-36
Mailbox Exit Roll and Bin Gate .....	4-38
Mailbox Entrance Sensor .....	4-39

## 4025 Options

IN Gate Solenoid	4-40
Vertical LED/Sensor	4-42
Mailbox Control PWB	4-44
Mailbox Drive Motor	4-46
Full Stack Actuator	4-48
Rear Lower Cover	4-49
IN Gate	4-50
Lower Chute	4-52
Mailbox Interlock Switch	4-53
Transport Guide Assembly	4-54
<b>High Capacity Feeder</b>	<b>4-55</b>
HCF Rear Cover	4-57
HCF Left Cover	4-58
Left Cover Assembly	4-59
Right Cover	4-60
Front Cover BTM	4-61
HCF Feed Motor	4-62
HCF Drive Belt	4-64
HCF PWB	4-66
Lift Motor	4-67
Tray 3 Paper Size Sensor PWB	4-68
Tray 4 and Tray 5 Paper Size Sensor PWBs	4-69
Trays 3, 4, and 5 Feed Clutches	4-70
Trays 3, 4, and 5 No Paper Actuators	4-71
Trays 3, 4, and 5 No Paper Sensors	4-73
Trays 3, 4, and 5 Paper Level Sensors	4-75
Left Cover Interlock Switch	4-77
Tray 3 Take Away Sensor	4-78
Tray 3 Feeder Assembly	4-79
Tray 3 Retard Assembly	4-81
Tray 3 Nudger, Feeder, and Retard Rolls	4-84
Tray 4 Take Away Sensor	4-86
HCF Tray 4	4-87
Tray 4 Front Cover	4-88
Tray 4 Take Away Roll	4-89
Remove Tray 4 Take Away Roll.	4-90
Tray 4 Feeder Assembly	4-92
Tray 4 Retard Assembly	4-94
Tray 4 Feed, Nudger, and Retard Rolls	4-96
Tray 5 Take Away Sensor	4-98
HCF Tray 5	4-99
Tray 5 Front Cover	4-100
Tray 5 Feeder Assembly	4-101

## 4025 Options

Tray 5 Retard Assembly .....	4-103
Tray 5 Feed, Nudger, and Retard Rolls .....	4-105
<b>Connector Locations</b> .....	5-1
<b>Envelope Feeder</b> .....	5-1
Envelope Feeder P/J Location Table .....	5-1
Envelope Feeder P/J Location Map 1 .....	5-2
Envelope Feeder Wiring Diagrams .....	5-2
<b>Duplex</b> .....	5-6
Duplex P/J Location Table .....	5-6
Duplex P/J Location Map 1 .....	5-7
Duplex Wiring Diagrams .....	5-8
<b>Mailbox</b> .....	5-11
Mailbox P/J Location Table .....	5-11
Mailbox P/J Location Map 1 .....	5-12
Mailbox Wiring Diagrams .....	5-13
<b>High Capacity Feeder</b> .....	5-17
High Capacity Feeder P/J Location Table .....	5-17
High Capacity Feeder P/J Location Map 1 .....	5-19
High Capacity Feeder P/J Location Map 2 .....	5-20
High Capacity Feeder Wiring Diagrams .....	5-21
<b>Preventative Maintenance</b> .....	6-1
<b>Parts Catalog</b> .....	7-1
<b>How to Use the Parts Catalog</b> .....	7-1
<b>Assembly 1: Envelope Feeder</b> .....	7-2
<b>Assembly 2: Duplex</b> .....	7-4
<b>Assembly 3: Mailbox</b> .....	7-14
<b>Assembly 4: High Capacity Feeder</b> .....	7-30
<b>Index</b> .....	I-1

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).