

Revised: July 27, 2005

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).



## *Service Manual*

**Lexmark™ T63x**

*(including Lexmark T630, Lexmark T632, Lexmark T634)*

**4060-xxx**

*(including 4060-000, 4060-010, 4060-200,  
4060-210, 4060-400, 4060-410)*

- ***Table of Contents***
- ***Start Diagnostics***
- ***Safety and Notices***
- ***Trademarks***
- ***Index***

**LEXMARK™**

*Lexmark and Lexmark with diamond design are  
trademarks of Lexmark International, Inc., registered  
in the United States and/or other countries.*

**Edition: July 27, 2005**

**The following paragraph does not apply to any country where such provisions are inconsistent with local law:**  
LEXMARK INTERNATIONAL, INC. PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

Comments may be addressed to Lexmark International, Inc., Department D22A/032-2, 740 West New Circle Road, Lexington, Kentucky 40550, U.S.A or e-mail at [ServiceInfoAndTraining@Lexmark.com](mailto:ServiceInfoAndTraining@Lexmark.com). Lexmark may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you. You can purchase additional copies of publications related to this product by calling 1-800-553-9727. In other countries, contact your point of purchase.

Lexmark, Lexmark with diamond design, MarkNet, MarkVision, and *Prebate* are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

ImageQuick, Optra Forms, PrintCryption, and StapleSmart are trademarks of Lexmark International, Inc.

LEXFAX is a service mark of Lexmark International, Inc.

Other trademarks are the property of their respective owners.

**© 2005 Lexmark International, Inc.  
All rights reserved.**

**UNITED STATES GOVERNMENT RIGHTS**

This software and any accompanying documentation provided under this agreement are commercial computer software and documentation developed exclusively at private expense.

# Table of contents

<b>Laser notices</b> .....	<b>ix</b>
<b>Safety information</b> .....	<b>xv</b>
<b>Preface</b> .....	<b>xviii</b>
Definitions .....	xviii
<b>General information</b> .....	<b>1-1</b>
Maintenance approach .....	1-1
Options .....	1-2
Print speed and performance print speed .....	1-3
Performance .....	1-3
Time to first print .....	1-4
Memory configuration .....	1-4
Printer specifications .....	1-5
Dimensions .....	1-5
Operating clearances .....	1-6
Power and electrical specifications .....	1-6
Electrical specifications .....	1-6
Acoustics .....	1-7
Environment .....	1-7
Media specifications .....	1-8
Print area .....	1-12
Media guidelines .....	1-12
Paper .....	1-12
Envelopes .....	1-13
Transparencies .....	1-13
Labels .....	1-13
Tools required .....	1-14
Acronyms .....	1-15
<b>Diagnostic information</b> .....	<b>2-1</b>
Start .....	2-1
Messages and error codes .....	2-2
Service error codes .....	2-2
Sub error codes .....	2-5
Sub error codes for 9xx and 2xx error codes .....	2-5
Base printer sub error codes .....	2-6
Base printer (fuser) sub error codes .....	2-11
Duplex option sub error codes .....	2-12
Envelope feeder sub error codes .....	2-13
User status displays .....	2-14
User status messages .....	2-17
User attendance messages .....	2-19
User line 2 link messages .....	2-32
Check device connection messages .....	2-33

Power-On Self Test (POST) .....	2-34
Symptom tables .....	2-35
Base printer symptoms .....	2-35
High-capacity feeder (2000-sheet) symptoms .....	2-35
Paper tray symptoms .....	2-36
Duplex option symptoms .....	2-36
Envelope feeder symptoms .....	2-36
Output expander .....	2-36
StapleSmart finisher .....	2-37
Service Checks .....	2-38
5-Bin mailbox service check .....	2-38
900 Error Code service check .....	2-41
950 Error Code service check .....	2-42
Charge roll service check .....	2-43
Cover closed switch/cable service check .....	2-44
Dead machine service check .....	2-45
Duplex option service check .....	2-47
Envelope feeder service check .....	2-49
Fuser service checks .....	2-52
Cold fuser service check .....	2-52
Hot fuser service check .....	2-54
Fuser solenoid service check .....	2-55
High-capacity feeder input tray service check .....	2-56
High-capacity output stacker service check .....	2-62
Input sensor service check .....	2-64
Input tray(s) service check .....	2-64
Internal tray card/paper size sensing service check .....	2-66
Main drive service check .....	2-68
Main fan service check .....	2-69
Operator panel service check .....	2-70
Operator panel buttons service check .....	2-70
Operator panel display service check .....	2-70
Options service check .....	2-71
Flash Memory Option(s) .....	2-71
DRAM Memory Option(s) .....	2-71
Hard Disk Option .....	2-71
Output bin sensor standard tray service check .....	2-72
Output expander service check .....	2-72
Paper feed service check .....	2-76
Parallel port service check .....	2-77
Printhead service check .....	2-78
Print quality service check .....	2-78
Smart contact assembly service check .....	2-85
StapleSmart finisher service check .....	2-86
Toner sensor service check .....	2-93
Transfer roll service check .....	2-94

<b>Diagnostic aids</b> .....	<b>3-1</b>
Diagnostics mode .....	3-1
Entering Diagnostic Mode: .....	3-1
Available tests .....	3-1
Exiting Diagnostics Mode .....	3-1
Device tests .....	3-2
Quick Disk Test .....	3-2
Disk Test/Clean .....	3-2
Flash Test .....	3-3
Disabling Download Emulations .....	3-3
Duplex tests .....	3-4
Duplex Quick Test .....	3-4
Duplex Sensor Test .....	3-4
Duplex Motor Test .....	3-5
Duplex Feed 1 Test .....	3-5
Duplex Feed 2 Test .....	3-6
Error log .....	3-6
Viewing the error log .....	3-6
Printing the error log .....	3-7
Clearing the error log .....	3-8
Hardware tests .....	3-8
LCD Test .....	3-8
Button Test .....	3-8
SDRAM Memory Test .....	3-9
ROM Memory Test .....	3-9
Parallel Wrap Test .....	3-9
Input tray tests .....	3-10
Input Tray Feed Test .....	3-10
Input Tray Sensor Test .....	3-10
Output Bin Tests .....	3-11
Output Bin Test—Standard Bin .....	3-11
Output Bin Feed Test .....	3-11
Feed to All Bins Test .....	3-12
Output Bin Sensor Test .....	3-12
Finisher Tests for StapleSmart Finisher .....	3-14
Finisher Feed Tests .....	3-14
Finisher Sensor Tests .....	3-14
Staple Sensor Test .....	3-15
Cover and Door Sensors .....	3-15
Pass and Media Sensors .....	3-15
Bin Level Sensor .....	3-15
Base Sensor Test .....	3-16
Print registration .....	3-16
Printer setup .....	3-17
Setting the page count .....	3-17
Viewing the permanent page count .....	3-17

Maintenance page count	3-17
Setting configuration ID	3-18
Restore EP Factory Defaults	3-18
Print tests	3-19
Print quality test pages	3-20
Printing menu settings page	3-20
Theory	3-21
Autocompensator operation	3-21
Autoconnect system, paper tray options, envelope feeder—electrical	3-21
Autoconnect cabling and connectors	3-21
Duplex Option	3-22
Option microcode	3-22
Paper feed jams	3-22
Paper jams—base printer	3-23
Paper jams—options	3-24
Error Message 23x Paper Jam - Check Duplex Option	3-24
Error Message 24x (x=tray 1 through 5) Paper Jam Check Tray x	3-25
Error Message 250 Paper Jam - Check MP Feeder	3-25
Error Message 260 Paper Jam - Check Envelope Feeder	3-25
Error Message 27x Paper Jam - Check Bin x	3-25
Error Message 28x Paper Jam (x=StapleSmart finisher)	3-25
Error Message 282 - Check Stapler	3-26
Error Message 283 - Check Stapler	3-26
<b>Repair information</b>	<b>4-1</b>
Handling ESD-sensitive parts	4-1
Adjustment procedures	4-2
Duplex motor drive belt adjustment	4-2
Fuser solenoid adjustment	4-2
Gap adjustment	4-3
Printhead assembly adjustment	4-3
Paper alignment assembly adjustment	4-4
Screw identification table	4-6
Removal procedures	4-9
Covers removals	4-9
Left door removal	4-9
Right cover removal	4-10
Upper front cover removal	4-12
Laser cover removal	4-14
Bevel gear removal	4-16
Installation	4-17
Communications board removal	4-18
Cover closed switch/cable removal	4-19
Developer drive assembly removal	4-20
Frames removals	4-20
EP frame assembly	4-20
Left side frame	4-20
Right side frame	4-22
Fuser assembly removal	4-23

Fuser cover removal	4-25
Fuser exit sensor or fuser narrow media sensor removal	4-28
Fuser lamp removal	4-28
Fuser transfer plate removal	4-30
High voltage power supply removal	4-31
Inner paper deflector assembly removal	4-33
Inner shield removal	4-34
Input sensor removal	4-34
Integrated tray autocompensator assembly removal	4-35
Integrated tray autocompensator pick roll assembly removal	4-38
Interconnect board assembly removal	4-40
Internal tray card (ITC)/Paper size sensing board removal	4-41
Low voltage power supply removal	4-42
Main drive assembly removal	4-44
Main fan removal	4-46
Multipurpose tray/lower deflector assembly removal	4-47
Operator panel assembly removal	4-48
Operator panel bezel removal	4-49
Operator panel cable removal	4-50
Optional 250 or 500-sheet paper tray assembly removal	4-51
Paper tray autocompensator assembly removal	4-51
Paper tray frame assembly removal	4-51
Paper tray board removal	4-51
Paper tray paper out sensor flag removal	4-51
Paper size spring comb removal	4-51
Outer shield removal	4-52
Paper alignment assembly removal	4-52
Paper bin full sensor flag assembly removal	4-54
Pick roll removal (MPT)	4-55
Printhead removal	4-56
Redrive assembly removal	4-57
Smart contact assembly removal	4-58
System board removal	4-58
Toner sensor removal	4-61
Transfer roll assembly removal	4-61
Upper front cover hinge assembly removal	4-62
Upper paper deflector assembly removal	4-63
<b>Connector locations</b>	<b>5-1</b>
Autoconnect	5-1
Envelope feeder board	5-2
Fuser Board	5-2
High-capacity output stacker board	5-3
High voltage power supply	5-4
Interconnect board	5-5
Low voltage power supply	5-6
Output expander control board	5-7
StapleSmart finisher	5-8

System board—non-network . . . . .	5-10
System board—network . . . . .	5-11
<b>Preventive maintenance . . . . .</b>	<b>6-1</b>
Safety inspection guide . . . . .	6-1
Lubrication specifications . . . . .	6-1
Scheduled maintenance . . . . .	6-1
<b>Parts catalog . . . . .</b>	<b>7-1</b>
How to use this parts catalog . . . . .	7-1
Assembly 1: Covers . . . . .	7-2
Assembly 2: Frame 1 . . . . .	7-4
Assembly 3: Frame 2 . . . . .	7-6
Assembly 4: Printhead 1 (000/010) . . . . .	7-10
Assembly 5: Printhead 2 (200/210) . . . . .	7-11
Assembly 6: Printhead 3 (400/410) . . . . .	7-12
Assembly 7: Paper feed—autocompensator . . . . .	7-13
Assembly 8: Paper feed—multipurpose feeder . . . . .	7-14
Assembly 9: Paper feed—alignment . . . . .	7-16
Assembly 10: Integrated paper tray—250-sheet . . . . .	7-18
Assembly 11: Integrated paper tray—500-sheet . . . . .	7-20
Assembly 12: Drives—Main drive and developer drive . . . . .	7-22
Assembly 13: Hot roll fuser . . . . .	7-24
Assembly 14: Transfer/charging . . . . .	7-26
Assembly 15: Electronics—power supplies . . . . .	7-28
Assembly 16: Electronics—card assemblies . . . . .	7-30
Assembly 17: Electronics—shields . . . . .	7-32
Assembly 18: Cabling diagrams 1 . . . . .	7-34
Assembly 19: Cabling diagrams 2 . . . . .	7-36
Assembly 20: Cabling diagrams 3 . . . . .	7-38
Assembly 21: 250-sheet paper tray . . . . .	7-40
Assembly 22: 500-sheet paper tray . . . . .	7-44
Assembly 23: Duplex option . . . . .	7-48
Assembly 24: Envelope feeder . . . . .	7-50
Assembly 25: Output expander . . . . .	7-52
Assembly 26: High-capacity output expander . . . . .	7-56
Assembly 27: 5-bin mailbox . . . . .	7-60
Assembly 28: High-capacity feeder 1 . . . . .	7-64
Assembly 29: High-capacity feeder 2 . . . . .	7-66
Assembly 30: High-capacity feeder 3 . . . . .	7-68
Assembly 31: High-capacity feeder 4 . . . . .	7-70
Assembly 32: High-capacity feeder 5 . . . . .	7-72
Assembly 33: Kiosk—vertical paper adapter . . . . .	7-74
Assembly 34: Kiosk—horizontal paper adapter . . . . .	7-76
Assembly 35: StapleSmart finisher 1 . . . . .	7-78
Assembly 36: StapleSmart finisher 2 . . . . .	7-80
Assembly 37: StapleSmart finisher 3 . . . . .	7-82
Assembly 38: StapleSmart finisher 4 . . . . .	7-84
Assembly 39: Options . . . . .	7-86
Assembly 40: Miscellaneous . . . . .	7-88
<b>Index . . . . .</b>	<b>I-1</b>
<b>Part number index . . . . .</b>	<b>I-7</b>

<p>For the complete PDF manual please visit <a href="http://www.LaserPros.com">www.LaserPros.com</a>.</p>
---------------------------------------------------------------------------------------------------------------