

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).



## *Service Manual*

**Lexmark™ T62X**  
**4069-5xx/7xx**

- ***Table of Contents***
- ***Start Diagnostics***
- ***Safety and Notices***
- ***Trademarks***
- ***Index***

**LEXMARK™**

*Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.*

**4069-5XX/7XX**

**Edition: November 2004**

**The following paragraph does not apply to any country where such provisions are inconsistent with local law:** LEXMARK INTERNATIONAL, INC. PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

Comments may be addressed to Lexmark International, Inc., Department D22A/032-2, 740 West New Circle Road, Lexington, Kentucky 40550, U.S.A or e-mail at ServiceInfoAndTraining@Lexmark.com. Lexmark may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you. You can purchase additional copies of publications related to this product by calling 1-800-553-9727. In other countries, contact your point of purchase.

ImageQuick, Optra Forms, PictureGrade and StapleSmart are trademarks of Lexmark International, Inc.

Lexmark and Lexmark with diamond design, Prebate and MarkNet are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

PostScript is a registered trademark of Adobe Systems Incorporated.

PCL is a registered trademark of the Hewlett-Packard Company.

Other trademarks are the property of their respective owners.

**© Copyright Lexmark International, Inc. 2001, 2004.**

**All rights reserved.**

#### **UNITED STATES GOVERNMENT RESTRICTED RIGHTS**

This software and documentation are provided with RESTRICTED RIGHTS. Use, duplication or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 and in applicable FAR provisions: Lexmark International, Inc., Lexington, KY 40550.

**P/N: 12G3959**

# Table of Content

<b>Laser Notices</b> .....	<b>ix</b>
<b>Safety Information</b> .....	<b>xix</b>
<b>Preface</b> .....	<b>xxiv</b>
<b>General Information</b> .....	<b>1-1</b>
Options .....	1-2
Maintenance Approach .....	1-3
Tools Required for Service .....	1-3
Acronyms .....	1-4
<b>Diagnostic Information</b> .....	<b>2-1</b>
Start .....	2-1
Service Error Codes .....	2-2
User Status Screens .....	2-24
User Attendance Messages .....	2-29
Power-On Self Test (POST) .....	2-41
Symptom Tables .....	2-42
Service Checks .....	2-46
Charge Roll Service Check .....	2-47
Cover Open Switch/Cable Service Check .....	2-49
Dead Machine Service Check .....	2-50
Duplex Option Service Check .....	2-53
Envelope Feeder Option Service Check .....	2-56
Fan Service Check .....	2-63
Cold Fuser Service Check .....	2-65
Hot Fuser Service Check .....	2-67
Fuser Solenoid Service Check .....	2-68
Input Sensor Service Check .....	2-68
Input Tray(s) Option Service Check .....	2-69
High-Capacity Feeder Input Tray Service Check .....	2-72
Main Drive Service Check .....	2-85
Operator Panel Service Check .....	2-86
Options Service Check .....	2-88
Output Bin Sensor Standard Tray Service Check .....	2-90
Output Expander Service Check .....	2-91
High-Capacity Output Stacker Service Check .....	2-96
5-Bin Mailbox Service Check .....	2-99
Paper Feed Service Check .....	2-105
Parallel Port Service Check .....	2-107
Printhead Service Check .....	2-108

- Print Quality Service Check .....2-109
- Smart Cartridge Contact Assembly Service Check. ....2-121
- Serial Port Service Check .....2-122
- Toner Sensor Service Check .....2-122
- Transfer Roll Service Check .....2-123
- StapleSmart Finisher Service Check .....2-125
- Diagnostic Aids .....3-1**
  - Diagnostic/Configuration Menu .....3-1
  - Configuration Menu .....3-5
  - Diagnostic Mode .....3-6
    - Exiting the Diagnostics Mode .....3-6
  - Device Tests .....3-6
    - Quick Disk Test .....3-6
    - Disk Test/Clean .....3-6
    - Flash Test .....3-7
    - Disabling Download Emulations .....3-8
  - Duplex Tests .....3-8
    - Duplex Quick Test .....3-8
    - Duplex Sensor Test .....3-9
    - Duplex Motor Test .....3-9
    - Duplex Feed 1 Test .....3-12
    - Duplex Feed 2 Test .....3-12
  - Error Log .....3-13
    - Viewing the Error Log .....3-13
    - Clearing the Error Log .....3-13
  - Hardware Tests .....3-14
    - LCD Test .....3-14
    - Button Test .....3-14
    - SDRAM Memory Test .....3-15
    - ROM Memory Test .....3-15
    - Parallel Wrap Test .....3-16
    - Serial Wrap Test .....3-17
  - Input Tray Tests .....3-19
    - Input Tray Feed Test .....3-19
    - Input Tray Sensor Test .....3-19
  - Output Bin - Feed to all Bins Test .....3-20
  - Output Bin Feed Test .....3-21
  - Output Bin Sensor Test .....3-21
  - Finisher Tests, StapleSmart Finisher Option .....3-24
  - Base Sensor Test .....3-26
    - StapleSmart Finisher Tests .....3-26
    - StapleSmart Finisher Sensor Test .....3-27

5-Bin Mailbox Diverter Test .....	3-28
Registration .....	3-28
Printer Setup .....	3-30
Setting the Page Count .....	3-30
Viewing the Permanent Page Count .....	3-30
Maintenance Page Count .....	3-31
Setting Configuration ID.....	3-31
Restore EP Factory Defaults .....	3-32
Print Tests .....	3-33
Print Quality Test Pages .....	3-34
Printing Menu Settings Page .....	3-36
Auto Compensator Operation .....	3-36
Autoconnect System, Paper Tray Options, Envelope Feeder and Output Expander Operations .....	3-37
Electrical .....	3-37
Fuser Operation .....	3-39
Hot Roll Fuser .....	3-39
Paper Feed Jams .....	3-40
Paper Jams - Base Printer.....	3-40
Paper Jams - Options .....	3-41
<b>Repair Information .....</b>	<b>4-1</b>
Handling ESD-Sensitive Parts .....	4-1
Adjustment Procedures .....	4-2
Duplex Motor Drive Belts .....	4-2
Fuser Solenoid Adjustment .....	4-3
Gap Adjustment.....	4-3
Printhead Assembly Adjustment .....	4-4
Paper Alignment Assembly Adjustment.....	4-5
Screw Identification Table .....	4-7
Removal Procedures .....	4-12
Covers .....	4-12
Center Pan Assembly .....	4-16
System Board .....	4-17
Card Assembly (NAND Flash).....	4-18
.....	4-19
Developer Drive Assembly.....	4-20
Duplex Board.....	4-21
Duplex Front Cover Assembly.....	4-21
Duplex Front Cover Door.....	4-21
Duplex Motor .....	4-22
EMC Shields .....	4-23
Fan.....	4-25

Frames	4-26
Fuser	4-30
Fuser Cover	4-31
Fuser Detack Fingers	4-31
Fuser Detack Housing Assembly	4-32
Fuser Transfer Plate	4-33
Fuser Envelope Conditioner Solenoid	4-34
Fuser Narrow Media Sensor/Flag Assembly	4-35
Fuser Exit Sensor Flag Assembly	4-35
Fuser Lamp	4-35
Fuser Lower Exit Guide Assembly	4-36
High Voltage Power Supply	4-37
Integrated Tray Compensator Assembly	4-37
Integrated Tray Compensator Pick Roll Assembly	4-38
Interconnect Board Assembly	4-40
Low Voltage Power Supply	4-42
Main Drive Assembly	4-43
Main Drive Motor	4-45
Multipurpose Tray/Lower Deflector Assembly	4-46
Operator Panel Assembly	4-48
Operator Panel Cable/Cover Open Switch Assembly	4-49
Optional 250/500 Paper Tray Assembly	4-50
Paper Alignment Assembly	4-51
Paper Deflectors	4-53
Paper Input Sensor	4-54
Paper Size Sensing Board	4-54
Pick Roll	4-54
Printhead (4069-520/52n)	4-55
Printhead (4069-722/72n)	4-56
Redrive Assembly	4-57
Smart Cartridge Contact Assembly	4-58
Toner Sensor	4-59
Transfer Roll Assembly	4-60
Upper Paper Deflector Assembly	4-60
Upper Front Cover Hinge Assembly	4-61
Upper Front Cover Interlock Switch Assembly	4-62
Pick Roller Replacement	4-63
<b>Connector Locations</b>	<b>5-1</b>
Low Voltage Power Supply	5-1
High Voltage Power Supply	5-3
Interconnect Board	5-4
Envelope Option Board	5-7

Duplex Option Board .....	5-9
Autoconnect - Top .....	5-11
Output Expander Control Board .....	5-12
High-Capacity Output Stacker Board .....	5-14
System Board Connector Locations .....	5-16
System Board Connector Locations .....	5-20
StapleSmart Finisher Option - Staple Card Assembly ..	5-27
<b>Cables - Base Machine</b> .....	<b>5-31</b>
Fuser Cable, DC Internal .....	5-31
Autoconnect Cable, (Fuser to LVPS) .....	5-31
Deflector Cable .....	5-31
Fuser Cable, AC EP Autoconnect to Fuser Top Cover ..	5-32
Integrated Tray Cable .....	5-32
HSYNC Cable .....	5-32
Mirror Motor Cable .....	5-33
Main Drive Motor Cable .....	5-33
Laser Cable .....	5-33
Front Harness Cable .....	5-34
Fuser Cable, DC EP Autoconnect to System Board ....	5-34
Autoconnect Cable - System Board to Top/Interconnect Board .....	5-34
Autoconnect Cable - System Board to Front/Bottom/Interconnect Board .....	5-35
<b>Preventive Maintenance</b> .....	<b>6-1</b>
Safety Inspection Guide .....	6-1
Lubrication Specifications .....	6-1
Scheduled Maintenance .....	6-2
<b>Parts Catalog</b> .....	<b>7-1</b>
How to Use this Parts Catalog .....	7-1
Assembly 1: Covers .....	7-2
Assembly 2: Frame .....	7-6
Assembly 3: Printhead .....	7-10
Assembly 4: Paper Feed (Auto compensator) .....	7-12
Assembly 5: Paper Feed - Multipurpose Unit .....	7-14
Assembly 6: Paper Feed - Alignment .....	7-16
Assembly 7: Paper Feed - Output .....	7-18
Assembly 8: Integrated Paper Tray - 500 Sheet .....	7-20
Assembly 9: Main Drive .....	7-22
Assembly 10: Developer Drive .....	7-24
Assembly 11: Hot Roll Fuser .....	7-26
Assembly 12: Transfer .....	7-30
Assembly 13: Charging .....	7-32

Assembly 14: Electronics .....7-34  
Assembly 14: Electronics (continued) .....7-36  
Assembly 14: Electronics (continued) .....7-48  
Assembly 15: 250-Sheet Tray.....7-50  
Assembly 16: 500-Sheet Tray.....7-56  
Assembly 17: Duplex .....7-60  
Assembly 18: Output Expander .....7-66  
Assembly 19: Envelope Feeder .....7-70  
Assembly 20: High-Capacity Feeder.....7-74  
Assembly 21: Kiosk - Vertical Paper Adapter .....7-88  
Assembly 22: Kiosk - Horizontal Paper Adapter .....7-90  
Assembly 23: High-Capacity Output Stacker .....7-92  
Assembly 24: 5-Bin Mailbox .....7-98  
Assembly 25: StapleSmart Finisher .....7-102  
Assembly 26: Options .....7-110  
Assembly 27: Miscellaneous .....7-112  
**Index** ..... I-1

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).