

Revised: July, 27 2005



Service Manual

For the complete PDF manual
please visit www.LaserPros.com.

Lexmark™ C752

5060-2XX

- ***Table of Contents***
- ***Start Diagnostics***
- ***Safety and Notices***
- ***Trademarks***
- ***Index***

LEXMARK™

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

Edition: July 27, 2005

The following paragraph does not apply to any country where such provisions are inconsistent with local law:
LEXMARK INTERNATIONAL, INC. PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

Comments may be addressed to Lexmark International, Inc., Department D22A/032-2, 740 West New Circle Road, Lexington, Kentucky 40550, U.S.A or e-mail at ServiceInfoAndTraining@Lexmark.com. Lexmark may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you. You can purchase additional copies of publications related to this product by calling 1-800-553-9727. In other countries, contact your point of purchase.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user's responsibility.

Lexmark, Lexmark with diamond design, and MarkNet are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

ImageQuick, Optra Forms, and PrintCryption are trademarks of Lexmark International, Inc.

LEXFAX is a service mark of Lexmark International, Inc.

PostScript® is a registered trademark of Adobe Systems Incorporated.

PCL® is a registered trademark of the Hewlett-Packard Company.

Other trademarks are the property of their respective owners.

© 2005 Lexmark International, Inc.
All rights reserved.

UNITED STATES GOVERNMENT RIGHTS

This software and any accompanying documentation provided under this agreement are commercial computer software and documentation developed exclusively at private expense.

Table of contents

| | |
|--|--------------|
| Notices and safety information | xi |
| Laser notice | xi |
| Safety information | xv |
| Preface | xviii |
| Definitions | xviii |
| General information | 1-1 |
| Tools required for service | 1-1 |
| Options and features | 1-2 |
| Printer specifications | 1-4 |
| Print speed and performance print speed | 1-6 |
| Media specifications | 1-10 |
| Web oiler upgrade kit and replacements | 1-15 |
| Acronyms | 1-16 |
| Diagnostic information | 2-1 |
| Start | 2-1 |
| POR (Power-On Reset) sequence | 2-2 |
| Symptom tables | 2-3 |
| Symptom table - base printer | 2-3 |
| Symptom table - 500-sheet drawer option | 2-4 |
| Symptom table - HCIT 2000-sheet option | 2-4 |
| Symptom table - output expander option | 2-4 |
| Symptom table - 5-bin mailbox option | 2-5 |
| Symptom table - finisher (HCOF) option | 2-5 |
| Error code table | 2-6 |
| 9xx service errors | 2-6 |
| 1xx service errors | 2-8 |
| Programming errors - P101 through P116 | 2-14 |
| 2xx Paper Jams | 2-15 |
| Sub error code table | 2-18 |
| Understanding the printer operator panel | 2-21 |
| Operator panel buttons | 2-21 |
| Color Menu | 2-23 |
| Utilities Menu | 2-25 |
| User attendance messages | 2-27 |
| Service checks | 2-41 |
| 100 ITU Error | 2-41 |
| 104 ITU Error | 2-44 |
| 120 error code | 2-45 |
| 121 error code | 2-46 |
| 122 error code | 2-46 |
| 123 error code | 2-46 |
| 124 error code | 2-47 |
| 125 error code | 2-47 |
| 126 error code | 2-48 |
| 127 error code | 2-48 |
| 128 error code | 2-49 |
| 129 error code | 2-49 |
| 130 error code | 2-50 |

| | |
|--|-------|
| 131 error code | 2-51 |
| 132 error code | 2-52 |
| 133 error code | 2-53 |
| 134 error code | 2-54 |
| 135 error code | 2-54 |
| 136 error code | 2-55 |
| 148 error code | 2-56 |
| 150 error code | 2-57 |
| 151 error code | 2-57 |
| 152 error code | 2-58 |
| 153 error code | 2-59 |
| 154 error code | 2-60 |
| 156 error code | 2-61 |
| 157 error code | 2-61 |
| 158 error code | 2-62 |
| 159 error code | 2-63 |
| 160 error code | 2-63 |
| 162 error code | 2-64 |
| 163 error code | 2-64 |
| 164 error code | 2-64 |
| 165 error code | 2-65 |
| 200 Paper Jam—Tray 1 | 2-65 |
| 200 Paper Jam—Options and multipurpose feeder | 2-68 |
| 201 Paper Jam | 2-69 |
| 202 Paper Jam | 2-70 |
| 230 Paper Jam | 2-72 |
| 24x Paper jam | 2-73 |
| 250 Paper Jam | 2-77 |
| 271 Paper Jam - check bin 1 | 2-79 |
| 272 Paper Jam - check bin x | 2-80 |
| 280 Paper Jam | 2-81 |
| 900 RIP Software Error | 2-82 |
| 925 error code | 2-84 |
| 926 error code | 2-84 |
| 927 error code | 2-85 |
| 930 error code | 2-85 |
| 940 error code | 2-86 |
| 941 error code | 2-88 |
| 942 error code | 2-90 |
| 943 error code | 2-92 |
| 990 service error | 2-94 |
| 5-bin mailbox option service check | 2-96 |
| 500-sheet drawer option service check | 2-100 |
| AC and DC power service check | 2-104 |
| Autocompensator service check | 2-106 |
| Black only retract (BOR) service check | 2-108 |
| Close door/HVPS/printhead interlock switch service check | 2-109 |
| Duplex option service check | 2-111 |
| Envelope feeder option service check | 2-112 |
| Finisher service check | 2-114 |
| HCIT 2000-sheet option service check | 2-118 |
| Fuser drive assembly noise check | 2-121 |
| Operator panel LCD/status LED/buttons service check | 2-122 |
| Output expander option service check | 2-124 |
| Print quality service check | 2-127 |

| | |
|--|-------------|
| Blank page (no image) | 2-127 |
| Entire page is mostly one color—Full bleed planes in one color | 2-128 |
| Missing colors—Complete or partially missing color planes | 2-129 |
| Black and white only—cyan, magenta, and yellow are missing | 2-130 |
| Light print over the entire page | 2-130 |
| Vertical lines or streaks | 2-131 |
| Horizontal lines or streaks | 2-132 |
| Low image density | 2-132 |
| Poor color alignment | 2-133 |
| Transparency print quality is poor | 2-134 |
| Negative ghosting or faded image | 2-134 |
| Residual image | 2-135 |
| Uneven printing | 2-135 |
| Toner smears or rubs off the page with no error code displayed | 2-135 |
| Smudged or distorted images on fused page | 2-136 |
| Toner is on the back of the printed page | 2-136 |
| Light lines or streaks appear on the page | 2-137 |
| White streak in color plane | 2-137 |
| Paper wrapped around the second transfer roll | 2-138 |
| Second transfer roll service check | 2-138 |
| Tray 1 service check | 2-140 |
| Tray 1 paper size sensing service check | 2-141 |
| Diagnostic aids | 3-1 |
| Diagnostic aids | 3-1 |
| Printhead diagnostics | 3-1 |
| Print quality defect locator chart | 3-4 |
| Partial Print Test | 3-6 |
| Configuration Menu | 3-8 |
| ITU Count Value | 3-8 |
| Fuser Cnt Value | 3-8 |
| Reset Fuser Cnt | 3-9 |
| Prt Quality Pgs | 3-9 |
| Color Trapping | 3-9 |
| Tray Insert Msg | 3-9 |
| Size Sensing | 3-9 |
| Panel Menus | 3-10 |
| PPDS Emulation | 3-10 |
| Demo Mode | 3-10 |
| Factory Defaults | 3-10 |
| Energy Conserve | 3-10 |
| Auto Color Adjust | 3-11 |
| Error Log | 3-11 |
| Font Sharpening | 3-11 |
| Paper Prompts | 3-12 |
| Env Prompts | 3-12 |
| Exit configuration menu | 3-12 |
| Diagnostics Mode | 3-13 |
| Entering Diagnostics Mode | 3-13 |
| Exiting the Diagnostics Mode | 3-13 |
| Registration | 3-14 |
| Alignment Menu | 3-15 |
| Cyan, Yellow, Magenta | 3-15 |
| Drift Sensor Check | 3-16 |
| Top Fine Margin Adj | 3-16 |

| | |
|--|------|
| Misc Tests | 3-17 |
| Motor Detect | 3-17 |
| Toggle ITU | 3-17 |
| Belt Tracking (ITU 4th point adjustment) | 3-18 |
| Printhead Inst | 3-18 |
| Print Tests | 3-19 |
| Print Tests (Input Source) | 3-19 |
| Print Quality Pgs | 3-19 |
| Hardware Tests | 3-20 |
| LCD Test | 3-20 |
| Button Test | 3-20 |
| DRAM Test | 3-21 |
| Cache Test | 3-21 |
| ROM Test | 3-22 |
| Parallel Wrap Test | 3-22 |
| Serial Wrap Test | 3-23 |
| Duplex Tests | 3-24 |
| Duplex Quick Test | 3-24 |
| Duplex Top Margin Offset | 3-24 |
| Duplex Sensor Test | 3-24 |
| Input Tray Tests | 3-25 |
| Feed Test | 3-25 |
| Sensor Test | 3-25 |
| Output Bin Tests | 3-26 |
| Feed Test | 3-26 |
| Feed to All Bins | 3-26 |
| Sensor Test | 3-27 |
| Diverter Test | 3-27 |
| Finisher Tests | 3-28 |
| Staple Test | 3-28 |
| Finisher Feed Test | 3-28 |
| Finisher Sensor Test | 3-28 |
| Hole Punch Test | 3-29 |
| Base Sensor Test | 3-30 |
| Device Tests | 3-30 |
| Quick Disk Test | 3-30 |
| Disk Test/Clean | 3-30 |
| Flash Test | 3-31 |
| Error Log | 3-31 |
| Viewing the error log | 3-31 |
| Clearing the error log | 3-31 |
| Printing the error log | 3-32 |
| Printer Setup | 3-33 |
| Defaults | 3-33 |
| Page Counts | 3-33 |
| Serial Number | 3-34 |
| Engine Setting x | 3-34 |
| Model Name | 3-34 |
| Configuration ID | 3-34 |
| Reset Calibration | 3-34 |
| Edge to Edge | 3-35 |
| Cal Ref Adj | 3-35 |

| | |
|---|-------------|
| EP Setup | 3-35 |
| EP Defaults | 3-35 |
| Fuser Temp | 3-35 |
| DC Charge Adjustment | 3-35 |
| Dev Bias Adj | 3-35 |
| Transfer Adjust | 3-35 |
| HCIT standalone test mode | 3-36 |
| Repair information | 4-1 |
| Handling ESD-sensitive parts | 4-1 |
| Screw identification table | 4-2 |
| Removal procedures | 4-6 |
| Top cover assembly | 4-6 |
| Rear cover | 4-9 |
| Front right handle cover assembly | 4-11 |
| Front left handle cover assembly | 4-12 |
| Front cover assembly | 4-12 |
| Front lower right cover | 4-14 |
| Lower right door assembly | 4-15 |
| Left lower cover | 4-15 |
| Lower jam access door assembly | 4-16 |
| Redrive door | 4-16 |
| Paper path access door cover | 4-17 |
| Front lower left cover | 4-18 |
| Autocompensator pick assembly | 4-19 |
| BOR drive assembly | 4-27 |
| Cartridge contact assembly | 4-28 |
| Cartridge drive assembly | 4-29 |
| Developer HVPS board | 4-30 |
| Friction buckler | 4-31 |
| Fuser assembly | 4-32 |
| Fuser bottom duct | 4-33 |
| Fuser drive assembly | 4-33 |
| Fuser drive card assembly | 4-34 |
| Fuser fan | 4-34 |
| Fuser top duct | 4-35 |
| Fuser web oiler motor assembly and card | 4-36 |
| Inner system board shield | 4-39 |
| ITU assembly | 4-40 |
| ITU drive assembly | 4-40 |
| ITU drive motor | 4-41 |
| LVPS assembly | 4-42 |
| Multipurpose feeder (MPF) | 4-44 |
| Nip relief handle | 4-46 |
| Operator panel | 4-49 |
| Outer system board shield | 4-50 |
| Paper size sensing assembly | 4-51 |
| Paper size sensing board | 4-53 |
| Pick rolls | 4-54 |
| Printhead removal and adjustments | 4-55 |
| Identifying the printheads | 4-55 |
| Printhead mechanical alignment | 4-56 |
| Printhead electronic alignment | 4-59 |
| Rear bellcrank (cyan, magenta, yellow) | 4-59 |
| Rear bellcrank (black) | 4-61 |

| | |
|---|------------|
| Redrive assembly | 4-63 |
| Registration motor | 4-64 |
| RIP fan | 4-64 |
| S2/narrow media/transparency/multipurpose feeder cable | 4-65 |
| S2/narrow media/transparency/multipurpose feeder sensors | 4-66 |
| Second transfer roll | 4-66 |
| System board | 4-67 |
| Transfer HVPS board | 4-68 |
| Transfer plate assembly | 4-70 |
| Vacuum transport belt (VTB) | 4-71 |
| Vacuum transport belt (VTB) fan | 4-73 |
| Waste container door | 4-73 |
| Waste container latch | 4-74 |
| Web oiler fuser kit installation | 4-74 |
| Connector locations | 5-1 |
| Locations | 5-1 |
| Printer boards | 5-1 |
| Printer motors | 5-2 |
| Printer sensors | 5-3 |
| Cartridge contact assembly pin locations (cyan, magenta and yellow) | 5-4 |
| Cartridge contact assembly pin locations (black) | 5-5 |
| Connectors | 5-6 |
| System board - non-network | 5-6 |
| System board - network | 5-7 |
| Autoconnect—top | 5-18 |
| Autoconnect—bottom | 5-19 |
| Transfer high voltage power supply (HVPS) | 5-20 |
| Developer high voltage power supply (HVPS) board | 5-22 |
| Low voltage power supply (LVPS) | 5-23 |
| LVPS cable connectors to system board | 5-23 |
| LVPS fuser connectors | 5-24 |
| Paper size sensing board | 5-25 |
| High-capacity input tray (HCIT) | 5-26 |
| High-capacity output finisher (HCOF) | 5-28 |
| HCOF system board | 5-28 |
| HCOF LVPS board | 5-32 |
| HCOF sub LVPS relay board | 5-32 |
| Preventive maintenance | 6-1 |
| Safety inspection guide | 6-1 |
| Lubrication specifications | 6-1 |
| Lubrication for replacement motors | 6-2 |
| Fuser drive assembly | 6-2 |
| Cartridge drive assembly | 6-3 |
| ITU drive assembly | 6-3 |
| Scheduled maintenance | 6-4 |
| Standard fusers | 6-4 |
| Web oiler fusers | 6-4 |

| | |
|---|------------|
| Parts catalog | 7-1 |
| How to use this parts catalog | 7-1 |
| Assembly 1: Covers | 7-2 |
| Assembly 2: Cartridge mounting | 7-6 |
| Assembly 3: Fuser assembly | 7-7 |
| Assembly 4: Fuser drive | 7-10 |
| Assembly 5: Vacuum transport belt (VTB) assembly | 7-11 |
| Assembly 6: Transfer | 7-12 |
| Assembly 7: Printheads | 7-13 |
| Assembly 8: Paper feed output (redrive) | 7-14 |
| Assembly 9: Paper feed input | 7-15 |
| Assembly 10: Paper size sensing | 7-16 |
| Assembly 11: Paper feed transport | 7-17 |
| Assembly 12: Multipurpose feeder (MPF) | 7-18 |
| Assembly 13: 500-Sheet integrated tray | 7-20 |
| Assembly 14: Autocompensator assembly | 7-21 |
| Assembly 15: ITU assembly | 7-22 |
| Assembly 16: ITU drive assembly | 7-23 |
| Assembly 17: ITU loading | 7-24 |
| Assembly 18: Waste toner | 7-26 |
| Assembly 19: BOR drive assembly | 7-27 |
| Assembly 20: Cartridge contact assembly | 7-28 |
| Assembly 21: Cartridge drive assembly | 7-29 |
| Assembly 22: Electronics | 7-30 |
| Assembly 23: Electronics—cabling interconnections 1 | 7-36 |
| Assembly 24: Electronics—cabling interconnections 2 | 7-38 |
| Assembly 25: Electronics—cabling interconnections 3 | 7-40 |
| Assembly 26: Electronics—cabling interconnections 4 | 7-41 |
| Assembly 27: Output expander | 7-42 |
| Assembly 28: 5-Bin mailbox | 7-46 |
| Assembly 29: 500-Sheet tray option | 7-50 |
| Assembly 30: Duplex option | 7-54 |
| Assembly 31: High-capacity input tray (HCIT) | 7-58 |
| Assembly 32: Finisher | 7-62 |
| Assembly 33: Finisher cables | 7-68 |
| Assembly 34: Envelope option | 7-70 |
| Assembly 35: Options | 7-72 |
| Assembly 36: Miscellaneous | 7-74 |
| Appendix A—Service tips | A-1 |
| Printhead diagnostics | A-1 |
| Identifying the printheads | A-4 |
| Redrive belt routing | A-5 |
| Finisher alignment | A-6 |
| Duplex option deflector button replacement | A-13 |

Appendix B—Print quality samples. B-1

- Print Menus—Page one of two B-1**
 - Print Menus—Page two of two. B-2
- Print tests B-3**
 - Print Quality Pages—Title page (total of five) B-3
 - Print Quality Pages—Page 1 (total of five) B-4
 - Print Quality Pages—Page 2 (total of five) B-5
 - Print Quality Pages—Page 3 (total of five) B-6
 - Print Quality Pages—Page 4 (total of five) B-7
- Registration. B-8**
 - Quick Test B-8
- Miscellaneous test pages B-9**
 - Printhead mechanical alignment test page B-9
 - Printhead electronic alignment test page—Magenta (one of two) B-10
 - Printhead electronic alignment test page—Cyan (two of two) B-11

Index. I-1

Part number index. I-7

For the complete PDF manual
please visit www.LaserPros.com.