

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).



i n v e n t

**service**

**hp** color LaserJet 9500n  
**hp** color LaserJet 9500hdn



hp color LaserJet 9500 series printer

**service** \_\_\_\_\_

© Copyright 2003  
Hewlett-Packard Development  
Company, LP

Reproduction, adaptation, or  
translation without prior written  
permission is prohibited, except  
as allowed under the copyright  
laws.

The information contained herein  
is subject to change without  
notice.

The only warranties for HP  
products and services are set  
forth in the express warranty  
statements accompanying such  
products and services. Nothing  
herein should be construed as  
constituting an additional  
warranty. HP shall not be liable  
for technical or editorial errors or  
omissions contained herein.

Part number: C8546-90956

Edition 1, 9/2003

## Trademark Credits

Adobe® and PostScript® are  
trademarks of Adobe Systems  
Incorporated.

Microsoft®, MS-DOS®, and  
Windows® are U.S. registered  
trademarks of Microsoft  
Corporation.

TrueType™ is a U.S. trademark  
of Apple Computer, Inc.

UNIX® is a registered trademark  
of The Open Group.

Energy Star® is a U.S. registered  
service mark of the United States  
Environmental Protection  
Agency.



## 1 Product information

Product features	20
Product specifications	22
Identification	22
Specifications	22
Environmental specifications	23
Product overview	25
External assembly locations	25
Accessories	26
Space requirements	27
Printer with packaging	27
Printer physical dimensions	28
Setup	30
Media specifications	31
Guidelines for selecting media	31
Supported media and capacity for input and output	32
Recommended media	33
Special media specifications	35
Storing print media	39
Testing media specifications	39
Media assessment tools and suppliers	44

## 2 Service approach

Service approach	46
Parts and supplies	47
Ordering parts	47
Ordering supplies	47
Exchange program	47
Supplies	47
World Wide Web	47
HP service parts information compact disc	48
Customer care reseller sales and service support center	48
Ordering related documentation and software	49
Warranty	50
Limited warranty for print cartridge and image drum life	50
Transfer unit and fuser warranty	50
HP maintenance agreements	50
Onsite service agreements	51

## 3 Product configuration

Control panel layout	54
Control panel menus	56
Menu map	56
Using a menu map	56
Retrieve job menu	57
Information menu	58
Paper handling menu	59
Selecting media for a document	60
Configure device menu	61
Printing submenu	61
Print Quality submenu	64
System Setup submenu	69
Output Setup submenu	71
I/O submenu	71
Resets submenu	74
Diagnostics menu	75
Service menu	79

Service ID . . . . .	79
Restoring the Service ID . . . . .	80
Converting the Service ID to an actual date . . . . .	80
Settings and defaults . . . . .	81
Configure the control panel display language . . . . .	81
Configure the input trays . . . . .	82
Boot key sequences . . . . .	86
Hard disk reinitialization . . . . .	86
NVRAM initialization . . . . .	87
Cold reset. . . . .	89

## 4 Product maintenance

Preventative maintenance . . . . .	92
Image transfer kit . . . . .	92
Image cleaning kit . . . . .	92
Image fuser kit . . . . .	92
Cleaning the printer and accessories . . . . .	93
General cleaning . . . . .	93
Cleaning spilled toner . . . . .	93
Vacuum specifications . . . . .	93
First aid measures . . . . .	93
Cleaning procedures . . . . .	94
Cleaning the post charger . . . . .	94
Cleaning the separation guide, feed guide, and front fuser guide . . . . .	94
Cleaning the fuser input . . . . .	94
Cleaning the registration roller unit . . . . .	95
Cleaning the other rollers . . . . .	95
Cleaning the tray 1 separation pad . . . . .	95
Print cartridges . . . . .	96
Non-HP print cartridges and image drums . . . . .	96
Authenticating print cartridges . . . . .	96
Storing print cartridges . . . . .	97
Image drums . . . . .	98
Storing image drums . . . . .	98
Firmware upgrades . . . . .	99
Downloading the new firmware from the HP Web site . . . . .	99
Downloading the new firmware to the printer . . . . .	99
Remote firmware update through a local Windows port . . . . .	99

## 5 Theory of operation

Basic operation . . . . .	108
Major printer systems . . . . .	108
Printer block diagram . . . . .	109
Sequence of operation . . . . .	110
Timing charts . . . . .	112
Wiring diagrams . . . . .	114
Flat flexible cable signals . . . . .	118
Connector location . . . . .	126
Engine-control system . . . . .	130
DC controller circuit . . . . .	131
DC controller operations . . . . .	134
T driver circuit . . . . .	135
Fuser control circuit . . . . .	136
Low-voltage power supply . . . . .	137
High-voltage power supply circuits . . . . .	138
Post charger power supply unit . . . . .	138
Motors and fans . . . . .	139
Switches, solenoids, clutches, and sensors . . . . .	142

Formatter . . . . .	146
DIMM slots . . . . .	146
Formatter heartbeat LED . . . . .	147
Laser/scanner system . . . . .	148
Dual-beam method . . . . .	149
Laser control . . . . .	150
Scanner-motor control . . . . .	154
Color plane registration calibration control . . . . .	155
Image formation system . . . . .	158
Electrophotographic process . . . . .	158
Image stabilization control . . . . .	166
Paper-path system . . . . .	169
Pickup/feed unit . . . . .	171
Jam detection . . . . .	178

## 6 Removal and replacement

Introduction . . . . .	183
Removal and replacement strategy . . . . .	183
General cautions during removal and replacement . . . . .	183
Electrostatic discharge . . . . .	183
Required tools . . . . .	184
Flat flexible cable caution . . . . .	185
DC controller and cable/connector damage areas . . . . .	186
Potential damage areas while servicing . . . . .	186
Consumables . . . . .	187
Toner cartridges (print cartridges) . . . . .	187
Process cartridges (image drums) . . . . .	189
Waste toner bottle (toner collection bottle) . . . . .	191
Transfer cleaner (cleaning blade) . . . . .	192
Transfer roller . . . . .	193
External covers . . . . .	194
Control panel overlay . . . . .	194
Control panel . . . . .	195
Right upper cover . . . . .	196
Left upper cover . . . . .	198
Top right cover . . . . .	199
Top left cover . . . . .	201
Front doors . . . . .	203
Fuser door . . . . .	204
Intermediate transfer belt (ITB) door . . . . .	206
Left back cover . . . . .	210
Left lower cover . . . . .	211
Right back cover . . . . .	213
Back cover . . . . .	214
Major assemblies . . . . .	215
Process cartridge (image drum) door . . . . .	215
Laser/scanner assembly . . . . .	217
Printing a laser/scanner adjustment page . . . . .	219
Reading a laser/scanner adjustment page . . . . .	221
Adjusting the laser/scanner assemblies . . . . .	223
Delivery unit . . . . .	235
Delivery unit sensor . . . . .	239
Vertical feed unit . . . . .	240
Duplexer . . . . .	244
Fuser . . . . .	245
Intermediate transfer belt (ITB) . . . . .	246
Density and registration sensor assembly . . . . .	248
Right back fan . . . . .	251

Right front fan . . . . .	252
Secondary transfer assembly (T2) . . . . .	253
Pickup unit . . . . .	258
Temperature and humidity sensor . . . . .	266
High-voltage power supply . . . . .	267
Low-voltage power supply . . . . .	268
Registration assembly . . . . .	269
Delivery fan . . . . .	276
Fuser fan . . . . .	277
P-crg (image drum) drive assembly . . . . .	278
T-crg (print cartridge) drive assembly . . . . .	282
Fuser motor . . . . .	284
Fuser drive assembly . . . . .	285
DC controller . . . . .	286
Formatter PCB . . . . .	288
Formatter cage . . . . .	289
High-voltage contact . . . . .	291
Post charger power supply . . . . .	292
Tray 1 pickup roller . . . . .	294
Tray 1 separation pad . . . . .	295
Left door switch . . . . .	296
Right door switch (front and right side doors) . . . . .	297
ITB sensor . . . . .	298
Upper left door sensor . . . . .	299
Fuser front paper sensor . . . . .	300
Fuser sensor PCA . . . . .	301

## 7 Troubleshooting

Introduction . . . . .	306
Troubleshooting process . . . . .	306
Pre-troubleshooting checklist . . . . .	306
Power checks . . . . .	308
Control panel checks . . . . .	308
Troubleshooting tools and procedures . . . . .	309
Hardware and electrical troubleshooting tools . . . . .	309
Image formation and print-quality troubleshooting tools . . . . .	330
Sample defects and solutions . . . . .	336
Media and paper-path troubleshooting tools . . . . .	373
Tests for troubleshooting paper-path problems . . . . .	383
Noise troubleshooting tools . . . . .	384
Control panel messages . . . . .	385
Control panel and event log message format . . . . .	386
Event log page . . . . .	386
Error message interpretation . . . . .	389
Data and communication troubleshooting tools . . . . .	435
Tray 4 troubleshooting tools . . . . .	438

## 8 Parts and diagrams

Introduction . . . . .	443
Ordering parts . . . . .	443
Kits, supplies, accessories, exchange parts, and documentation . . . . .	445
Hardware identification . . . . .	447
Illustrations and parts lists . . . . .	448
External covers and panels . . . . .	448
Left cover assembly . . . . .	452
Right door assembly . . . . .	453
Internal components (1 of 9) . . . . .	454
Internal components (2 of 9) . . . . .	456

Internal components (3 of 9) . . . . .	458
Internal components (4 of 9) . . . . .	460
Internal components (5 of 9) . . . . .	462
Internal components (6 of 9) . . . . .	464
Internal components (7 of 9) . . . . .	466
Internal components (8 of 9) . . . . .	468
Internal components (9 of 9) . . . . .	470
Registration drive assembly . . . . .	472
Process cartridge drive assembly (image drum drive) . . . . .	473
Toner cartridge drive assembly (print cartridge drive) . . . . .	474
Fuser drive assembly . . . . .	476
Cassette assembly . . . . .	478
Paper pickup assembly (1 of 3) . . . . .	480
Paper pickup assembly (2 of 3) . . . . .	482
Paper pickup assembly (3 of 3) . . . . .	484
Manual feed pickup assembly (tray 1) (1 of 2) . . . . .	486
Manual feed pickup assembly (tray 1) (2 of 2) . . . . .	488
Registration assembly . . . . .	490
Secondary transfer assembly (T2) (1 of 2) . . . . .	492
Secondary transfer assembly (T2) (2 of 2) . . . . .	494
Delivery feed assembly. . . . .	495
Face down delivery assembly. . . . .	496
Delivery cover assembly. . . . .	497
Fuser assembly . . . . .	498
PCB assemblies . . . . .	499
Tray 4 . . . . .	500
Tray 4 main body . . . . .	500
Tray 4 drive assembly. . . . .	504
Tray 4 PCA location . . . . .	505
Master parts lists . . . . .	506
Alphabetical parts list . . . . .	506
Numerical parts list . . . . .	512

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).