

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).



# HP LaserJet 4000 and 4050 Series Printers Service Manual

HP LaserJet 4000 and 4050  
Series Printers

**Service Manual** \_\_\_\_\_

**© Copyright Hewlett-Packard  
Company 1999**

All Rights Reserved.  
Reproduction, adaptation, or  
translation without prior written  
permission is prohibited, except  
as allowed under the copyright  
laws.

Publication number  
C4251-91003

First edition, April 1999

**Warranty**

The information contained in  
this document is subject to  
change without notice.

Hewlett-Packard makes no  
warranty of any kind with  
respect to this information.  
HEWLETT-PACKARD  
SPECIFICALLY DISCLAIMS  
THE IMPLIED WARRANTY OF  
MERCHANTABILITY AND  
FITNESS FOR A PARTICULAR  
PURPOSE.

Hewlett-Packard shall not be  
liable for any direct, indirect,  
incidental, consequential, or  
other damage alleged in  
connection with the furnishing or  
use of this information.

**Trademark Credits**

PostScript™ is a trademark of  
Adobe Systems Incorporated  
which may be registered in  
certain jurisdictions.

CompuServe™ is a U.S.  
trademark of CompuServe, Inc.

Windows® is a U.S. registered  
trademarks of Microsoft  
Corporation.

TrueType™ is a U.S. trademark  
of Apple Computer, Inc.

ENERGY STAR® is a U.S.  
registered service mark of the  
U.S. EPA.

# Contents

## 1 Printer Description

Overview . . . . .	1-1
Printer Features . . . . .	1-2
Identification . . . . .	1-8
Model and Serial Numbers . . . . .	1-8
Site Requirements . . . . .	1-9
Space Requirements . . . . .	1-10
Environmental Requirements . . . . .	1-11
Paper Specifications . . . . .	1-12
Supported Types of Paper . . . . .	1-15
Guidelines for Using Paper . . . . .	1-16
Labels . . . . .	1-19
Transparencies . . . . .	1-19
Envelopes . . . . .	1-20
Card Stock and Heavy Paper . . . . .	1-23
Safety Information . . . . .	1-24
Laser Safety Statement . . . . .	1-24
Canadian DOC Regulations . . . . .	1-24
FCC Regulations . . . . .	1-25
Laser Statement for Finland . . . . .	1-26
Toner Safety . . . . .	1-27
Environmental Product Stewardship . . . . .	1-28

## 2 Service Approach

Overview . . . . .	2-1
Service Approach . . . . .	2-2
Parts and Supplies . . . . .	2-3
Ordering Information . . . . .	2-3
Helpful Documentation . . . . .	2-4
Phone Numbers for Ordering . . . . .	2-6
Exchange Program . . . . .	2-6
Consumables . . . . .	2-6
World Wide Web . . . . .	2-6
HP Service Parts Information Compact Disc . . . . .	2-6
HP Support Assistant Compact Disc . . . . .	2-7
HP FIRST . . . . .	2-7
Toner Cartridge Information . . . . .	2-9
Warranty Statement . . . . .	2-10

### 3 Printer Operation

Overview . . . . .	3-1
Using the Control Panel . . . . .	3-2
Control Panel Layout . . . . .	3-2
Control Panel Lights. . . . .	3-2
Control Panel Keys . . . . .	3-3
Settings and Defaults. . . . .	3-4
Control Panel Menus . . . . .	3-5
Quick Copy Jobs Menu . . . . .	3-6
Private/Stored Jobs Menu . . . . .	3-7
Information Menu. . . . .	3-8
Paper Handling Menu . . . . .	3-9
Print Quality Menu . . . . .	3-12
Printing Menu. . . . .	3-15
Configuration Menu . . . . .	3-20
I/O Menu . . . . .	3-26
EIO Menu (Networked Printers). . . . .	3-29
Resets Menu . . . . .	3-31
Service Mode . . . . .	3-32
Service Menu. . . . .	3-33
Setting the Page Count, Maintenance Count, and Serial Number. . . . .	3-33
Cold Reset Paper. . . . .	3-36
Diagnostics . . . . .	3-36
Clear Event Log. . . . .	3-36
Testing the Printer . . . . .	3-37
Resetting the Printer. . . . .	3-38
System Configuration . . . . .	3-39
MS-DOS System Configuration . . . . .	3-39
Parallel DOS Commands. . . . .	3-39
Serial MS-DOS Commands. . . . .	3-40
Printer I/O Configuration. . . . .	3-41
Parallel Menu. . . . .	3-41
Serial Configuration . . . . .	3-41

### 4 Printer Maintenance

Overview . . . . .	4-1
Cleaning the Printer and Accessories . . . . .	4-2
Cleaning Spilled Toner. . . . .	4-4
Preventative Maintenance . . . . .	4-5
Reset Maintenance Count . . . . .	4-5
Expected Life of Components . . . . .	4-6

## 5 Functional Information

Overview	5-1
Power Supply System	5-2
AC/DC Power Distribution	5-2
Overcurrent Overvoltage Protection	5-3
High-voltage Power Distribution	5-4
Toner Cartridge Detection	5-5
Engine Controller System	5-6
Engine Controller Board Inputs and Outputs	5-8
Laser and Scanner Drive	5-12
Paper Motion Monitoring and Control	5-12
Solenoids, Sensors, Clutches, and Switches	5-12
Engine Test Print	5-12
Motors	5-13
Formatter System	5-15
PowerSave	5-15
Resolution Enhancement technology (REt)	5-16
EconoMode	5-16
Input/Output	5-17
CPU	5-18
Printer Memory	5-18
Random Access Memory (RAM)	5-19
DIMM Slots	5-19
Page Protect	5-20
PJM Overview	5-20
PML	5-21
Control Panel	5-21
Image Formation System	5-22
Toner Cartridge	5-24
Photosensitive Drum	5-25
Writing the Image	5-28
Developing the Image	5-29
Transferring the Image	5-30
Image Fusing/Variable Fusing Temperature	5-31
Paper Feed System	5-33
Clutches and Sensors	5-35
Printing from Tray 1	5-36
Printing from Tray 2	5-38
Printing from the Optional 500-sheet	
Universal Tray	5-41
Envelope Feeder	5-44
Duplexer	5-46
Paper Jam	5-48
Basic Sequence of Operation	5-49

## 6 Removing and Replacing Parts

Overview	6-1
Removal and Replacement Strategy	6-2
Tools	6-3
Removing Covers	6-6
Rear Right Side Cover	6-6
Top Cover	6-7
Left Side Cover	6-12
Front Right Side Cover	6-13
Rear Cover/Rear Output Bin	6-14
Tray 1	6-15
Removing Assemblies	6-18
Fuser	6-18
Formatter Cage Assembly	6-20
Output Assembly	6-21
Laser Scanner	6-23
Fan	6-24
Main Motor	6-25
Transfer Roller	6-26
Tray 1 Pickup Roller	6-27
Tray 1 Pickup Assembly	6-29
Right Side Toner Cartridge Guide	6-33
Registration Assembly	6-34
Paper Feed Assembly	6-36
Formatter Pan	6-39
Gear Train	6-40
Delivery Drive Assembly	6-41
Separating the Engine Module from the Paper Feed Module	6-42
Engine Controller Board	6-44
Paper Feed Rollers	6-48
Separation Rollers	6-49
Paper Feed Module Plate	6-50
Paper Feed Module Gear Train Assembly	6-51
Paper Feed Module Side Rails	6-52
Lower Paper Feed Module Plate (HP LaserJet 4000 T/4000 TN and 4050 T/4050 TN)	6-53
PCA Cover (HP LaserJet 4000 T/4000 TN and 4050 T/4050 TN)	6-54
PCA Cover (HP LaserJet 4000/4000 N and 4050/4050 N)	6-55
PCA Controller	6-56

## 7 Troubleshooting

Overview	7-1
Troubleshooting Process	7-2
Troubleshooting Flowchart	7-4
Troubleshooting Flowchart (Continued)	7-5
Troubleshooting the Printing System	7-6
Preliminary Operating Checks	7-6
Power On	7-7
Engine Test	7-11
Display	7-12
Event Log	7-13
Printer Messages	7-17
General Paper Path Troubleshooting	7-45
Information Pages	7-48
Image Quality	7-54
Image System Troubleshooting	7-74
Interface Troubleshooting	7-77
AUTOEXEC.BAT Standard Configurations	7-81
Reference Diagrams	7-84
Locations of Components	7-84
Paper Path	7-90
Engine Controller Board	7-93
Paper Size Detection Switches	7-94
Motors	7-96
Connectors	7-97
PCAs	7-100
Sensors and Thermistor	7-102
Solenoids and Clutch	7-105
Switches	7-108
Timing	7-110

## 8 Parts and Diagrams

Overview	8-1
How To Use the Parts Lists and Diagrams	8-2
Accessories and Supplies	8-4
Common Screws and Replacement Cables	8-6
Illustrations and Parts Lists	8-8
Alphabetical Parts List	8-58
Numerical Parts List	8-67