


For the complete PDF manual
please visit www.LaserPros.com.



English



HP LaserJet 5000, 5000 N
and 5000 GN Printers
Service Manual

HP LaserJet 5000, 5000 N, and 5000 GN Printers

Service Manual _____

**© Copyright Hewlett-Packard
Company 1998**

All Rights Reserved.
Reproduction, adaptation, or
translation without prior written
permission is prohibited, except
as allowed under the copyright
laws.

Publication number
C4110-91033

First Edition

Warranty

The information contained in
this document is subject to
change without notice.

Hewlett-Packard makes no
warranty of any kind with
respect to this information.
HEWLETT-PACKARD
SPECIFICALLY DISCLAIMS
THE IMPLIED WARRANTY OF
MERCHANTABILITY AND
FITNESS FOR A PARTICULAR
PURPOSE.

Hewlett-Packard shall not be
liable for any direct, indirect,
incidental, consequential, or
other damage alleged in
connection with the furnishing or
use of this information.

Trademark Credits

PostScript™ is a trademark of
Adobe Systems Incorporated
which may be registered in
certain jurisdictions.

CompuServe™ is a U.S.
trademark of CompuServe, Inc.

Windows® is a U.S. registered
trademarks of Microsoft
Corporation.

TrueType™ is a U.S. trademark
of Apple Computer, Inc.

ENERGY STAR® is a U.S.
registered service mark of the
U.S. EPA.

Contents

1 Printer Description

Overview	1-1
Printer Features	1-2
Identification	1-5
Model and Serial Numbers	1-5
Site Requirements	1-6
Space Requirements	1-7
Paper Specifications	1-11
Supported Types of Paper	1-14
Guidelines for Using Paper	1-15
Labels	1-18
Transparencies	1-18
Vellum	1-18
Envelopes	1-19
Card Stock and Heavy Paper	1-20
Safety Information	1-22
Laser Safety Statement	1-22
Canadian DOC Regulations	1-22
FCC Regulations	1-23
Laser Statement for Finland	1-24
Toner Safety	1-25
Environmental Product Stewardship	1-26

2 Service Approach

Overview	2-1
Service Approach	2-2
Parts and Supplies	2-3
Ordering Information	2-3
Helpful Documentation	2-4
Phone Numbers for Ordering	2-5
Exchange Program	2-5
Consumables	2-5
Technical Assistance	2-5
Toner Cartridge Information	2-8
Warranty Statement	2-9

3 Printer Operation

Overview	3-1
Using the Control Panel	3-2
Control Panel Layout	3-2
Control Panel Lights	3-2
Control Panel Keys	3-3
Settings and Defaults	3-4
Control Panel Menus	3-5
Information Menu	3-6
Paper Handling Menu	3-7
Print Quality Menu	3-10
Printing Menu	3-13
Configuration Menu.	3-17
I/O Menu	3-24
EIO Menu (Networked Printers)	3-27
Resets Menu.	3-29
Service Mode	3-30
Service Menu	3-31
Setting the Page Count, Maintenance Count, and Serial Number	3-31
Cold Reset Paper	3-34
Diagnostics	3-34
Clear Event Log	3-34
Testing the Printer	3-35
Resetting the Printer	3-36
System Configuration	3-37
MS-DOS System Configuration	3-37
Parallel DOS Commands	3-37
Serial MS-DOS Commands	3-38
Printer I/O Configuration	3-39
Parallel Menu	3-39
Serial Configuration	3-39

4 Printer Maintenance

Overview	4-1
Cleaning the Printer and Accessories	4-2
Cleaning Spilled Toner	4-4
Preventative Maintenance.	4-5
Reset Maintenance Count	4-5
Expected Life of Components.	4-5

5 Functional Information

Overview	5-1
Printer Subsystems	5-2
Power Supply System	5-3
AC/DC Power Distribution	5-3
Overcurrent Overvoltage Protection	5-5
High Voltage Power Distribution	5-6
Toner Cartridge Detection	5-7
DC Controller System	5-7
Laser and Scanner Drive	5-8
Paper Motion Monitoring and Control	5-9
Solenoids, Sensors, Clutches, and Switches	5-9
Engine Test Print	5-9
Motors	5-10
Formatter System	5-12
PowerSave	5-12
Resolution Enhancement technology (REt)	5-13
EconoMode	5-13
Input/Output	5-14
CPU	5-14
Printer Memory	5-15
Random Access Memory (RAM)	5-15
DIMM Slots	5-16
Memory Enhancement technology (MEt)	5-16
Page Protect	5-16
PJM Overview	5-17
PML	5-17
Control Panel	5-17
Image Formation System	5-18
Toner Cartridge	5-20
Photosensitive Drum	5-21
Writing the Image	5-24
Developing the Image	5-25
Transferring the Image	5-26
Image Fusing/Variable Fusing Temperature	5-27
Paper Feed System	5-29
Clutches and Sensors	5-30
Printing from Tray 1	5-31
Printing from Tray 2	5-33
Printing from the Optional 500-sheet and 250-sheet Trays	5-35
Paper Jam	5-37
Duplexer	5-38
Paper Jam in the Duplexer	5-44
Basic Sequence of Operation	5-45

6 Removing and Replacing Parts

Overview	6-1
User Installable Accessories	6-2
Removal and Replacement Strategy	6-7
Required Tools	6-7
Removing Covers	6-10
Rear Door / Rear Output Bin	6-10
Top Cover	6-12
Control Panel Overlay and Control Panel	6-15
Toner Cartridge Door Assembly	6-17
Front Cover and Tray 1	6-18
Front Cover Pins	6-20
Face Down Assembly	6-21
Left and Right Side Covers	6-23
Tray 1 Inner Cover	6-24
Right and Left Corner Covers	6-26
Removing Assemblies	6-27
Transfer Roller Assembly	6-28
Fuser	6-30
Paper Handling PCA	6-31
Main Gear Assembly	6-35
Pickup Gear Assembly	6-37
Tray 1 Pickup Solenoid	6-39
Fan	6-40
Formatter Assembly	6-41
Tray 1 Roller	6-42
Tray 2 Roller	6-43
Paper Feed Roller Assembly	6-44
DC Controller Board and Power Supply	6-47
Paper Feed Belt Assembly	6-51
Tray 1 Shaft	6-53
Tray 2 Shaft	6-55
Tray 1 Lift Plate	6-57
Tray 1 Separation Pad	6-58
Paper Guide	6-59
Paper Path Detect Sensor	6-60
Face Down Bin Full Sensor	6-61
Power Connection	6-63
Registration Assembly	6-64
Upper Delivery Assembly	6-66
Delivery Roller Removal	6-68
Laser Scanner Assembly	6-70
Main Motor	6-71
Toner Cartridge Guides	6-72
Power Inlet Assembly	6-73

Optional 500-sheet Tray Disassembly	6-74
Tray Indicator Assembly	6-76
Left Front Corner Cover Installation	6-77
Paper Size Spring Assembly	6-78
D-roller and Feed Roller	6-79
Gear Assembly and PCA	6-81
Power Connector	6-82
Separation Roller	6-83

7 Troubleshooting

Overview	7-1
Troubleshooting Process.	7-2
Troubleshooting Process Flow	7-4
Troubleshooting the Printing System	7-6
Preliminary Operating Checks	7-6
Power On	7-7
Display	7-11
Event Log	7-12
Printer Messages	7-16
General Paper Path Troubleshooting	7-41
Information Pages.	7-44
Image Quality	7-49
Interface Troubleshooting	7-77
Reference Diagrams	7-80
Locations of Components.	7-80
Sensors and Signals.	7-88
DC Controller PCA Inputs and Outputs	7-107

8 Parts and Diagrams

Overview	8-1
How To Use the Parts Lists and Diagrams	8-2
Accessories and Supplies	8-4
Common Hardware and Replacement Cables	8-6
Illustrations and Parts Lists	8-7
Alphabetical Parts List	8-39
Numerical Parts List	8-44

Index

For the complete PDF manual
please visit www.LaserPros.com.