



# LASERJET PROFESSIONAL P1560 and P1600 SERIES PRINTER

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).

## Service Manual







# HP LaserJet Professional P1560 and P1600 Series Printer

Service Manual

**Copyright and License**

© 2010 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number: CE663-90939


Edition 1, 4/2010

**Trademark Credits**


Microsoft®, Windows®, Windows® XP, and Windows Vista® are U.S. registered trademarks of Microsoft Corporation.


## Conventions used in this guide

---

 **TIP:** Tips provide helpful hints or shortcuts.

 **NOTE:** Notes provide important information to explain a concept or to complete a task.

 **CAUTION:** Cautions indicate procedures that you should follow to avoid losing data or damaging the product.

 **WARNING!** Warnings alert you to specific procedures that you should follow to avoid personal injury, catastrophic loss of data, or extensive damage to the product.

---



---

# Table of contents

<b>1 Theory of operation .....</b>	<b>1</b>
Basic operation .....	2
Major product systems .....	2
Product block diagram .....	2
Sequence of operation .....	3
Normal sequence of operation .....	3
Formatter-control system .....	4
Sleep mode .....	4
Input/output .....	4
CPU .....	4
Memory .....	4
Firmware .....	5
Memory use .....	5
PJM overview .....	5
LEDM overview .....	5
ACL overview .....	5
Control panel .....	6
Engine-control system .....	7
Motors, fans, clutches, solenoids, switches, and sensors .....	8
DC controller operations .....	13
Fuser-control circuit .....	15
Fuser failure detection .....	16
Fuser temperature control .....	17
Fuser protective function .....	18
Pressure roller cleaning .....	18
Low-voltage power supply .....	19
Overcurrent/overvoltage protection .....	20
High-voltage power supply .....	21
Laser/scanner system .....	22
Laser failure detection .....	23
Image-formation system .....	24
Electrophotographic process .....	24
Image formation process .....	26
Latent-image formation stage .....	27

Primary charging .....	27
Laser beam exposure .....	27
Developing stage .....	28
Print cartridge .....	28
Transfer stage .....	29
Fusing stage .....	29
Cleaning stage .....	30
Pickup, feed, and delivery system .....	31
Photo sensors and switches .....	32
Main-input tray or priority input slot .....	34
Jam detection .....	34

## **2 Removal and replacement ..... 35**

Introduction .....	36
Removal and replacement strategy .....	36
Electrostatic discharge .....	37
Required tools .....	37
Before performing service .....	37
After performing service .....	38
Post-service test .....	38
Print-quality test .....	38
Parts removal order .....	39
Pickup roller .....	40
Separation pad .....	41
Transfer roller .....	42
Covers .....	43
Main-input tray .....	43
Output bin tray extension .....	44
Left cover, simplex product .....	45
Remove the left cover, simplex product .....	45
Left cover, duplex product .....	47
Remove the left cover, duplex product .....	47
Right cover, simplex product .....	50
Remove the right cover, simplex product .....	50
Right cover, duplex product .....	52
Remove the right cover, duplex product .....	52
Duplex door, duplex product .....	55
Duplex frame, duplex product .....	56
Remove the duplex frame .....	56
Cartridge door .....	57
Control panel .....	59
Front cover .....	61
Remove the front cover .....	61

Rear cover, simplex product .....	63
Remove the rear cover, simplex product .....	63
Face-down cover .....	65
Remove the face-down cover .....	65
Main assemblies .....	67
Formatter PCA .....	67
Laser/scanner assembly .....	68
Remove the laser/scanner assembly .....	68
Reinstall the laser/scanner assembly .....	71
Pickup assembly .....	72
Remove the pickup assembly .....	72
Reinstall the pickup assembly .....	78
Fuser .....	80
Remove the fuser .....	80
Reinstall the fuser .....	86
Main motor .....	87
Remove the main motor .....	87
Reinstall the main-motor drive belt .....	92
Pickup solenoid .....	93
Remove the pickup solenoid .....	93
Engine controller PCA .....	97
Remove the engine controller PCA .....	97
Reinstall the engine controller PCA .....	102
Duplex-reverse solenoid, duplex product .....	104
Remove the duplex-reverse solenoid .....	104
Main fan, duplex product .....	107
Remove the main fan .....	107
Reinstall the main fan .....	109
Duplex-connector PCA, duplex product .....	110
Remove the duplex-connector PCA .....	110
<b>3 Solve problems .....</b>	<b>113</b>
Solve problems checklist .....	114
Troubleshooting process .....	116
Determine the problem source .....	116
Power subsystem .....	117
Power-on checks .....	117
Tools for troubleshooting .....	118
Individual component diagnostics .....	118
Engine diagnostics .....	118
Engine-test button .....	118
Components tests .....	119
Drum rotation functional check .....	119

Half self-test functional check .....	119
Diagrams .....	120
Plug/jack locations .....	120
Location of connectors .....	121
Locations of major components .....	122
General timing charts .....	125
General circuit diagram .....	126
Internal print-quality test pages .....	127
Cleaning page .....	127
Configuration page .....	127
Print-quality troubleshooting tools .....	128
Repetitive defect ruler .....	128
Interpret control-panel light patterns .....	128
Clear jams .....	133
Common causes of jams .....	133
Jam locations .....	133
Clear jams from the input trays .....	134
Clear jams from the duplexer .....	136
Clear jams from the output areas .....	138
Clear jams from inside the product .....	139
Solve repeated jams .....	141
Change jam recovery .....	142
Solve paper-handling problems .....	143
Solve image-quality problems .....	144
Image defect table .....	144
Light print or faded .....	144
Toner specks .....	144
Dropouts .....	145
Vertical lines .....	145
Gray background .....	145
Toner smear .....	146
Loose toner .....	146
Vertical repetitive defects .....	146
Misformed characters .....	146
Page skew .....	147
Curl or wave .....	147
Wrinkles or creases .....	147
Toner scatter outline .....	148
Moisture .....	148
Change print density .....	149
Clean the product .....	150
Clean the pickup roller .....	150
Clean the paper path .....	151
Clean the print-cartridge area .....	153

Clean the exterior .....	154
Solve performance problems .....	155
Solve connectivity problems .....	156
Solve direct-connect problems .....	156
Solve network problems .....	156
Service mode functions .....	158
Product resets .....	158
Product updates .....	158
Firmware updates .....	158
<b>4 Parts and diagrams .....</b>	<b>159</b>
Order parts by authorized service providers .....	160
Order replacement parts .....	160
Related documentation and software .....	160
Supplies part numbers .....	160
Customer self repair parts .....	161
Service parts .....	161
Whole-unit replacement part numbers .....	161
How to use the parts lists and diagrams .....	162
Assembly locations .....	163
Base product (no optional trays or accessories) .....	163
Covers .....	164
Simplex model .....	164
Duplex model .....	166
Internal assemblies .....	168
Internal assemblies (1 of 3) .....	168
Internal assemblies (2 of 3) .....	170
Internal assemblies (3 of 3) .....	172
PCAs .....	174
Alphabetical parts list .....	176
Numerical parts list .....	179
<b>Appendix A Service and support .....</b>	<b>183</b>
Hewlett-Packard limited warranty statement .....	184
HP's Premium Protection Warranty: LaserJet print cartridge limited warranty statement .....	185
End User License Agreement .....	186
Customer self-repair warranty service .....	188
Customer support .....	188
Repack the product .....	189
Service information form .....	190
<b>Appendix B Specifications .....</b>	<b>191</b>
Physical specifications .....	192

Power consumption .....	192
Acoustic specifications .....	192
Environmental specifications .....	193
<b>Appendix C Regulatory information .....</b>	<b>195</b>
FCC regulations .....	196
Declaration of conformity .....	197
Certificate of Volatility .....	198
Safety statements .....	200
Laser safety .....	200
Canadian DOC regulations .....	200
VCCI statement (Japan) .....	200
Power cord instructions .....	200
Power cord statement (Japan) .....	200
EMC statement (Korea) .....	200
Laser statement for Finland .....	201
GS statement (Germany) .....	201
Substances Table (China) .....	202
Restriction on Hazardous Substances statement (Turkey) .....	202
<b>Index .....</b>	<b>203</b>

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).