


# HP LaserJet P4010 and P4510 Series Printers

## Service Manual



For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).





HP LaserJet P4010 and P4510 Series Printers  
Service Manual



## Copyright and License

© 2008 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number: CB506-91004

Edition 1, 8/2008

## Trademark Credits

Adobe®, Acrobat®, and PostScript® are trademarks of Adobe Systems Incorporated.

Microsoft®, Windows®, and Windows®XP are U.S. registered trademarks of Microsoft Corporation.

Windows Vista® is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.

UNIX® is a registered trademark of The Open Group.

ENERGY STAR and the ENERGY STAR mark are registered U.S. marks.

---

# Table of contents

## 1 Product basics

Quick access to product information .....	2
Product comparison .....	3
HP LaserJet P4014 models .....	3
HP LaserJet P4015 models .....	4
HP LaserJet P4515 models .....	5
Product features .....	6
Product walkaround .....	8
Front view .....	8
Rear view .....	8
Interface ports .....	10
Model and serial-number label location .....	11
Supported operating systems .....	12
Supported product software .....	13
Software included with the product .....	13
Software for Windows .....	13
HP Web Jetadmin .....	13
Embedded Web server .....	13
HP Easy Printer Care .....	14
Software for Macintosh .....	14
HP Printer Utility .....	14
Supported printer drivers .....	16
Supported printer drivers for Windows .....	16
Supported printer drivers for Macintosh .....	16
Software for other operating systems .....	17
Connectivity .....	18
Supported network protocols .....	18

## 2 Control panel

Control-panel layout .....	20
Use the control-panel menus .....	22
Show Me How menu .....	23
Retrieve Job menu .....	24
Information menu .....	25

Paper Handling menu .....	26
Configure Device menu .....	27
Printing submenu .....	27
Print Quality submenu .....	30
System Setup submenu .....	33
Stapler Stacker submenu .....	37
MBM-5 (multi-bin mailbox) submenu .....	37
I/O submenu .....	38
Resets submenu .....	44
Diagnostics menu .....	45
Service menu .....	46

### 3 Paper and print media

Supported paper and print media sizes .....	48
Supported paper and print media types .....	50
Supported paper types for input options .....	50
Supported paper types for output options .....	51
Tray and bin capacity .....	52
Special paper or print media guidelines .....	53
Load trays .....	54
Paper orientation for loading trays .....	54
Load letterhead, preprinted, or prepunched paper .....	54
Load envelopes .....	55
Load Tray 1 .....	56
Load Tray 2 or an optional 500-sheet tray .....	57
Load an optional 1,500-sheet tray .....	59
Configure trays .....	61
Configure a tray when loading paper .....	61
Configure a tray to match print job settings .....	61
Configure a tray by using the Paper Handling menu .....	62
Select the paper by source, type, or size .....	62
Source .....	62
Type and size .....	62
Use paper output options .....	63
Print to the top (standard) output bin .....	63
Print to the rear output bin .....	63
Print to the optional stacker or stapler/stacker .....	64
Print to the 5-bin mailbox .....	64

### 4 Manage and maintain the product

Print the information and show-me-how pages .....	66
Use the HP Easy Printer Care software .....	68
Open the HP Easy Printer Care software .....	68

HP Easy Printer Care software sections .....	68
Use the embedded Web server .....	71
Open the embedded Web server by using a network connection .....	71
Embedded Web server sections .....	72
Use HP Web Jetadmin software .....	74
Use security features .....	75
IP Security .....	75
Secure the embedded Web server .....	75
Secure stored jobs .....	75
Lock the control panel menus .....	76
Lock the formatter cage .....	77
Manage supplies .....	78
Supplies life .....	78
Approximate print-cartridge replacement intervals .....	78
Manage the print cartridge .....	78
Print-cartridge storage .....	78
Use genuine HP print cartridges .....	78
HP policy on non-HP print cartridges .....	78
Print-cartridge authentication .....	79
HP fraud hotline and Web site .....	79
Replace supplies and parts .....	79
Supply replacement guidelines .....	79
Change the print cartridge .....	80
Load staples .....	82
Perform preventive maintenance .....	83
Reset the maintenance-kit counter .....	83
Install memory, internal USB devices, and external print server cards .....	84
Overview .....	84
Install memory .....	84
Install product memory .....	84
Check DIMM installation .....	88
Save resources (permanent resources) .....	88
Enable memory for Windows .....	89
Install internal USB devices .....	90
Install HP Jetdirect print server cards .....	93
Install an HP Jetdirect print server card .....	93
Remove an HP Jetdirect print server card .....	94
Clean the product .....	95
Clean the exterior .....	95
Clean the paper path .....	95
Clean the paper path automatically .....	95
Upgrade the firmware .....	96
Determine the current firmware version .....	96
Download new firmware from the HP Web site .....	96

Transfer the new firmware to the product .....	96
Use FTP to upload the firmware through a browser .....	96
Use FTP to upgrade the firmware on a network connection .....	97
Use HP Web Jetadmin to upgrade the firmware .....	98
Use Microsoft Windows commands to upgrade the firmware .....	98
Upgrade the HP Jetdirect firmware .....	98

## 5 Theory of operation

Basic operation .....	102
Major print systems .....	102
Internal components .....	103
Operating sequence .....	106
Engine-control system .....	107
DC controller PCA .....	107
Motors and fans .....	108
Failure detection .....	109
Motor failure .....	109
Fan motor failure .....	109
Engine power supply .....	109
Fuser-control circuit .....	109
Low-voltage power supply .....	111
High-voltage power supply .....	111
Overcurrent/overvoltage protection .....	112
Laser/scanner system .....	113
Laser failure detection .....	114
Image-formation system .....	115
Image-formation process .....	115
Block 1: Latent image formation .....	116
Step 1: Primary charging .....	116
Step 2: Laser-beam exposure .....	117
Block 2: Developing .....	117
Step 3: Developing .....	117
Block 3: Transfer .....	117
Step 4: Transfer .....	118
Step 5: Separation .....	118
Block 4: Fusing .....	118
Step 6: Fusing .....	119
Block 5: Drum cleaning .....	119
Step 7: Drum cleaning .....	119
Step 8: Drum charge elimination .....	119
Pickup, feed, and delivery system .....	121
Pickup-and-feed block .....	122
Fuser/delivery block .....	123

Paper trays .....	123
Printing from Tray 1 .....	123
Printing from Tray 2 .....	123
Formatter system .....	123
Sleep mode .....	124
Resolution Enhancement technology .....	124
EconoMode .....	124
Input/output .....	125
USB .....	125
Embedded print server .....	125
Expanded I/O .....	125
Hard-disk accessory .....	125
CPU .....	125
Product memory .....	125
Read-only memory .....	125
Random-access memory .....	125
DIMM slot .....	125
Nonvolatile memory .....	126
Memory Enhancement technology .....	126
PJM overview .....	126
PML .....	126
Control panel .....	126

## 6 Removal and replacement

Removal and replacement strategy .....	128
Warnings, cautions, notes, and tips .....	128
Electrostatic discharge .....	128
Required tools .....	129
Service approach .....	130
Before performing service .....	130
After performing service .....	130
Post-service tests .....	131
Test 1 (print-quality test) .....	131
Types of screws .....	132
Parts removal order .....	133
Product input trays and cabinet wheel locks .....	134
DC controller diagram .....	135
User-replaceable parts .....	137
Print cartridge .....	137
Memory DIMM .....	139
Tray 2 .....	140
Tray 2 separation, pickup, and feed rollers .....	141
Transfer roller .....	143

Top-accessory cover .....	144
Envelope feed accessory covers .....	145
Duplex accessory or cover .....	146
Tray 2 extension door .....	147
Rear output bin .....	148
Fuser .....	149
Formatter cover, formatter cage, and formatter PCA .....	150
Reinstallation notes, formatter .....	151
Installing a new formatter and a new DC controller .....	151
Service replaceable parts .....	152
Tray 1 pickup and feed rollers .....	152
Tray 1 separation roller .....	155
Registration assembly .....	157
Top cover .....	159
Right-side cover .....	161
Reinstall the right cover .....	162
Left-side cover .....	164
Right-front cover .....	166
Rear-upper cover .....	169
Control-panel assembly .....	170
Front cover .....	172
Fan FN102 .....	174
Fan FN103 .....	176
Pickup-motor assembly (M101) .....	178
Drum-motor assembly (M102) .....	180
Lifter-motor assembly (M103) .....	183
DC controller PCA .....	186
Reinstallation tip .....	189
Installing a new formatter and a new DC controller .....	189
Pickup-drive assembly .....	190
Reinstall the pickup-drive assembly .....	194
Fuser-motor assembly (M299) .....	195
Drum-drive assembly .....	197
Reinstall the drum-drive assembly .....	199
Fan FN101 .....	200
Fan FN301 .....	202
Environmental sensor (TH3) .....	204
High voltage power supply .....	206
Feed-guide assembly .....	211
Reinstall the feed-guide assembly .....	212
Tray 1 paper-pickup assembly .....	214
Feed-roller assembly .....	216
Laser/scanner assembly .....	217
Paper-delivery assembly .....	219

Reinstall the paper-delivery assembly .....	222
1,500-sheet feeder assembly .....	223
1,500-sheet feeder feed rollers .....	223
1,500-sheet feeder separation roller .....	224
1,500-sheet feeder rear cover .....	225
1,500-sheet feeder right-side cover .....	226
1,500-sheet feeder left-side cover .....	227
1,500-sheet feeder door .....	230
1,500-sheet feeder motor .....	232
1,500-sheet feeder driver PCA .....	233
1,500-sheet feeder lift-drive assembly .....	234

## 7 Solve problems

Troubleshooting checklist .....	238
Menu map .....	239
Troubleshooting process .....	240
Power-on checks .....	240
Overview .....	240
Troubleshooting tools .....	243
Individual component diagnostics .....	243
LED diagnostics .....	243
Understand lights on the formatter .....	243
Formatter test .....	244
Engine diagnostics .....	244
Engine test .....	244
Half self test .....	245
Drum rotation test .....	245
Paper path sensors test .....	246
Paper path test .....	248
Sensor test (interactive) .....	248
Manual sensor test (special mode test) .....	248
Manual sensor test 2 (special mode test) .....	256
Print/stop test .....	257
Component tests .....	259
Diagrams .....	260
Block diagrams .....	260
Main assemblies .....	260
Main parts .....	261
Motors and fans .....	262
PCAs .....	263
500-sheet feeder .....	263
1,500-sheet feeder .....	264
Connectors .....	266

DC controller PCA connectors .....	266
Product base connectors .....	268
500-sheet paper tray connectors .....	268
1,500-sheet paper tray connectors .....	269
Duplexer connectors .....	270
Envelope feeder connectors .....	270
General timing chart .....	271
Circuit diagrams .....	271
Print quality troubleshooting tools .....	278
Repetitive image defect ruler .....	278
Cleaning page .....	278
Control-panel messages .....	280
Event log messages .....	300
Print an event log .....	300
Show an event log .....	300
Sample event log .....	301
Paper-handling problems .....	302
Jams .....	302
Common causes of jams .....	302
Jam locations .....	304
Clear jams .....	305
Clear jams from the top-cover and print-cartridge areas .....	305
Clear jams from the optional envelope feeder .....	307
Clear jams from the trays .....	309
Clear jams from the optional duplexer .....	312
Clear jams from the fuser area .....	313
Clear jams from the output areas .....	318
Jam recovery .....	323
Product feeds incorrect page size .....	324
Output is curled or wrinkled .....	325
Product will not duplex or duplexes incorrectly .....	326
Solve image quality problems .....	327
Image defects .....	327
Solve performance problems .....	332
Solve connectivity problems .....	333
Solve direct-connect problems .....	333
Solve network connectivity problems .....	333
Solve network printing problems .....	333
Ping test .....	334
Service mode functions .....	335
Service menu .....	335
Product resets .....	336
Restore factory-set defaults .....	336
Hard disk initialization .....	336

NVRAM initialization .....	336
Cold reset .....	337
Service ID .....	337
Restore the service ID .....	337
Convert the service ID to an actual date .....	337
Reset page counts .....	338
Cold reset paper .....	338

## 8 Parts

Order parts, accessories, and supplies .....	340
Order directly from HP .....	340
Order through service or support providers .....	340
Order directly through the HP Easy Printer Care software .....	340
Order replacement parts .....	340
Paper-handling accessories .....	341
Print cartridges .....	342
Maintenance kits .....	342
Memory .....	343
Cables and interfaces .....	343
Paper .....	344
How to use the parts lists and diagrams .....	347
Customer/field-replaceable units .....	348
Assembly locations .....	350
Covers .....	354
Internal components .....	356
PCAs .....	384
Input devices .....	390
Output devices .....	414
Alphabetical parts list .....	423
Numerical parts list .....	458

## Appendix A Service and support

Hewlett-Packard limited warranty statement .....	493
Print cartridge limited warranty statement .....	494
Customer self-repair warranty service .....	495
Customer support .....	496
HP maintenance agreements .....	497
On-site service agreements .....	497
Next-day on-site service .....	497
Weekly (volume) on-site service .....	497
Repacking the device .....	497
Extended warranty .....	498

## Appendix B Specifications

Physical specifications .....	500
Electrical specifications .....	500
Acoustic specifications .....	502
Operating environment .....	502

## Appendix C Regulatory information

FCC regulations .....	504
Declaration of conformity .....	505
Declaration of conformity .....	505
Safety statements .....	506
Laser safety .....	506
Canadian DOC regulations .....	506
VCCI statement (Japan) .....	506
Power cord statement (Japan) .....	506
EMI statement (Korea) .....	506
Laser statement for Finland .....	507
Substances table (China) .....	508

Index .....	509
-------------	-----

For the complete PDF manual  
please visit [www.LaserPros.com](http://www.LaserPros.com).